
MITSUBISHI

Operating Manual






• SAFETY PRECAUTIONS •

(Read these precautions before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only. For the safety precautions of the programmable controller system, refer to the user's manual for the CPU module User's Manual.

In this manual, the safety precautions are classified into two levels: "AWARNING" and "ACAUTION".



Under some circumstances, failure to observe the precautions given under "ACAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety.

Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

[Start-Up/Maintenance Precautions]

⚠ CAUTION

 Before performing the OPR, JOG operation, inching operation, positioning data test or other operation in the test mode, read the manual carefully, fully ensure safety, and set the programmable controller CPU to STOP.

Not doing so can damage the machine or cause an accident due to misoperation.

A - 1 A - 1

• CONDITIONS OF USE FOR THE PRODUCT •

- (1) Mitsubishi programmable controller ("the PRODUCT") shall be used in conditions;
 - i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and
 - ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.
- (2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries.

MITSUBISHI SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI'S USER, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BULLETINS AND GUIDELINES FOR the PRODUCT.

("Prohibited Application")

Prohibited Applications include, but not limited to, the use of the PRODUCT in;

- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
- Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
- Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property.

Notwithstanding the above, restrictions Mitsubishi may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTs are required. For details, please contact the Mitsubishi representative in your region.

A - 2

REVISIONS

* The manual number is given on the bottom left of the back cover.

Print Date *Manual Number Revision Jun., 2001 SH (NA)-080172-A First edition Sep., 2001 SH (NA)-080172-B Modifications CONTENTS, Section 4.1.1, Section 4.1.2, Section 4.2, INDEX Feb., 2002 SH (NA)-080172-C Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Section 2.2, Section 3.2, Section 5.1, Section 8.2, Section 11.1.3, Section 11.2.1, Appendix 3 Aug., 2002 SH (NA)-080172-D Modifications SOFTWARE USER REGISTRATION, CONTENTS, Section 1.1, Section 2.1, Section 2.2, Section 3.2, Section 4.2, Section 5.1, Section 5.2, Section 6.3, Section 6.6.2, Section 7.1, Section 7.4, Section 8.2, Section 8.3.1, Section 8.3.2, Section 10.2.5, Section 10.2.5, Section 10.2.6, Section 10.3.2, Section 10.4.1 to Section 10.2.5, Section 10.2.6, Section 10.3.2, Section 10.4.1 to Section 10.4.5, Section 11.4, Section 11.2.1 to Section 11.2.3, Section 11.4, Section 11.6.2, Section 11.7.2, Section 11.8.2, Appendix 2, Appendix 3 Feb., 2003 SH (NA)-080172-E Modifications CONTENTS, ABOUT MANUALS, Section 2.1, Section 2.2, Section 4.1.2, Section 2.2, Section 4.3, Appendix 3, INDEX May., 2004 SH (NA)-080172-F Modifications SOFTWARE USER REGISTRATION, Section 2.1, Section 2.1, Section 2.2, Section 10.4, Section 2.2, Section 10.2.6, Section 10.2.6, Section 6.3, Section 8.2, Section 10.2.5, Section 10.4, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-F Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 6.6, Section 1.1, Section 1.1, Section 1.1, Section 1.1, Sect		· · · · · · ·	* The manual number is given on the bottom left of the back cover.
Sep., 2001 SH (NA)-080172-B Modifications			
CONTENTS, Section 4.1.1, Section 4.1.2, Section 4.2, INDEX	,	. ,	
Feb., 2002 SH (NA)-080172-C Modifications	Sep., 2001	SH (NA)-080172-B	<u> </u>
ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Section 2.2, Section 3.2, Section 5.1, Section 8.2, Section 11.1.3, Section 11.2.1, Appendix 3 Aug., 2002 SH (NA)-080172-D Modifications SOFTWARE USER REGISTRATION, CONTENTS, Section 1.1, Section 2.1, Section 2.2, Section 3.2, Section 4.2, Section 5.1, Section 5.2, Section 6.1, Section 6.3, Section 6.6.2, Section 7.1, Section 7.2, Section 6.1, Section 8.2, Section 8.3.1, Section 8.3.2, Section 8.5.1, Section 10.2.5, Section 10.3.2, Section 10.4.1 to Section 10.2.5, Section 10.2.5, Section 10.2.6, Section 10.3.2, Section 10.4.1 to Section 10.4.5, Section 11.1.4, Section 11.2.1 to Section 11.2.3, Section 11.4, Section 11.6.2, Section 11.7.2, Section 11.8.2, Appendix 2, Appendix 3 Feb., 2003 SH (NA)-080172-E Modifications CONTENTS, ABOUT MANUALS, Section 2.1, Section 2.2, Section 4.1.2, Section 4.1.3, Section 4.2, Section 4.3, Appendix 3, INDEX May., 2004 SH (NA)-080172-F Modifications SOFTWARE USER REGISTRATION, Section 2.1, Section 2.2, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-G Modifications SOFTWARE USER REGISTRATION, Section 2.1, Section 10.4, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 2.1, Section 6.1, Section 6.2, Section 6.3, Section 6.2, Section 6.2, Section 6.4, Section 6.4, Section 6.1, Section 6.4, Section 6.4, Section 6.2, Section 6.2, Section 6.2, Section 6.4, Section 6.4, Section 6.4, Section 6.2, Section 6.4, Sec			
Aug., 2002 SH (NA)-080172-D Modifications SOFTWARE USER REGISTRATION, CONTENTS, Section 1.1, Section 2.1, Section 2.2, Section 3.2, Section 4.2, Section 5.1, Section 5.2, Section 5.1, Section 5.2, Section 6.3, Section 6.6, Section 7.1, Section 7.2, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.1, Section 10.2.5, Section 10.2.5, Section 10.2.6, Section 10.3.2, Section 10.4.1 to Section 10.4.5, Section 11.1.4, Section 11.2.1 to Section 11.2.3, Section 11.4, Section 11.6.2, Section 11.7.2, Section 11.8.2, Appendix 2, Appendix 3 Feb., 2003 SH (NA)-080172-E Modifications CONTENTS, ABOUT MANUALS, Section 2.1, Section 2.2, Section 4.1.2, Section 4.1.3, Section 4.2, Section 4.3, Appendix 3, INDEX May., 2004 SH (NA)-080172-F Modifications SOFTWARE USER REGISTRATION, Section 2.1, Section 10.4, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-G Modifications SOFTWARE USER REGISTRATION, Section 10.2.5, Section 10.4, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-G Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 1.1, Section 7.4, Section 3.1, Chapter 6, Section 6.1, Section 1.1, Section 7.4, Section 8.2, Section 8.3, I, Section 10.2.4 to	Feb., 2002	SH (NA)-080172-C	Modifications
SOFTWARE USER REGISTRATION, CONTENTS, Section 1.1, Section 2.1, Section 2.2, Section 3.2, Section 4.2, Section 5.1, Section 5.2, Section 6.1, Section 6.3, Section 6.6.2, Section 7.1, Section 7.2, Section 7.4, Section 8.2, Section 8.3.1, Section 8.3.2, Section 8.5.1, Section 8.5.2, Section 9.1, Section 10.1, Section 10.2.1, Section 10.2.5, Section 10.2.6, Section 10.3.2, Section 10.4.1 to Section 10.4.5, Section 11.1.4, Section 11.2.1 to Section 11.2.3, Section 11.4, Section 11.6.2, Section 11.7.2, Section 11.8.2, Appendix 2, Appendix 3 Feb., 2003 SH (NA)-080172-E Modifications CONTENTS, ABOUT MANUALS, Section 2.1, Section 2.2, Section 4.1.2, Section 4.1.3, Section 4.2, Section 4.3, Appendix 3, INDEX May., 2004 SH (NA)-080172-F Modifications SOFTWARE USER REGISTRATION, Section 2.1, Section 2.2, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to			Section 3.2, Section 5.1, Section 8.2, Section 11.1.3, Section 11.2.1,
Section 2.1, Section 2.2, Section 3.2, Section 4.2, Section 5.1, Section 5.2, Section 6.1, Section 6.3, Section 6.6.2, Section 7.1, Section 7.2, Section 7.4, Section 8.2, Section 8.3.1, Section 8.3.2, Section 8.5.1, Section 8.5.2, Section 9.1, Section 10.1, Section 10.2.1, Section 10.2.5, Section 10.2.6, Section 10.3.2, Section 10.4.1 to Section 10.4.5, Section 11.1.4, Section 11.2.1 to Section 11.2.3, Section 11.4, Section 11.6.2, Section 11.7.2, Section 11.8.2, Appendix 2, Appendix 3	Aug., 2002	SH (NA)-080172-D	Modifications
Section 2.1, Section 2.2, Section 3.2, Section 4.2, Section 5.1, Section 5.2, Section 6.1, Section 6.3, Section 6.6.2, Section 7.1, Section 7.2, Section 7.4, Section 8.2, Section 8.3.1, Section 8.3.2, Section 8.5.1, Section 8.5.2, Section 9.1, Section 10.1, Section 10.2.1, Section 10.2.5, Section 10.2.6, Section 10.3.2, Section 10.4.1 to Section 10.4.5, Section 11.1.4, Section 11.2.1 to Section 11.2.3, Section 11.4, Section 11.6.2, Section 11.7.2, Section 11.8.2, Appendix 2, Appendix 3	- I		SOFTWARE USER REGISTRATION, CONTENTS, Section 1.1,
Section 5.2, Section 6.1, Section 6.3, Section 6.6.2, Section 7.1, Section 7.2, Section 7.4, Section 8.2, Section 8.3.1, Section 8.3.2, Section 8.5.1, Section 8.5.2, Section 9.1, Section 10.1, Section 10.2.1, Section 10.2.5, Section 10.2.6, Section 10.3.2, Section 10.4.1 to Section 10.4.5, Section 11.4, Section 11.2.1 to Section 11.2.3, Section 11.4, Section 11.6.2, Section 11.7.2, Section 11.8.2, Appendix 2, Appendix 3 Feb., 2003 SH (NA)-080172-E Modifications	l		
Section 7.2, Section 8.2, Section 8.3.1, Section 8.3.2, Section 8.5.1, Section 8.5.1, Section 8.5.2, Section 9.1, Section 10.1, Section 10.2.1, Section 10.2.5, Section 10.2.6, Section 10.3.2, Section 10.4.1 to Section 10.4.5, Section 11.4, Section 11.2.1 to Section 11.2.3, Section 11.4, Section 11.6.2, Section 11.7.2, Section 11.8.2, Appendix 2, Appendix 3 Feb., 2003 SH (NA)-080172-E	l		
Section 8.5.1, Section 8.5.2, Section 9.1, Section 10.1, Section 10.2.1, Section 10.2.5, Section 10.2.6, Section 10.3.2, Section 10.4.1 to Section 10.4.5, Section 11.4, Section 11.2.1 to Section 11.2.3, Section 11.4, Section 11.6.2, Section 11.7.2, Section 11.8.2, Appendix 2, Appendix 3 Feb., 2003 SH (NA)-080172-E Modifications CONTENTS, ABOUT MANUALS, Section 2.1, Section 2.2, Section 4.1.2, Section 4.1.3, Section 4.2, Section 4.3, Appendix 3, INDEX May., 2004 SH (NA)-080172-F Modifications SOFTWARE USER REGISTRATION, Section 2.1, Section 10.4, Section 12.2, Section 10.2, INDEX Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	l		
Section 10.2.5, Section 10.2.6, Section 10.3.2, Section 10.4.1 to Section 10.4.5, Section 11.1.4, Section 11.2.1 to Section 11.2.3, Section 11.4, Section 11.6.2, Section 11.7.2, Section 11.8.2, Appendix 2, Appendix 3 Feb., 2003 SH (NA)-080172-E Modifications CONTENTS, ABOUT MANUALS, Section 2.1, Section 2.2, Section 4.1.2, Section 4.1.3, Section 4.2, Section 4.3, Appendix 3, INDEX May., 2004 SH (NA)-080172-F Modifications SOFTWARE USER REGISTRATION, Section 2.1, Section 2.2, Section 6.3, Section 8.2, Section 10.2.5, Section 10.4, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	l		
Section 10.4.5, Section 11.1.4, Section 11.2.1 to Section 11.2.3, Section 11.4, Section 11.6.2, Section 11.7.2, Section 11.8.2, Appendix 2, Appendix 3 Feb., 2003 SH (NA)-080172-E Modifications CONTENTS, ABOUT MANUALS, Section 2.1, Section 2.2, Section 4.1.2, Section 4.1.3, Section 4.2, Section 4.3, Appendix 3, INDEX May., 2004 SH (NA)-080172-F Modifications SOFTWARE USER REGISTRATION, Section 2.1, Section 2.2, Section 6.3, Section 8.2, Section 10.2.5, Section 10.4, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	l		
Feb., 2003 SH (NA)-080172-E Modifications CONTENTS, ABOUT MANUALS, Section 2.1, Section 2.2, Section 4.1.2, Section 4.1.3, Section 4.2, Section 4.3, Appendix 3, INDEX May., 2004 May., 2004 SH (NA)-080172-F Modifications SOFTWARE USER REGISTRATION, Section 2.1, Section 10.4, Section 11.6.2, INDEX Mar., 2005 Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	l		
Feb., 2003 SH (NA)-080172-E Modifications CONTENTS, ABOUT MANUALS, Section 2.1, Section 2.2, Section 4.1.2, Section 4.1.3, Section 4.2, Section 4.3, Appendix 3, INDEX May., 2004 SH (NA)-080172-F Modifications SOFTWARE USER REGISTRATION, Section 2.1, Section 2.2, Section 6.3, Section 8.2, Section 10.2.5, Section 10.4, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	l		
CONTENTS, ABOUT MANUALS, Section 2.1, Section 2.2, Section 4.1.2, Section 4.1.3, Section 4.2, Section 4.3, Appendix 3, INDEX May., 2004 SH (NA)-080172-F Modifications SOFTWARE USER REGISTRATION, Section 2.1, Section 2.2, Section 6.3, Section 8.2, Section 10.2.5, Section 10.4, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	l		
May., 2004 SH (NA)-080172-F Modifications SOFTWARE USER REGISTRATION, Section 2.1, Section 2.2, Section 6.3, Section 8.2, Section 10.2.5, Section 10.4, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	Feb., 2003	SH (NA)-080172-E	Modifications
May., 2004 SH (NA)-080172-F Modifications SOFTWARE USER REGISTRATION, Section 2.1, Section 2.2, Section 6.3, Section 8.2, Section 10.2.5, Section 10.4, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	l		CONTENTS, ABOUT MANUALS, Section 2.1, Section 2.2, Section 4.1.2,
SOFTWARE USER REGISTRATION, Section 2.1, Section 2.2, Section 6.3, Section 8.2, Section 10.2.5, Section 10.4, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	<u> </u>		Section 4.1.3, Section 4.2, Section 4.3, Appendix 3, INDEX
Section 2.2, Section 6.3, Section 8.2, Section 10.2.5, Section 10.4, Section 11.6.2, INDEX Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	May., 2004	SH (NA)-080172-F	Modifications
Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	l		SOFTWARE USER REGISTRATION, Section 2.1,
Mar., 2005 SH (NA)-080172-G Modifications ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	1		
ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 1.1, Section 2.1, Section 3.1, Chapter 6, Section 6.1, Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	Mar., 2005	SH (NA)-080172-G	· · · · · · · · · · · · · · · · · · ·
Section 6.6.1, Section 7.4, Section 8.2, Section 8.3.1, Section 10.2.4 to	, 	,	ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1,
0000011 10.210, 0000011 10.12, 0000011 11.110,	i		•
Section 11.4, Section 11.6.2, Section 11.8, Section 11.9, Appendix 1 to	l		Section 11.4, Section 11.6.2, Section 11.8, Section 11.9, Appendix 1 to
Appendix3	l		Appendix3
Addition	l		Addition
Section 2.3			Section 2.3
May, 2007 SH (NA)-080172-H Modifications	May, 2007	SH (NA)-080172-H	Modifications
ABOUT MANUALS, ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 2.1, Section 11.1.3, Appendix 3			· · · · · · · · · · · · · · · · · · ·
Jan., 2008 SH (NA)-080172-I Modifications	Jan., 2008	SH (NA)-080172-I	Modifications
ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Section 2.1,	ı		ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Section 2.1,
Section 4.1.2, Section 4.1.3, Section 4.2, Section 4.3, Section 11.10,	l		
Appendix 3			
Apr., 2008 SH (NA)-080172-J Modifications	Apr., 2008	SH (NA)-080172-J	Modifications
ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 2.1, Section 3.1, Chapter 6, Section 7.1, Section 8.2,	1		
Section 10.2.6, Section 11.1.3, Appendix 3			
Oct., 2008 SH (NA)-080172-K Modifications Chapter 1, Section 2.1, Section 7.1, Section 8.2, Section 11.1.3,	Oct., 2008	SH (NA)-080172-K	
Appendix 3	ı		

A - 3

Print Date	* Manual Number	Revision
Mar., 2009	SH (NA)-080172-L	Modifications
		ABOUT MANUALS, ABOUT THE GENERIC TERMS AND
		ABBREVIATIONS, Chapter 1, Section 2.1, Section 2.3, Section 4.1.2,
		Section 7.1, Appendix 3 Addition
		Section 7.1.1
Apr., 2010	SH (NA)-080172-M	
Apr., 2010	311 (NA)-000 17 2-W	SAFETY PRECAUTIONS, SOFTWARE USER REGISTRATION,
		ABOUT MANUALS, ABOUT THE GENERIC TERMS AND
		ABBREVIATIONS, PACKING LIST, Chapter 1, Section 1.1, 2.1, 2.2, 2.3,
		3.1, 4.1.2, 4.1.3, 4.1.4, 4.2, 4.3, 5.1, 5.2, Chapter 6, Section 6.1, 6.6.1,
		6.6.2, Chapter 7, Section 7.1, 7.1.1, 7.2, 7.3, 7.4, Chapter 8, Section 8.1, 8.2, 8.3, 8.6, Chapter 9, Section 9.1, 9.2, 9.3, 9.4, Chapter 10,
		Section 10.1, 10.2.1 to 10.2.6, 10.3.2, 10.4, 10.4.1 to 10.4.5, 10.5, 11.1.2,
		11.1.3, 11.1.4, 11.2.1, 11.2.2, 11.2.4, 11.4, 11.5, 11.7, 11.7.1, 11.7.2,
		11.8, 11.8.1, 11.8.2, 11.9, 11.9.1, 11.9.2, 11.10, Appendix 1 to 3, INDEX
		Addition
	011 (114) 000 (70 11	CONDITIONS OF USE FOR THE PRODUCT
Apr., 2011	SH (NA)-080172-N	<u> </u>
		SAFETY PRECAUTIONS, ABOUT MANUALS, ABOUT THE GENERIC TERMS AND ABBREVIATIONS, Section 2.1, Section 2.2, Section 4.1.2,
		Appendix 3
May, 2012	SH (NA)-080172-O	
	,	Section 2.2, Section 11.8.2

Japanese Manual Version SH-080137-R

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

INTRODUCTION

Thank you for choosing the Mitsubishi MELSOFT Series Integrated FA software. Read this manual and make sure you understand the functions and performance of MELSOFT series thoroughly in advance to ensure correct use.

CONTENTS

SAFETY PRECAUTIONS	
CONDITIONS OF USE FOR THE PRODUCT	
REVISIONS	
INTRODUCTION	
CONTENTS	
ABOUT MANUALS	
HOW TO USE THIS MANUAL	
ABOUT THE GENERIC TERMS AND ABBREVIATIONS	
PACKING LIST	A-12
1. OVERVIEW	1- 1 to 1- 7
1.1 Features	1- 3
1.2 Manual Makeup	1- 7
2. SYSTEM CONFIGURATION	2- 1 to 2-11
2.1 System Configuration	2- 1
2.2 Operating Environment	2- 9
2.3 Instructions for use of older version of GX Configurator-QP	
3. FUNCTION LIST	3- 1 to 3- 4
3.1 Function List	3- 1
3.2 Menu List	3- 4
4. INSTALLATION AND UNINSTALLATION	4- 1 to 4-33
4.1 Installation	4- 1
4.1 Installation	
	4- 1
4.1.1 Installation procedure	4- 1 4- 2
4.1.1 Installation procedure	4- 1 4- 2 4-12
4.1.1 Installation procedure 4.1.2 Installing GX Configurator-QP 4.1.3 Installing the USB driver.	4- 1 4- 2 4-12 4-21
4.1.1 Installation procedure 4.1.2 Installing GX Configurator-QP 4.1.3 Installing the USB driver 4.1.4 Upgrading the USB drivers 4.2 Uninstallation 4.3 Starting GX Configurator-QP	
4.1.1 Installation procedure 4.1.2 Installing GX Configurator-QP 4.1.3 Installing the USB driver 4.1.4 Upgrading the USB drivers 4.2 Uninstallation	4- 1 4- 2 4-12 4-21 4-28 4-31
4.1.1 Installation procedure 4.1.2 Installing GX Configurator-QP 4.1.3 Installing the USB driver 4.1.4 Upgrading the USB drivers 4.2 Uninstallation 4.3 Starting GX Configurator-QP	
4.1.1 Installation procedure 4.1.2 Installing GX Configurator-QP 4.1.3 Installing the USB driver 4.1.4 Upgrading the USB drivers 4.2 Uninstallation 4.3 Starting GX Configurator-QP 4.4 Exiting GX Configurator-QP	4- 1 4- 2 4-12 4-21 4-28 4-31 4-32 5- 1 to 5- 4

6. PROJECT CREATION	6- 1 to 6-18
6.1 Creating a New Project 6.2 Opening the Existing Project 6.3 Saving the Project 6.4 Closing the Project 6.5 Deleting the Project 6.6 Reading other Format Files 6.6.1 Reading SW1RX/IVD/NX-AD75P / GX Configurator-AP format file 6.6.2 Reading the CSV format file 6.7 Write to CSV Format File	
7. SYSTEM CHECKING FROM PERIPHERAL DEVICE	7- 1 to 7-12
7.1 Connection Setup	7- 6 7- 8 7- 9
8. DATA SETTING	8- 1 to 8-20
8.1 Parameter Setting 8.2 Servo Parameter Setting 8.3 Positioning Data Setting 8.3.1 Positioning data 8.3.2 M code comment 8.4 Simulation 8.5 Block Start Data Setting 8.5.1 Block start data 8.5.2 Condition data 8.6 Error Check	8- 3 8- 6 8- 6 8-12 8-13 8-16 8-18
9. WRITING TO/READING OF/VERIFICATION OF POSITIONING MODULE DATA	9- 1 to 9- 7
9.1 Write to Module/Read from Module/Verify Module Data	9- 6 9- 7
10. POSITIONING DEBUGGING	10- 1 to 10-42
10.1 Error Check Module Data 10.2 Monitor	
10.2.6 Servo monitor	10-19

Appendix 1 Read from Module/Write to Module Reference Processing Times	10.3 Sampling Monitor	10-25
10.4 Positioning start test 10.4.1 Positioning start test 10.4.2 Present value change test 10.4.3 Speed change test 10.4.3 Speed change test 10.4.5 JOG/MPG operation test 10.4.5 JOG/MPG operation test 10.4.5 JOG/MPG operation test 10.4.5 JOG/MPG operation test 11.1 USEFUL FUNCTIONS 11- 1 to 11-4 11.1 USEFUL FUNCTIONS 11- 1 to 11-4 11.1 Useful Functions for Projects 11- 1 11.1.1 Verifying the project data 11- 1 11.2 Changing the model after data setting 11- 1 11.1.3 Intelligent function utility 11- 1 11.2 Changing the model after data setting 11- 1 11.2 Loulfooplypaste 11- 1 11.2 Jump 11- 1 11.2 Jump 11- 1 11.2 Jump 11- 1 11.3 Clearing the rows/columns 11- 1 11.3 Copying the Data 11- 1 11.5 Option Setting 11- 1 11.6 Printing the Project Data 11- 1 11.6 Printing the Project Data 11- 1 11.6 Printing the Project Data 11- 1 11.7 Positioning Data Setting in Test Mode 11.9 Location trace condition setting 11.9 Location trace condition setting 11.9 Location trace sexcution 11.9 Appendix 2 Restrictions Depending on Function Version of QD75 11.5 Appendix 5 App	10.3.1 Sampling signal monitor	10-25
10.4.1 Positioning start test. 10-3; 10.4.2 Present value change test 10.3 10.4.3 Present value change test 10.3 10.4.3 Posed change test 10.3 10.4.5 JOG/MPG operation test. 10.3 10.4.5 JOG/MPG operation test. 10.5 servo On/Off. 10.4 10.5 Servo On/Off. 10.4 11.0 Servo On/Off. 10.4 11.0 Servo On/Off. 10.4 11.1 USEFUL FUNCTIONS 11- 1 to 11-4 11.1 Useful Functions for Projects. 11.1 Verifying the project data 11- 11.1 Verifying the project data 11- 11.1 Sintelligent function utility 11.1 Useful Functions for Projects. 11.1 Useful Functions for Data Setting 11- 11.1 Useful Functions for Data Setting 11.1 Useful Function for Data Setting 11.1 Useful Function for Data Setting 11.1 Useful Function Function 11.1 Useful Function Function 11.1 Useful Function Function 11.1 Useful Function 11.1 Useful Function Function 11.1 Useful Function 11.1 Useful Function Function Setting 11.1 Useful Function Function Function Version of QD75 Appendix 1 Appendix 2 Restrictions Depending on Function Version of QD75 Appendix 2 Appen	10.3.2 Sampling buffer monitor	10-27
10.4.2 Present value change test	10.4 Test	10-30
10.4.2 Present value change test	10.4.1 Positioning start test	10-32
10.4.3 Speed change test		
10.4.4 OPR test	_	
10.4.5 JOG/MPG operation test. 10.40 10.5 Servo On/Off 10.40 11. USEFUL FUNCTIONS 11- 1 to 11-48 11.1 Useful Functions for Projects 11- 11.1.1 Verifying the project data 11- 11.1.2 Changing the model after data setting 11- 11.1.3 Intelligent function utility 11.1.4 Multi module batch write 11- 11.2 Edit Functions for Data Setting 11- 11.2.2 Jump 11- 11.2.3 Clearing the rows/columns 11-15 11.2.3 Clearing the rows/columns 11-15 11.2.4 Oppying the data 11-17 11.3 Copying the data 11-17 11.3 Copying the data 11-18 11.3 Copying the data on an axis basis (Axis copy) 11-18 11.3.1 Copying the data on an axis basis (Axis copy) 11-18 11.3.2 Block start copy 11-18 11.3.4 Porping the Project Data 11-19 11.4 Navigation Function 11-20 11.5 Option Setting 11-22 11.6 Printing the Project Data 11-22 11.6 Printing the Project Data 11-22 11.7 Positioning Data Setting in Test Mode 11-21 11.7 Positioning Data Setting in Test Mode 11-30 11.7.1 Teaching 11-30 11.7.2 Positioning data test edit 11-30 11.8 Wave Trace 11-30 11.8 Wave trace execution 11-30 11.9 Location Trace 11-30 11.9 Location Trace 11-30 11.9 Location Trace condition setting 11-31 11.9 Location Trace condition setting 11-34 Appendix 1 Read from Module/Write to Module Reference Processing Times Appendix Appendix 1 Rependix 2 Respirations Added to/Changed from the Previous Versions Appendix Appendix 4 Uninstalling the License Key FD Appendix 5 Parameter Names Shown in GX Configurator-QP Screens and Manuals Appendix 5 Parameter Names Shown in GX Configurator-QP Screens and Manuals Appendix 5 Parameter Names Shown in GX Configurator-QP Screens and Manuals Appendix 5 Parameter Names Shown in GX Configurator-QP Screens and Manuals Appendix 5 Parameter Names Shown in GX Configurator-QP Screens and Manuals Appendix 5 Parameter Names Shown in GX Configurator-QP Screens and Manuals Appendix 5 Parameter Names Shown in GX Configurator-QP Screens and Manuals Appendix 5 Parameter Names Shown in GX Configurator-QP Screens and Manuals Appendix 5 Parameter Names Shown in GX Configurato	·	
10.5 Servo On/Off		
11. USEFUL FUNCTIONS 11- 1 to 11-42 11.1 Useful Functions for Projects. 11- 1 to 11-42 11.1.1 Verifying the project data 11- 11- 11- 11- 11- 11- 11- 11- 11- 11-	·	
11.1 Useful Functions for Projects	_	
11.1.1 Verifying the project data 11-11.1.2 Changing the model after data setting 11-11.1.3 Intelligent function utility 11-12.1.3 Intelligent function utility 11-12.1.1.3 Intelligent function utility 11-12.1.1.3 Intelligent function utility 11-12.1.1.3 Intelligent function utility 11-13.1.3 Intelligent function utility 11-15.1.3.1.1.3.1.1.3.1.1.3.1.1.3.1.1.1.3.1.1.3.1.1.3.1.1.3.1.3.1.3.1.3.1.3.1.3.1.3.1.3.1.3.1.3.1.3.3.1.3		
11.1.2 Changing the model after data setting 11-3 11.1.3 Intelligent function utility 11-5 11.1.4 Multi module batch write 11-5 11.2 Edit Functions for Data Setting 11-1 11.2 Edit Functions for Data Setting 11-1 11.2.1 Cut/copy/paste 11-1 11.2.2 Jump 11-1 11.2.3 Clearing the rows/columns 11-1 11.2.4 Initializing the data 11-1 11.3. Copying the Data 11-1 11.3. Copying the data on an axis basis (Axis copy) 11-18 11.4. Navigation Function 11-16 11.4. Navigation Function 11-2 11.5. Option Setting 11-2 11.6. Printing the Project Data 11-2 11.7. Positioning Data Setting in Test Mode 11-3 11.7. Positioning Data Setting in Test Mode 11-3 11.7.1 Teaching 11-3 11.7.1 Teaching 11-3 11.8.1 Wave trace condition setting 11-3 11.8.2 Wave trace execution 11-3	11.1 Useful Functions for Projects	11- 1
11.1.3 Intelligent function utility 11-5 11.1.4 Multi module batch write 11-5 11.2 Edit Functions for Data Setting 11-1 11.2.1 Cut/copy/paste 11-1 11.2.2 Jump 11-1 11.2.3 Clearing the rows/columns 11-16 11.2.4 Initializing the data 11-16 11.3. Copying the Data 11-17 11.3. Copying the data on an axis basis (Axis copy) 11-18 11.4. Navigation Function 11-16 11.5. Option Setting 11-2 11.6. Printing the Project Data 11-2 11.6. Printing the Project Data 11-2 11.6. Printing the Project Data 11-2 11.6. Printing in Test Mode 11-3 11.7. Positioning Data Setting in Test Mode 11-3 11.7. Positioning data test edit 11-3 11.8. Wave Trace 11-3 11.8. Wave trace condition setting 11-3 11.9. Location Trace 11-3 11.9. Location trace execution 11-3	11.1.1 Verifying the project data	11- 1
11.1.4 Multi module batch write 11-5 11.2 Edit Functions for Data Setting 11-1* 11.2.1 Cut/copy/paste 11-1* 11.2.2 Jump 11-1* 11.2.3 Clearing the rows/columns 11-16 11.2.4 Initializing the data 11-16 11.2.5 Opying the Data 11-17 11.3.1 Copying the data on an axis basis (Axis copy) 11-18 11.3.2 Block start copy 11-18 11.4 Navigation Function 11-20 11.5 Option Setting 11-20 11.6 Printing the Project Data 11-20 11.6.1 Printer setting 11-20 11.6.2 Printing 11-20 11.7 Positioning Data Setting in Test Mode 11-30 11.7.1 Teaching 11-30 11.7.2 Positioning data test edit 11-30 11.8 Wave Trace 11-30 11.8.1 Wave trace execution 11-30 11.9.1 Location Trace 11-31 11.9.2 Location trace execution 11-30 11.9.1 Location trace condition setting 11-31 11.9.2 Location trace execution 11-30 11.9.2 Location trace execution 11-30 11.9.2 Location trace	11.1.2 Changing the model after data setting	11- 3
11.2 Edit Functions for Data Setting 11-1* 11.2.1 Cut/copy/paste 11-1* 11.2.2 Jump 11-1* 11.2.3 Clearing the rows/columns 11-1* 11.2.4 Initializing the data 11-1* 11.3 Copying the Data 11-1* 11.3.1 Copying the data on an axis basis (Axis copy) 11-1* 11.3.2 Block start copy 11-1* 11.4 Navigation Function 11-2* 11.5 Option Setting 11-2* 11.6 Printing the Project Data 11-2* 11.6.1 Printer setting 11-2* 11.7 Positioning Data Setting in Test Mode 11-2* 11.7 Positioning Data Setting in Test Mode 11-3* 11.7.1 Teaching 11-3* 11.7.2 Positioning data test edit 11-3* 11.8 Wave Trace 11-3* 11.8.1 Wave trace condition setting 11-3* 11.9 Location Trace 11-3* 11.9.1 Location trace execution 11-3* 11.9.2 Location trace condition setting 11-3* 11.9.2 Location trace execution 11-4* APPENDICES Appendix 1 to Appendix 2 Appendix 1 Read from Module/Write to Module Reference Processing Times	11.1.3 Intelligent function utility	11- 5
11.2.1 Cut/copy/paste 11-11 11.2.2 Jump 11-16 11.2.3 Clearing the rows/columns 11-16 11.2.4 Initializing the data 11-17 11.3 Copying the Data 11-18 11.3.1 Copying the data on an axis basis (Axis copy) 11-18 11.3.2 Block start copy 11-19 11.4 Navigation Function 11-20 11.5 Option Setting 11-20 11.6 Printing the Project Data 11-21 11.6.1 Printer setting 11-22 11.6.2 Printing 11-22 11.7 Positioning Data Setting in Test Mode 11-30 11.7.1 Teaching 11-30 11.7.2 Positioning data test edit 11-30 11.8 Wave Trace 11-33 11.8.1 Wave trace condition setting 11-33 11.9.1 Location Trace 11-33 11.9.2 Location trace condition setting 11-36 11.9.1 Location trace execution 11-34 11.9.2 Location trace execution 11-34 11.9.2 Location trace execution 11-34 11.9.2 Location trace execution 11-34 4PPENDICES Appendix 1 to Appendix 2 Appendix 2 Restricti	11.1.4 Multi module batch write	11- 9
11.2.2 Jump 11-15 11.2.3 Clearing the rows/columns 11-16 11.2.4 Initializing the data 11-17 11.3 Copying the Data 11-18 11.3.1 Copying the data on an axis basis (Axis copy) 11-18 11.3.2 Block start copy 11-19 11.4 Navigation Function 11-20 11.5 Option Setting 11-20 11.6 Printing the Project Data 11-20 11.6.2 Printing the Project Data 11-20 11.6.2 Printing setting 11-20 11.6.2 Printing 11-20 11.7 Positioning Data Setting in Test Mode 11-30 11.7.1 Teaching 11-30 11.8 Wave Trace 11-30 11.8.1 Wave trace condition setting 11-31 11.8.2 Wave trace execution 11-32 11.9 Location Trace 11-36 11.9.1 Location trace condition setting 11-36 11.9.2 Location trace execution 11-36 11.9.1 Read from Module/Write to Module Reference Processing Times Appendix - Appen	11.2 Edit Functions for Data Setting	11-11
11.2.3 Clearing the rows/columns 11-16 11.2.4 Initializing the data 11-17 11.3 Copying the Data 11-18 11.3.1 Copying the data on an axis basis (Axis copy) 11-18 11.3.2 Block start copy 11-18 11.4 Navigation Function 11-20 11.5 Option Setting 11-20 11.6 Printing the Project Data 11-20 11.6.1 Printer setting 11-20 11.6.2 Printing 11-20 11.7 Positioning Data Setting in Test Mode 11-30 11.7.1 Teaching 11-30 11.7.2 Positioning data test edit 11-30 11.8 Wave Trace 11-30 11.8.1 Wave trace condition setting 11-31 11.9 Location Trace 11-32 11.9.1 Location trace condition setting 11-33 11.9.2 Location trace execution 11-34 11.9.2 Location trace execution 11-34 APPENDICES Appendix- 1 to Appendix- 2 Appendix 1 Read from Module/Write to Module Reference Processing Times Appendix- 2 Appendix 2 Restrictions Depending on Function Version of QD75 Appendix- 2 Appendix 2 Rependix 3 Functions Added to/Changed from the Previous Versions	11.2.1 Cut/copy/paste	11-11
11.2.4 Initializing the data 11-17 11.3 Copying the Data 11-18 11.3.1 Copying the data on an axis basis (Axis copy) 11-18 11.3.2 Block start copy 11-18 11.4 Navigation Function 11-20 11.5 Option Setting 11-20 11.6 Printing the Project Data 11-20 11.6.1 Printer setting 11-20 11.6.2 Printing 11-20 11.7 Positioning Data Setting in Test Mode 11-30 11.7.1 Teaching 11-30 11.7.2 Positioning data test edit 11-30 11.8 Wave Trace 11-30 11.8.1 Wave trace execution 11-30 11.9.2 Location Trace 11-30 11.9.1 Location trace condition setting 11-30 11.9.2 Location trace execution 11-30 11.9.2 Location trace execution 11-30 11.9.2 Location trace execution 11-30 11.9.2 Location trace perform Module/Write to Module Reference Processing Times Appendix - Appendi	11.2.2 Jump	11-15
11.2.4 Initializing the data 11-17 11.3 Copying the Data 11-18 11.3.1 Copying the data on an axis basis (Axis copy) 11-18 11.3.2 Block start copy 11-18 11.4 Navigation Function 11-20 11.5 Option Setting 11-20 11.6 Printing the Project Data 11-20 11.6.1 Printer setting 11-20 11.6.2 Printing 11-20 11.7 Positioning Data Setting in Test Mode 11-30 11.7.1 Teaching 11-30 11.7.2 Positioning data test edit 11-30 11.8 Wave Trace 11-30 11.8.1 Wave trace execution 11-30 11.9.2 Location Trace 11-30 11.9.1 Location trace condition setting 11-30 11.9.2 Location trace execution 11-30 11.9.2 Location trace execution 11-30 11.9.2 Location trace execution 11-30 11.9.2 Location trace perform Module/Write to Module Reference Processing Times Appendix - Appendi	11.2.3 Clearing the rows/columns	11-16
11.3 Copying the Data 11-18 11.3.1 Copying the data on an axis basis (Axis copy) 11-18 11.3.2 Block start copy 11-18 11.4 Navigation Function 11-20 11.5 Option Setting 11-22 11.6 Printing the Project Data 11-22 11.6.1 Printer setting 11-25 11.7 Positioning Data Setting in Test Mode 11-30 11.7.1 Teaching 11-30 11.7.2 Positioning data test edit 11-30 11.8.1 Wave trace 11-30 11.8.1 Wave trace execution 11-31 11.9.1 Location Trace 11-32 11.9.1 Location trace condition setting 11-36 11.9.2 Location trace execution 11-36 11.9.2 Location trace execution 11-36 11.9.3 Location trace execution 11-36 11.9.4 Location trace execution 11-36 11.9.2 Location trace execution 11-36 11.9.3 Location trace execution 11-36 11.9.4 Location trace execution 11-36 11.9.2 Location trace execution 11-36 11.9.3 Location trace execution 11-36 11.9 Location trace execution 11-36 <td>•</td> <td></td>	•	
11.3.1 Copying the data on an axis basis (Axis copy) 11-18 11.3.2 Block start copy 11-19 11.4 Navigation Function 11-20 11.5 Option Setting 11-21 11.6 Printing the Project Data 11-22 11.6.1 Printer setting 11-22 11.6.2 Printing 11-26 11.7 Positioning Data Setting in Test Mode 11-30 11.7.1 Teaching 11-30 11.7.2 Positioning data test edit 11-31 11.8 Wave Trace 11-33 11.8.1 Wave trace condition setting 11-33 11.9.2 Location Trace 11-33 11.9.1 Location trace condition setting 11-36 11.9.2 Location trace execution 11-36 11.9.1 Location trace execution 11-36 11.9.2 Location trace execution 11-36 11.9.1 Location trace execution 11-36 11.9.2 Location trace execution 11-36 11.9.3 Location trace execution 11-36 11.9.4 Location trace execution 11-36 11.9.2 Location trace execution 11-36 11.9.2 Location trace execution 11-36 11.9 Location trace execution 11-36 <td><u> </u></td> <td></td>	<u> </u>	
11.3.2 Block start copy 11-19 11.4 Navigation Function 11-20 11.5 Option Setting 11-20 11.6 Printing the Project Data 11-20 11.6.1 Printer setting 11-20 11.6.2 Printing 11-20 11.7 Positioning Data Setting in Test Mode 11-30 11.7.1 Teaching 11-30 11.7.2 Positioning data test edit 11-30 11.8 Wave Trace 11-30 11.8.1 Wave trace condition setting 11-30 11.9 Location Trace 11-30 11.9.1 Location trace condition setting 11-30 11.9.2 Location trace execution 11-30 11.9.1 Location trace execution 11-30 11.9.2 Location trace execution 11-30 11.9.2 Location trace execution 11-30 11.9.3 Location trace execution 11-30 11.9.4 Location trace execution 11-30 11.9.2 Location trace execution 11-30 <td< td=""><td></td><td></td></td<>		
11.4 Navigation Function 11-20 11.5 Option Setting 11-23 11.6 Printing the Project Data 11-25 11.6.1 Printer setting 11-25 11.6.2 Printing 11-26 11.7 Positioning Data Setting in Test Mode 11-30 11.7.1 Teaching 11-31 11.7.2 Positioning data test edit 11-33 11.8 Wave Trace 11-33 11.8.1 Wave trace condition setting 11-33 11.9 Location Trace 11-36 11.9.1 Location trace condition setting 11-36 11.9.2 Location trace execution 11-36 11.9.2 Location trace execution 11-40 4PPENDICES Appendix- 1 to Appendix- 1 Appendix 2 Restrictions Depending on Function Version of QD75 Appendix- 2 Appendix 2 Restrictions Depending on Function Version of QD75 Appendix- 3 Appendix 2 Rependix 3 Functions Added to/Changed from the Previous Versions Appendix- 4 Appendix 4 Uninstalling the License Key FD Appendix- 4 Appendix 5 Parameter Names Shown in GX Configurator-QP Screens and Manuals Appendix- 4 Index- 1 to Index- 5		
11.5 Option Setting	··	
11.6 Printing the Project Data 11-25 11.6.1 Printer setting 11-25 11.6.2 Printing 11-26 11.7 Positioning Data Setting in Test Mode 11-30 11.7.1 Teaching 11-30 11.7.2 Positioning data test edit 11-31 11.8 Wave Trace 11-32 11.8.1 Wave trace condition setting 11-33 11.8.2 Wave trace execution 11-35 11.9 Location Trace 11-36 11.9.1 Location trace condition setting 11-36 11.9.2 Location trace execution 11-36 11.9.4 Location trace execution 11-36 11.9.2 Location trace execution 11-36 11.9.1 Location trace execution 11-36 11.9.2 Location trace execution 11-36 11.9.3 Location trace execution 11-36 11.9.4 Location trace execution 11-36 11.9.2 Location trace execution 11-36 <	· · · · · · · · · · · · · · · · · · ·	
11.6.1 Printer setting		
11.6.2 Printing	•	
11.7 Positioning Data Setting in Test Mode		
11.7.1 Teaching	<u> </u>	
11.7.2 Positioning data test edit		
11.8 Wave Trace		
11.8.1 Wave trace condition setting	-	
11.8.2 Wave trace execution		
11.9 Location Trace	_	
11.9.1 Location trace condition setting		
11.9.2 Location trace execution		
APPENDICES Appendix- 1 to Appendix- 7 Appendix 1 Read from Module/Write to Module Reference Processing Times	~	
Appendix 1 Read from Module/Write to Module Reference Processing Times		
Appendix 1 Read from Module/Write to Module Reference Processing Times		
Appendix 2 Restrictions Depending on Function Version of QD75	APPENDICES	Appendix- 1 to Appendix- 7
Appendix 2 Restrictions Depending on Function Version of QD75	Appendix 1 Read from Module/Write to Module Reference Processina Times	Appendix- 1
Appendix 3 Functions Added to/Changed from the Previous Versions	,,	
Appendix 4 Uninstalling the License Key FD	· · ·	
Appendix 5 Parameter Names Shown in GX Configurator-QP Screens and ManualsAppendix- 5 INDEX Index- 1 to Index- 5		
	,,	
	INDEX	Index- 1 to Index- 5
	A - 7	A - 7

ABOUT MANUALS

The following manuals are related to this product.


Refer to the following table and request the required ones.

Related Manuals

Manual Name	Manual Number (Model Code)
Type QD75P/QD75D Positioning Module User's Manual Describes the system configuration, performance specifications, functions, handling, pre-operation procedures and troubleshooting of the QD75P1/QD75P2/QD75P4 and QD75D1/QD75D2/QD75D4. (Sold separately)	SH-080058 (13JR09)
Type QD75M Positioning Module User's Manual (Details) Describes the system configuration, performance specifications, functions, handling, pre-operation procedures and troubleshooting of the QD75M1/QD75M2/QD75M4. (Sold separately)	IB-0300062 (1XB752)
Type QD75MH Positioning Module User's Manual (Details) Describes the system configuration, performance specifications, functions, handling, pre-operation procedures and troubleshooting of the QD75MH1/QD75MH2/QD75MH4. (Sold separately)	IB-0300117 (1XB917)
MELSEC-L LD75P/LD75D Positioning Module User's Manual Describes the system configuration, performance specifications, functions, handling, pre-operation procedures and troubleshooting of the LD75P4/LD75D4. (Sold separately)	SH-080911ENG (13JZ46)
MELSEC-L LD77MH Simple Motion Module User's Manual (Positioning Control) Describes the system configuration, performance specifications, functions, handling, pre-operation procedures and troubleshooting of the LD77MH4. (Sold separately)	IB-0300172 (1XB942)
Q Corresponding MELSECNET/H Network System Reference Manual (Remote I/O network) This manual describes the system configuration of MELSECNET/H network system (Remote I/O network), performance, specifications and programming. (Sold separately)	SH-080124 (13JF96)
GOT1000 Series Connection Manual (Mitsubishi Products) Describes the system configuration for connection type and cable wiring applicable to GOT1000 series. (Sold separately)	SH-080868ENG (1D7MC2)

A - 8

HOW TO USE THIS MANUAL



A - 9

In addition, there are also the following explanations.



HELPFUL OPERATION

Describes application operation if there are multiple purposes and the basic operation and display/setting data do not provide enough information.



HELPFUL CORRECTIVE ACTIONS

Explains corrective actions if monitored data is abnormal or a test cannot be made.



Provides information relevant to that page, e.g. the items you should be careful of and the functions you should know.

The following table lists the symbols used in this manual and their definitions.

Symbol	Description
	Represents the menu name of the menu bar.
	If the menu name differs among Axes #1 to #4, they are indicated #1 to #4.
[]	[] $ ightarrow$ [] indicates a drop-down menu.
	Example: [Project] → [New Project] menu
	[Online] $ ightarrow$ [Test] $ ightarrow$ [Operation test #1 to #4] menu
	Represents the tool button on the toolbar corresponding to the drop-down menu.
	If the button differs among Axes #1 to #4, the buttons of #1 to #4 are indicated.
	Example: [Project] \rightarrow [Save Project] menu (\blacksquare)
	$[Online] \to [Test] \to [M \; code \; off] \to [M \; code \; \#1 \; to \; \#4 \; off] \; menu \; (\; $
" "	Represents the item name or command button in the dialog box.
	Example: "OK" button
	Represents the tab in the dialog box.
<< >>	Example: < <basic 1="" parameter="">> tab</basic>

A - 10 A - 10

ABOUT THE GENERIC TERMS AND ABBREVIATIONS

The following generic terms and abbreviations for the software for positioning module, positioning modules, etc. are used in this manual.

etc. are used in this	manuai.
Generic Term/Abbreviation	Description
GX Configurator-QP	Generic product name for type SW2D5C-QD75P-E, SW2D5C-QD75P-EA and SW2D5C-QD75P-EV -EA means a multiple license product and -EV an update-only product.
GX Configurator-AP	Generic product name for type SW0D5C-AD75P-E and SW0D5C-AD75P-EA -EA means a multiple license product.
GX Developer	Abbreviation for GX Developer (SW4D5C-GPPW-E or later)
SW1AD75P	Generic term for SW1RX-AD75P, SW1NX-AD75P, SW1IVD-AD75P(-E) positioning module software packages for MELSEC-A series
Peripheral device	Generic term for personal computers and personal computer CPU modules on which GX Configurator-QP may be used
QD75P	Generic term for type QD75P1, QD75P2 and QD75P4 positioning modules
QD75D	Generic term for type QD75D1, QD75D2 and QD75D4 positioning modules
QD75M	Generic term for type QD75M1, QD75M2 and QD75M4 positioning modules
QD75MH	Generic term for type QD75MH1, QD75MH2 and QD75MH4 positioning modules
QD75	Generic term for type QD75P, QD75D, QD75M and QD75MH positioning modules
LD75	Generic term for type QD75F, QD75B, QD75W and QD75WH positioning modules
LD77	Another term for type LD77MH4 simple motion module
Positioning module	Generic term for type QD75 and LD75 positioning modules and type LD77 simple motion modules
AD75P	Generic term for type AD75P1, AD75P2 and AD75P3, A1SD75P1, A1SD75P2, A1SD75P3, AD75P1-S3, AD75P2-S3, AD75P3-S3, A1SD75P1-S3, A1SD75P2-S3, A1SD75P3-S3 and AJ65BT-D75P2-S3 positioning modules
AD75M	Generic term for type AD75M1, AD75M2, AD75M3, A1SD75M1, A1SD75M2 and A1SD75M3 positioning modules
AD75	Generic term for MELSEC-A series positioning modules that may be used with GX Configurator-AP
QCPU	Generic term for Q00JCPU, Q00UJCPU, Q00CPU, Q00UCPU, Q01CPU, Q01UCPU, Q02CPU, Q02HCPU, Q02PHCPU, Q02UCPU, Q03UDECPU, Q04UDHCPU, Q04UDEHCPU, Q06HCPU, Q06PHCPU, Q06UDHCPU, Q06UDEHCPU, Q10UDHCPU, Q10UDEHCPU, Q12HCPU, Q13UDHCPU, Q13UDEHCPU, Q20UDHCPU, Q20UDEHCPU, Q25HCPU, Q25PHCPU, Q26UDHCPU, and Q26UDEHCPU
LCPU	Generic term for L02CPU and L26CPU-BT
Universal model QCPU	Generic term for Q00UJCPU, Q00UCPU, Q01UCPU, Q02UCPU, Q03UDCPU, Q04UDHCPU, Q06UDHCPU, Q10UDHCPU, Q13UDHCPU, Q20UDHCPU, Q26UDHCPU, Q03UDECPU, Q04UDEHCPU, Q06UDEHCPU, Q10UDEHCPU, Q13UDEHCPU, Q20UDEHCPU, and Q26UDEHCPU
Built-in Ethernet port QCPU	Generic term for Q03UDECPU, Q04UDEHCPU, Q06UDEHCPU, Q10UDEHCPU, Q13UDEHCPU, Q20UDEHCPU, and Q26UDEHCPU
Programmable controller CPU	Generic term for programmable controller CPU on which a positioning module can be mounted
Serial communication module	Generic term for Q corresponding serial communication module and L corresponding serial communication module
PC CPU module	Abbreviation for MELSEC-Q series compatible PC CPU module (CONTEC CO., LTD. make)
Servo amplifier	Generic term for drive units connected to the positioning module
Servo motor	Generic term for motors connected to the drive units (servo amplifiers)
Positioning control	Generic term for equipment sets which exercise positioning control, including the positioning
system	modules, servo amplifiers, servo motors and external switches
1-license product	Abbreviation for 1-license product of GX Configurator-QP
corice product	r to retail to 1 moon to product or on configuration wi

(To the next page)

A - 11 A - 11

Generic Term/Abbreviation	Description
Multiple-license product	Abbreviation for multiple-license product of GX Configurator-QP
Update-only product	Abbreviation for update-only product of GX Configurator-QP
Windows® 7	Generic term for the following: Microsoft® Windows® 7 Starter Operating System, Microsoft® Windows® 7 Home Premium Operating System, Microsoft® Windows® 7 Professional Operating System, Microsoft® Windows® 7 Ultimate Operating System, Microsoft® Windows® 7 Enterprise Operating System Note that the 32-bit version is designated as "32-bit Windows® 7", and the 64-bit version is designated as "64-bit Windows® 7".
Windows Vista®	Generic term for the following: Microsoft® Windows Vista® Home Basic Operating System, Microsoft® Windows Vista® Home Premium Operating System, Microsoft® Windows Vista® Business Operating System, Microsoft® Windows Vista® Ultimate Operating System, Microsoft® Windows Vista® Enterprise Operating System
Windows® XP	Generic term for the following: Microsoft® Windows® XP Professional Operating System, Microsoft® Windows® XP Home Edition Operating System

PACKING LIST

This product consists of the following.

Туре	Product Name		Quantity
	GX Configurator-QP Version 2 (1-license product)	(CD-ROM)	1
SW2D5C-QD75P-E	End-user software license agreement		1
3002D3C-QD73F-E	Software registration notice		1
	License agreement		1
	GX Configurator-QP Version 2 (multiple-license product)	(CD-ROM)	1
SW2D5C-QD75P-EA	End-user software license agreement		1
SVVZD3C-QD731 -LA	Software registration notice		1
	License agreement		n*
	GX Configurator-QP Version 2 (update-only product)	(CD-ROM)	1
SW2D5C-QD75P-EV	End-user software license agreement		1
	Software registration notice		1
	License agreement		1

st : Cards of the same quantity as the number of licenses are packed with the product.

A - 12

1

1. OVERVIEW

This manual describes the functions and operating procedures of GX Configurator-QP. GX Configurator-QP is a software package that performs various functions such as data settings, monitoring, and tests for the MELSEC-Q/L series positioning modules.

GX Configurator-QP offers the following functions.

- · Setting of positioning data and parameters
- Simulation using positioning data
- Read/write of data from/to positioning module
- Monitoring of positioning control status
- · Test operation of positioning control
- Auto refresh setting between QCPU or LCPU devices and positioning module buffer memory

GX Configurator-QP can be used with any of the following positioning modules.

Desitioning module type	Model		
Positioning module type	MELSEC-Q series	MELSEC-L series	
Open collector output type	QD75P1, QD75P2, QD75P4	LD75P4	
Differential driver output type	QD75D1, QD75D2, QD75D4	LD75D4	
SSCNET connection type	QD75M1, QD75M2, QD75M4	-	
SSCNETIII connection type	QD75MH1, QD75MH2, QD75MH4	LD77MH4	

GX Configurator-QP can access the QD75 via any of the following modules.

Module type	Model
QCPU	Q00JCPU, Q00UJCPU, Q00CPU, Q00UCPU, Q01CPU, Q01UCPU, Q02CPU, Q02HCPU, Q02PHCPU, Q02UCPU, Q03UDECPU, Q04UDHCPU, Q04UDEHCPU, Q06HCPU, Q06PHCPU, Q06UDHCPU, Q06UDEHCPU, Q10UDHCPU, Q12HCPU, Q12PHCPU, Q13UDHCPU, Q13UDHCPU, Q20UDHCPU, Q25PHCPU, Q26UDHCPU, and Q26UDEHCPU
Q corresponding serial communication module	QJ71C24(N), QJ71C24(N)-R2
Q corresponding MELSECNET/H network remote I/O module *	QJ72LP25-25, QJ72BR15, QJ72LP25G, QJ72LP25GE
C Controller module	Q12DCCPU-V

^{* :} Only when connecting to the remote I/O module directly.

1

GX Configurator-QP can access the LD75/LD77 via any of the following modules.

Module type	Model	
LCPU	L02CPU, L26CPU-BT	
L corresponding serial	L 174C24 L 174C24 D2	
communication module	LJ71C24, LJ71C24-R2	



GX Configurator-QP can simultaneously edit positioning module projects of MELSEC-Q series and MELSEC-L series.


Also, online operation in each project is available by specifying a connection target for each project.

1. OVERVIEW ______ MELSOFT

1.1 Features

(1) Concurrent editing of multiple projects


Capable of opening multiple projects simultaneously, this software allows you to easily edit the positioning data and block start data to be utilized by copying and pasting.



(2) Efficient debugging of multi-modules

Because the QD75/LD75/LD77 to be connected to is set per project, batch write to or monitoring of multi-modules can be performed.

When using multiple QD75/LD75/LD77s, you can reduce the software start waiting time and physical work time, increasing debugging efficiency.




(3) Simplified program by auto refresh setting

Auto refresh setting is made to automatically read the following values stored in QD75/LD75/LD77 buffer memory to the QCPU/LCPU devices.


- Feed present value
- · Machine feed value
- Feed speed
- Error No.
- · Warning No.
- · Enable M code

Auto refresh setting reduces the number of FROM instructions used to read the buffer memory storage values, facilitating creation and debugging of programs.



(4) Ease of operation with navigation function (only for QD75P/QD75D) GX Configurator-QP has a navigation function which can perform operations from data setting, write to the QD75P/QD75D, monitoring, test to data storage in a sequential order.


As basic settings and debugging can be performed in orderly sequence, you can understand operations necessary for this software and positioning control.




(5) Setting of optimum positioning data without complicated calculation

Positioning data can be set by sub arc setting and automatic axis speed setting. Sub arc setting generates from the specified two linear interpolation control data the circular interpolation control data in which the angle between two linear paths is converted into a circular arc (curve) path.

Sub axis speed setting calculates the axis speed (command speed) from the operation time, travel, acceleration/deceleration time and motor specifications.






These functions allow the optimum positioning data to be set without complicated calculation and advance measurement.

(6) Ease of transition from AD75 (only for QD75)

You can read and use the data created on A series SW1—AD75P and GX Configurator-AP.


Valuable data is not wasted and can be utilized for QD75.



(7) Versatility by compatibility with RS-232 and USB

If the personal computer does not have a free serial port, connection can be made from the USB connector.


Especially for a notebook computer having a few serial ports, there are no restrictions due to shortage of ports.



1. OVERVIEW MELSOFT

(8) Compatible with multiple CPU system (only for QD75)

On GX Configurator-QP, setting the control CPU type and PLC No. of the QD75 to communicate with in Connection Setup (refer to Section 7.1) allows communication to be made with any QD75.



(Example)

Connection Setup for communication with the QD75 under control of PLC No. 1 PLC type: Type of PLC No. 1, Multiple PLC specification: PLC No. 1

*: For details, refer to "QCPU User's Manual (Multiple CPU system)".



- Communication with the QD75 cannot be made if the control CPU type and PLC
 No. of the QD75 to communicate with are not set correctly in Connection Setup.
- If correct settings have been made in Connection Setup, any of PLC No. 1 to No. 4 may be specified as the connection target of the connection cable.

1.2 Manual Makeup

This manual is made up of 11 chapters and appendices.

This manual assumes that GX Configurator-QP is used to perform steps from positioning control system checking to operation in the following procedure.

<Sequence of steps taken by the user up to positioning control system operation>

Step 1: Install and wire the positioning control system.	Refer To
• Install and wire the programmable controller (such as the QCPU/LCPU, QD75/LD75/LD77, I/O	User's manual for
modules and intelligent function modules), servo amplifiers, motors, external switches and other	the positioning
external devices.	module used



Step 2: Check the GX Configurator-QP functions and learn the basic operations.	Refer To
Check the system with which GX Configurator-QP can be used.	Chapter 2
Check the functions that can be performed by GX Configurator-QP.	Chapter 3
Install GX Configurator-QP in the peripheral device and start the program. Chapter	
• Learn the GX Configurator-QP screen makeup and basic operations. Chap	



Step 3: Start operation of GX Configurator-QP.	Refer To
Create a project which will be the object of operation for GX Configurator-QP.	Chapter 6



Step 4: Check the connection and initial operation of the positioning control system.	Refer To
• Specify the QD75/LD75/LD77 to be accessed, ports where cables will be connected, and others.	
Check the QD75/LD75/LD77 types and I/O addresses of the stations connected.	
Check connection according to the signal states from the external devices.	Chapter 7
Check the alarms and warnings of the positioning module.	
Check that the servo motors are run by JOG operation.	



(To the next page)

(From the preceding page)



Step 5: Set and write data to the positioning module.	Refer To
 Set the parameters appropriate for the positioning control system and control. Set the servo parameters appropriate for the specifications of the servo amplifiers and motors used. (Only QD75M, QD75MH, and LD77) Set the positioning data and M code comments. Check the positioning data on the simulation screen. Make the corresponding setting if block start data and/or condition data is required. Make error check to check the parameters, servo parameters, positioning data and block start data settings. 	Chapter 8
Write, read or verity the set data on the project.	Chapter 9



Step 6: Perform test operation and check and adjust the settings.	Refer To
Make online error check to recheck the settings of the parameters, servo parameters, positioning	
data and block start data written to the QD75/LD75/LD77.	
Check positioning control and test on the monitor screen.	Chapter 10
Set the positioning data and block start data, and perform test operation.	
Make present value change test, speed change test, OPR test, JOG operation test and MPG	
operation test to check the parameters, addresses, axis speeds, etc.	




Step 7: Positioning control system operation	Refer To
	User's manual for
Operate the positioning control system with the programmable controller CF	PU program. the positioning
	module used

2. SYSTEM CONFIGURATION


2.1 System Configuration


(1) Overall configuration of this system (MELSEC-Q series)(a) Via QCPU, Q corresponding serial communication module, and C Controller module (Q12DCCPU-V)



^{* :} When the PC CPU module is used as a peripheral device, the connection cable is not needed since it is loaded to the base unit module directly. For details of the PC CPU module, refer to Manual for PC CPU module.

(b) Connecting to Q corresponding MELSECNET/H network remote I/O module directly






*1: For cables for connection of a peripheral device to the programmable controller via GOT by the GOT transparent mode, refer to the GOT1000 Series Connection Manual (Mitsubishi Products).

^{*2:} The GOT transparent mode does not support Q corresponding MELSECNET/H Network remote I/O modules and C Controller module (Q12DCCPU-V).

(2) Overall configuration of this system (MELSEC-L series) (a) Via LCPU, L corresponding serial communication module



(b) Via GOT by the GOT transparent mode GX Configurator-QP (CD-ROM) Peripheral device Printer RS-232 cable* (user prepared) RS-232 cable* (user prepared) RS-232 cable* (user prepared)

LD75D4/ LD75P4/ LD77MH4 L corresponding

communication module END cover

serial

*: For cables for connection of a peripheral device to the programmable controller via GOT by the GOT transparent mode, refer to the GOT1000 Series Connection Manual (Mitsubishi Products).

CPU module

RS-232 adaptor

(optional))

Power supply module



- Do not connect a peripheral device to the serial communication module by multidrop link.
- When the GOT transparent mode is activated, Ethernet connection cannot be made between GOT and a peripheral device and between GOT and the programmable controller.

(3) About the connection cables

(a) Connection to QCPU or Q corresponding MELSECNET/H network remote I/O module by QC30R2 (made by Mitsubishi Electric)

When the baudrate is set to 115.2/57.6kbps, communication cannot be made unless the peripheral device used is compatible with the communication speed of 115.2/57.6kbps.

If a communication error occurs, reduce the baudrate setting and restart communication.

(b) Connection to QCPU/LCPU or C Controller module (Q12DCCPU-V) by USB cable

 Usable when the USB driver has been installed with any of the following operating systems used.

Microsoft® Windows® 98 Operating System

Microsoft® Windows® Millennium Edition Operating System

Microsoft® Windows® 2000 Professional Operating System

Microsoft® Windows® XP Professional Operating System

Microsoft® Windows® XP Home Edition Operating System

Microsoft® Windows Vista® Home Basic Operating System

Microsoft® Windows Vista® Home Premium Operating System

Microsoft® Windows Vista® Business Operating System

Microsoft® Windows Vista® Ultimate Operating System

Microsoft® Windows Vista® Enterprise Operating System

Microsoft® Windows® 7 Starter Operating System

Microsoft® Windows® 7 Home Premium Operating System

Microsoft® Windows® 7 Professional Operating System

Microsoft® Windows® 7 Ultimate Operating System

Microsoft® Windows® 7 Enterprise Operating System

 Use of the USB cable allows only programmable controller CPU to be connected.

(c) Connection to QCPU/LCPU by Ethernet cable

 Connect the personal computer with the Built-in Ethernet port QCPU or LCPU directly by using the Ethernet cable.

The GX Configurator-QP does not support the online connection between the personal computer and the Built-in Ethernet port QCPU or LCPU.


Use the following Ethernet cables.

Connection mode	Specifications	
10BASE-T connection	Cables compliant with Ethernet standards, category 3 or higher (STP/UTP cables)	
100BASE-TX connection	Cables compliant with Ethernet standards, category 5 or higher (STP/UTP cables)	

In an environment subject to electric noise, use shielded twisted-pair (STP) cables.


(d) Connection to serial communication module

The specifications of the RS-232 cable connector are indicated below.




Pin Number	Signal Code	Signal Name	Signal Direction Serial communication module External device
1	CD(DCD)	Data carrier detect	←
2	RD(RXD)	Received data	←——
3	SD(TXD)	Transmitted data	
4	ER(DTR)	Data terminal ready	
5	SG	Signal ground	←
6	DR(DSR)	Data set ready	—
7	RS(RTS)	Request to send	—
8	CS(CTS)	Clear to send	←
9	CI(RI)	Ring indicator	—

• Connection example which can turn ON/OFF CD signal (No. 1 pin)



Connection example which cannot turn ON/OFF CD signal (No. 1 pin)
 Connection example for exercising DC code control or DTR/DSR control



(e) Connection via GOT

For cables for connection of a peripheral device to the programmable controller via GOT by the GOT transparent mode, refer to the GOT1000 Series Connection Manual (Mitsubishi Products).

2.2 Operating Environment

The operating environment of GX Configurator-QP is indicated below.

	Item	Description	
Peripheral	Personal computer	Personal computer on which Windows® operates.	
device	PC CPU module	MELSEC-Q series compatible PC CPU module (CONTEC CO., LTD. make)	
Computer r	nain unit		
	CPU	Refer to the following table "Used operating system and performance required for	
Required personal computer".		personal computer".	
Hard disk fr	ee space	200MB or more	
Disk drive		CD-ROM disk drive	
Display		800 × 600 dot or more resolution *1	
Display Operating system *2		Microsoft® Windows® 95 Operating System SP 1 or later Microsoft® Windows® 98 Operating System Microsoft® Windows® Millennium Edition Operating System Microsoft® Windows NT® Workstation Operating System Version 4.0 SP 3 or later Microsoft® Windows® 2000 Professional Operating System Microsoft® Windows® XP Professional Operating System Microsoft® Windows® XP Home Edition Operating System Microsoft® Windows Vista® Home Basic Operating System Microsoft® Windows Vista® Home Premium Operating System Microsoft® Windows Vista® Business Operating System Microsoft® Windows Vista® Ultimate Operating System Microsoft® Windows Vista® Enterprise Operating System Microsoft® Windows® 7 Starter Operating System Microsoft® Windows® 7 Home Premium Operating System Microsoft® Windows® 7 Professional Operating System Microsoft® Windows® 7 Professional Operating System Microsoft® Windows® 7 Enterprise Operating System	

^{*}1: For Windows Vista $^{\text{®}}$ and Windows $^{\text{®}}$ 7, resolution of 1024 \times 768 pixels or more is recommended.

^{*2}: 64-bit Windows $^{\otimes}~$ XP and 64-bit Windows Vista $^{\otimes}~$ are not supported.

Used operating system and performance required for personal computer

Operating system	Performance Required for Personal Computer			
Operating system	CPU	Required memory		
Windows® 95	Pentium® 133MHz or more	64MB or more		
Windows® 98	Pentium® 133MHz or more	64MB or more		
Windows® Me	Pentium® 150MHz or more	64MB or more		
Windows NT® Workstation 4.0	Pentium® 133MHz or more	64MB or more		
Windows® 2000 Professional	Pentium® 133MHz or more	64MB or more		
Windows® XP	Pentium® 300MHz or more	128MB or more		
Windows Vista®	Pentium® 1GHz or more	1GB or more		
Windows® 7	Pentium® 1GHz or more	1GB or more (32-bit Windows® 7) 2GB or more (64-bit Windows® 7)		



 Windows® XP, Windows Vista®, and Windows® 7 do not support the following functions.

If any of the following functions is attempted, this product may not operate normally.

Start of application in Windows® compatible mode

Fast user switching

Remote desktop

Large fonts (Details setting of Display properties)

DPI setting other than 100%

• Windows® 7 does not support the following functions.

Windows XP Mode

Windows Touch

• Operate Windows Vista® and Windows® 7 with user privileges or higher.

2 - 10 2 - 10

2.3 Instructions for use of older version of GX Configurator-QP

If using an older version of GX Configurator-QP, pay attention to the following.

(1) For using QD75M

- When GX Configurator-QP Version 2.13P or later is used, setting items and setting values for the QD75M parameters have been added.
- If a QD75M project created with GX Configurator-QP Version 2.13P or later is opened on GX Configurator-QP Version 2.12N or earlier, some data will not be processed properly.
- For details, refer to "Section 8.2 Servo Parameter Setting".

(2) For using QD75MH

- Use GX Configurator-QP Version 2.20W or later.
- QD75MH projects cannot be opened on GX Configurator-QP Version 2.19V or earlier.

(3) For using LD75/LD77

- Use GX Configurator-QP Version 2.33K or later.
- LD75/LD77 projects cannot be opened on GX Configurator-QP Version 2.32J or earlier.

(4) When opening a project with unsupported connection destination data

If the following dialog box appears after an existing project is opened, the used Configurator-QP does not support the settings of the connection destination.



Change the destination route.

2 - 11 2 - 11

3. FUNCTION LIST

3.1 Function List

(1) Function list

The main functions of GX Configurator-QP are listed.

Function		Description	QD75P/ QD75D	QD75M/ QD75MH	LD75	LD77
Edit	Parameter setting	Sets the basic parameters #1, basic parameters #2, extended parameters #1, extended parameters #2, OPR basic parameters and OPR extended parameters.	0	0	0	0
	Servo parameter setting	Sets the servo parameters. Sets servo basic parameters, servo regulation parameters and servo extended parameters for QD75M. Sets servo amplifier series, basic setting parameters, gain/filter parameters, extension setting parameters and I/O setting parameters, extended control parameters, special setting parameters for QD75MH/LD77.	×	0	×	0
	Positioning data setting	Sets the positioning data, such as pattern, control method, accel/decel time and address, on an axis basis.	0	0	0	0
	M code comment setting	Sets comments to the M codes assigned to the positioning data on an axis basis.	0	0	0	0
	Sub arc	Automatically generates positioning data to ensure smooth movement on the intersection of consecutive two-axis linear interpolations by circular interpolation.	0	0	0	0
	Automatic axis speed setting	Automatically calculates the axis speed in the constant-speed part by setting the time taken from a positioning start until the target position is reached.	0	×	0	×
	Block start data setting	Sets the starting mode, etc. of the positioning data specified for points on an axis basis.	0	0	0	0
	Condition data setting	Sets the data which is used as a special start condition in the block start data on an axis basis.	0	0	0	0
	Simulation	Simulates axis operation from the setting positioning data. Wave form data is displayed for single axis control. Locus data is displayed for two axis interpolation control.	0	0	0	0

3

Function		on	Description	QD75P/ QD75D	QD75M/ QD75MH	LD75	LD77
	Positioning monitor		Enters the monitor mode from the positioning data edit window and monitors the positioning data during operation.	0	0	0	0
	Block start monitor		Enters the monitor mode from the block start data edit window and monitors the block start data during operation.	0	0	0	0
	Operation monitor		Monitors the operating states, such as feed present values, axis feed speeds, axis statuses and executed positioning data numbers, of all axes.	0	0	0	0
	History monitor		Monitors the error, warning, start history of all axes.	0	0	0	0
Monitor	Signal monitor		Monitors the X/Y devices, external signals or status signals of all axes.	0	0	0	0
	Operation monitor		Monitors the control states, QD75/LD75/LD77 parameter settings or others of all axes.	0	0	0	0
	Servo m	onitor	Monitors the states of the servo amplifiers and servo motors on all axes.	×	0	×	0
	Sampling monitor	Signal	Monitors the specified signals while simultaneously sampling them.	0	0	0	0
		Buffer memory	Monitors the specified buffer memory data while simultaneously sampling them.	0	0	0	0
	System monitor		Shows the system configuration of the host and the I/O address and model (type) of the specified QD75.	0	0	×	×
	Cableless mode		Tests the QD75P/QD75D/LD75 alone without wiring between the servo amplifier and motor.	0	×	0	×
	Positioning data test edit		Writes the setting parameters, positioning data and block start data in the test mode.	0	0	0	0
Test	Operation test	Positioning start	Specifies the positioning data number and block start data point number and performs test operation.	0	0	0	0
		Present value change	Performs the change test of the feed present value.	0	0	0	0
		Speed change	Performs a speed change test on the axis on which a positioning start test is being done.	0	0	0	0
		OPR	Performs an original point return test.	0	0	0	0
		JOG operation	Performs a JOG operation test.	0	0	0	0
		Inching operation	Moves the axis over the specified distance per operation.	0	0	0	0
		MPG operation	Performs test operation using a manual pulse generator.	0	0	0	0

Function		Description	QD75P/ QD75D	QD75M/ QD75MH	LD75	LD77
Diagnosis	Checking connect	Displays signals from external devices. Also tests initial operation by JOG operation.	0	×	0	×
T	Wave trace	Traces the speed command for a given time and displays the waveform data relative to the time axis.	0	×	0	×
Trace	Location trace	Traces the position command or real value for a given time and displays the track data of the axes.	0	×	0	×
Extended	Auto refresh setting	Assigns the QD75/LD75/LD77 buffer memory and CPU module devices for auto refresh between QD75/LD75/LD77 and CPU module.	0	0	0	0
	Navigation	Performs operations from parameter and positioning data settings to simple test operation and set data storage in accordance with navigation.	0	×	×	×

3.2 Menu List

The menu bar drop-down menus are listed below.


Project O	ņline
New Project · · · · · · Section 6.1	Connection setup····· Section 7.1
Open Project · · · · · Section 6.2	Read from module Section 9.1
Close Project · · · · · Section 6.4	Write to module *** Section 9.1
Save Project Section 6.3	Writing of batch of multi module ***** Section 11.1.4
Save as Project Section 6.3	Verify module data · · · · Section 9.1
Delete Project · · · · Section 6.5	Error check module data Section 10.1
Verify Project Section 11.1.1	Servo amplifier data read · · · · · Section 10.1
Import file	OS information Section 7.3
File reading of SW1RX/IVD/NX-AD75P · · · · Section 6.6.1	Flash ROM request Section 9.3
File reading of SW0D5C-AD75P Section 6.6.1	Initialize module Section 9.4
File reading of CSV form positioning data * * * Section 6.6.2	Monitor
File reading of Trace data · · · · Section11.8.2,11.9.2	└ Monitor On/Off · · · · · Section 10.2,10.3
Export file	Test
File writing of CSV form positioning data · · · Section 6.7	Test On/Off · · · · · Section 10.4
File writing of Trace data · · · · · Section 11.8.2,11.9.2	Edit positioning data······ Section 11.7.2
Change module type · · · · · · · Section 11.1.2	Teaching · · · · · · · · · · Section 11.7.1
Print · · · · · Section 11.6.2	Cableless mode · · · · · · · Section 10.4
Printer setup Section 11.6.1	Operation test
-Latest file · · · · · Section 6.2	Operation test #1 · · · · · · · Section 10.4.1
Exit Section 4.4	Operation test #2 · · · · · · Section 10.4.1
	Operation test #3 · · · · · · · Section 10.4.1
Edit	Operation test #4 · · · · · · Section 10.4.1
- Cut Section 11.2.1	Error reset
Copy Section 11.2.1	Error reset #1 · · · · · Chapter 10
Paste · · · · · · Section 11.2.1	Error reset #2 · · · · · Chapter 10
Select all · · · · · · · Section 11.2.1	Error reset #4 · · · · · Chapter 10 Error reset #4 · · · · Chapter 10
- Jump · · · · · · Section 11.2.2	Error reset #4 · · · · · Chapter 10 M code off
Clear row Section 11.2.3	M code off #1 ······ Chapter 10
Clear column Section 11.2.3	M code off #2 · · · · · · · Chapter 10
Axis copy Section 11.3.1	M code off #3 ····· Chapter 10
Block start copy Section 11.3.2	M code off #4 · · · · · Chapter 10
M code comment Section 8.3.2 Condition data edit Section 8.5.2	All axis stop · · · · · Chapter 10
Condition data edit Section 8.5.2 Simulation Section 8.4	All axis Servo On/Off · · · · · · Section 10.5
Assistance arc · · · · Section 8.3.1	Tool····· Section 10.5
Speed of axis setting Section 8.3.1	#1 Servo Off command · · · · · Section 10.5
Speed of axis setting Section 6.5.1	#2 Servo Off command · · · · · Section 10.5
View	#3 Servo Off command · · · · · Section 10.5
Project tree view****** Section 5.2	L#4 Servo Off command · · · · · Section 10.5
Toolbar Section 5.2	Error check······Section 8.6
Test toolbar Section 5.2	Initializing data Section 3.4
Status bar Section 5.2	-Navigation · · · · · · · Section 11.4
Online toolbar Section 5.2	System monitor Section 7.2
Select block start data no Section 8.5.1	Intelligent function utility · · · · · · Section 11.1.3
CONSTRUCTION CHART GALLATIC	Option Section 11.5
W	indow
	Cascade · · · · · Section 5.7
	Tile vertically · · · · · Section 5.7
	-Arrange icons · · · · · Section 5.7
	All close Section 5.7
He	elp
	Error/Warning/List of Buffer memory · · · · · Section 11.10
	Key operations list Section 11.10
	About Section 11.10
	Connection to MELFANS web · · · · Section 11.10

4. INSTALLATION AND UNINSTALLATION

This chapter describes how to install and uninstall GX Configurator-QP.

4.1 Installation

4.1.1 Installation procedure





- *1: The target is either of the following versions of software.
 - Refer to "Section 11.10 Help" for the way to confirm the version.
 - SW0D5C-QD75P-E
- *2: This product can be installed if the license key FD is valid.(However, the license right decreases by 1.)
- *3: When performing uninstalling operation, refer to the operating manual of the installed product.

4.1.2 Installing GX Configurator-QP

The following explains how to install GX Configurator-QP.



- Before starting installation, close all other applications running on Windows® .
- Install GX Configurator-QP compatible with the operating system. For compatible GX Configurator-QP versions, refer to Appendix 3.
- The installer may not work normally because the update program of operating system or other companies' software such as Windows Update and Java update may start automatically. Please install the driver after changing the setting of the update program not to start automatically.
- When the following operating system is being used, please logon as a user with the attribute of Administrator.

Microsoft® Windows NT® Workstation Operating System Version 4.0

Microsoft® Windows® 2000 Professional Operating System

Microsoft® Windows® XP Professional Operating System

Microsoft® Windows® XP Home Edition Operating System

Microsoft® Windows Vista® Home Basic Operating System

Microsoft® Windows Vista® Home Premium Operating System

Microsoft® Windows Vista® Business Operating System

Microsoft® Windows Vista® Ultimate Operating System

Microsoft® Windows Vista® Enterprise Operating System


Microsoft® Windows® 7 Starter Operating System

Microsoft® Windows® 7 Home Premium Operating System

Microsoft® Windows® 7 Professional Operating System

Microsoft® Windows® 7 Ultimate Operating System

Microsoft® Windows® 7 Enterprise Operating System




↓
(To the next page)

- 1) After powering on the personal computer, start Windows® .
- 2) Start Windows® Explorer and click the drive where the disk is inserted. Double-click "Setup.exe".


To display Windows® Explorer, choose [Start] \rightarrow [Programs] \rightarrow [Windows Explorer].


 * : When user account control is enabled, the following dialog box appears.
 Click "Allow" or Yes button.

[Windows Vista®]



[Windows® 7]







3) If the message shown on the left appears, click the OK button, uninstall GX Configurator-QP, and then reinstall it.



4) If either of the left screens appears, perform operation in accordance with the instructions given in (a) in "(reference) When message appears at start of installation".

After the operation is over, restart installation operation.



Severe


If the left screen appears, perform operation in accordance with the instructions given in (b) in "(reference) When message appears at start of installation".

After the operation is over, restart installation operation.




5) The screen shown on the left appears. Make sure that all applications have been closed, and click the OK button.


If applications are running, close them all.



6) As the screen shown on the left appears, click the Next> button.



(To the next page)




7) Enter the name and company, and click the Next> button.



8) Check the registered name and company.

If they are correct, click the Yes button.


To change them, click the No button to return to the previous screen.



9) Enter the product ID and chick the Next> button. The product ID is given in the "License agreement" packed with the product.

Proceed to Step 11) to install the product newly. Proceed to Step 10) to update the product.


(To the next page)



10) When an update-only product is used for updating, the screen shown on the left appears. Enter the product ID of the old product and click the Next> button.

The product ID is given in the "Software Registration Card" or "License agreement" packed with the product.

The screen shown on the left does not appear when the product is installed anew.



11) Specify the installation destination folder.

After specifying the destination folder, click the Next> button.

It defaults to "C:\MELSEC\".

To change the destination folder, click the Browse button and specify a new drive and folder.

REMARK

If the following dialog box appears, click the OK button to end the installation.

Then, reinstall GX Configurator-QP compatible with the operating system.

For the versions of GX Configurator-QP compatible with each operating system, refer to Appendix 3.

(The following screen may appear behind another screen. Then, press the Alt + Tab keys to bring it to the front.)

(To the next page)




[Windows® XP]

The following screen may appear at installation.

Click Continue.

We checked operations in Windows® XP (Problems never occur after installation.) The following screen may appear behind another screen. Then, press the Alt + Tab keys to bring it to the front.



(To the next page)

[Windows Vista® and Windows® 7]

The following screen may appear at installation.

Click Install. (Although the displayed screen may differ for some operating systems, the operation is the same.)

The following screen may appear behind another screen. Then, press

the Alt + Tab keys to bring it to the front.






(To the next page)



12) When the screen on the left appears, installation is complete.

Click the OK button.


*: When the following screen appears, select "This program installed correctly".



Do not choose "Reinstall using recommended settings", because the installer installs an incorrect module.


If choose, reinstall GX Configurator-QP with following POINT on the next page.

13) If the message shown on the left appears, restart Windows $^{\tiny{\circledR}}$.



(Complete)

Installing GX Configurator-QP registers the icon as shown below.



REMARK

For Windows® XP, Windows Vista®, and Windows® 7, the icon is registered under [MELSOFT Application], displayed by selecting [All Programs] from the start menu.




Note the following when starting the installer from the hard disk on the personal computer.

If the "Program Compatibility Assistant" screen appears after the installation, choose "This program installed correctly".

If "Reinstall using recommended settings" is selected by mistake, 'Windows XP compatibility mode' is set automatically.

Disable the 'Windows XP compatibility mode' by following the procedure described below, and perform the reinstallation.

- 1. Right-click on the setup.exe icon of the installation target in the Windows explorer, and open the "setup Properties" screen.
- 2. Select the "Compatibility" tab and click the Show settings for all users button.
- 3. Uncheck the "Run this program in compatibility mode for:" check box of compatibility mode in the "Compatibility for all users" tab and click the OK button.
- 4. Click the OK button on the "setup Properties" screen.



(Reference) When message appears at start of installation

When the installation of this product starts, the "This package is not in proper operating environment" message appears, disabling normal completion of installation.

In such a case, close all applications and perform the (a) or (b) operation.

4 - 10 4 - 10

(a) Installation of dcom95.exe or Axdist.exe

Execute dcom95.exe or Axdist.exe provided for GX Configurator-QP. Install GX Configurator-QP after executing the exe file and restarting the IBM-PC/AT compatible.

The exe file to be executed on the corresponding operating system is indicated below.


Operating System	File name
Microsoft® Windows® 95 Operating System dcom95.exc	
Microsoft® Windows® 98 Operating System	Axdist.exe
Microsoft® Windows NT® Workstation Operating System Version 4.0	Axdist.exe

(dcom95.exe and Axdist.exe are in the "Update" folder on CD-ROM.)

(b) Installation of EnvMEL


Execute Setup.exe in the "EnvMEL" folder on this product CD-ROM. Install GX Configurator-QP after executing the "Setup.exe".

*: When user account control is enabled, the following dialog box appears. Click Allow or Yes.



After executing the above exe file, install the product again. If this product is not installed properly at this time, reboot the personal computer.

*: If the following dialog box appears, select "This program installed correctly". Do not choose "Reinstall using recommended settings", because the installer installs an incorrect module.



4 - 11 4 - 11

4.1.3 Installing the USB Driver

To communicate between the personal computer on which Windows® 2000 Professional, Windows® XP, Windows Vista®, or Windows® 7 has been installed and the CPU module with USB, install a USB driver.

The following is the USB driver installation procedure.



If the USB driver cannot be installed, check the following setting.

• When Windows® 2000 Professional is used

If you have selected "Block-Prevent installation of unsigned files" after [Control Panel] - [System] - [Hardware] - [Driver Signing], the USB driver may not be installed

Choose "Ignore-Install all files, regardless of file signature" or "Warn-Display a message before installing an unsigned file" for [Driver Signing], and install the USB driver.

· When Windows XP used

If you have selected "Block-Never install unsigned driver software" after [Control Panel] - [System] - [Hardware] - [Driver Signing], the USB driver may not be installed.

Choose "Ignore-Install the software anyway and don't ask for my approval" or "Warn-Prompt me each time to choose an action" for [Driver Signing], and install the USB driver.

[1] When Windows® 2000 Professional is used

The following indicates the procedure for installing the USB driver when using Windows® 2000 Professional.




 The screen shown on the left appears when the personal computer and the CPU module is connected with USB cable.

Click the Next>


(To the next page)

4 - 12 4 - 12






2) Choose "Search for a suitable driver for my device (recommended)" and click the Next>.



3) Check "Specify a location" and click the Next>



4) As the screen on the left appears, set the GX Configurator-QP installation destination "Easysocket\USBdrivers" and click the Next>.

The screen shown on the left shows the example of setting C:\MELSEC\Easysocket\USBdrivers.

If volume MELSOFT products have been installed, browse the installation destination of the first product.



(Completion)

5) The screen on the left appears to indicate completion of installation.

Click the Finish to terminate installation.

[2] When Windows® XP is used

The following indicates the procedure for installing the USB driver when using Windows® XP.



 The screen shown on the left appears when the personal computer and the CPU module is connected with USB cable.

Choose "Install from a list or specific location [Advanced]" and click the Next>.




As the screen on the left appears, choose "Include this location in the search".

Check "Include this location in the search" and set "Easysocket\USBDrivers" of the folder where GX Configurator-QP was installed.

After setting, click the Next>

The screen shown on the left shows the example of setting C:\MELSEC\Easysocket\USBDrivers.

If volume MELSOFT products have been installed, browse the installation destination of the first product.



As the screen on the left appears, click the Continue Anyway.


REMARKS

Though the screen on the left appears during installation of the USB driver, we have confirmed that the USB driver operates properly using Windows® XP.

(No problem will occur after installation of the USB driver.) Click Continue Anyway to continue the installation of the USB driver.

(To the next page)

4 - 14 4 - 14





(Completion)

4) The screen on the left appears to indicate completion of installation.

Click the Finish to terminate installation.


[3] When Windows Vista® is used

The following shows installation procedure of USB driver when using Windows Vista®.




- The screen shown on the left appears when the personal computer and the CPU module is connected with USB cable. Choose "Locate and install driver software (recommended)" and wait until searching ends.
 - * : When user account control is enabled, the following screen appears.

 Click the Continue button.





2) The left screen appears. Choose "Browse my computer for driver software (advanced)".



3) The left screen appears. Set installation location of GX Developer, "Easysocket\USBdrivers". Then, click the Next> button.
The left screen shows an example when

C:\MELSEC\Easysocket\USBdrivers is set.

If multiple MELSOFT products have been installed, refer to the installation location of the first installed product.

(To the next page)

4 - 16 4 - 16






4) The left screen appears. Select "Install this driver software anyway".



5) The left screen appears. Click the Close button.



6) The left screen appears when the installation is completed.Click the Close button to exit.


4 - 17 4 - 17

[4] When Windows® 7 is used

The following shows installation procedure of USB driver when using Windows® 7.




1) The message shown on the left appears when the personal computer is connected to the CPU module with a USB cable.



 \downarrow


2) Select "System and Security" from the Control Panel.

To display the Control Panel, select [Start] - [Control Panel].



 \downarrow


3) The screen shown on the left appears. Select "Administrative Tools".



4) The screen shown on the left appears. Select "Computer Management".

(To the next page)


4 - 18 4 - 18



5) Right-click "Unknown device" in the Windows Device Manager as shown left, and select "Update Driver Software...".

REMARKS

If multiple 'Unknown devices' exist therefore cannot be specified, right-click "Unknown device" as shown left and select "Properties". The "Unknown device", whose "Hardware Ids" is "USB\VID_06D3&PID_1800" on the <<Details>> tab of the properties screen, is the update target.



Update Driver Software - Unknown Device

How do you want to search for driver software?


Search automatically for updated driver software Windows will search your computer and the Internet for the latest driver software for your device, unless you've disabled this feature in your device installation settings.

Browse my computer for driver software Locate and install driver software manually.

(To the next page)

6) The screen shown on the left appears. Select "Browse my computer for driver software".

4 - 19 4 - 19



7) The screen shown on the left appears. Set installation location of GX Configurator-QP,

"Easysocket\USBdrivers".

Then, click the Next> button.


The left screen is an example when

C:\MELSEC\Easysocket\USBdrivers is set.


If multiple MELSOFT products have been installed, refer to the installation location of the first installed product.



8) The screen shown on the left appears. Click the Install button.



The screen shown on the left appears. Click the Close button.



10) "MITSUBISHI Easysocket Driver" is registered under "Universal Serial Bus controllers".

4.1.4 Upgrading the USB drivers

In Windows Vista® or Windows® 7, if MELSOFT incompatible with each operating system has been installed when MELSOFT compatible with each operating system is installed, upgrading the USB drivers is required.

The USB driver has the following two types:

- · USB driver for CPU module connection
- USB driver for GOT connection (used for the GOT transparent mode.)
- (1) Procedure for upgrading the USB driver for CPU module connection

(a) Check method

Whether upgrade of the USB driver is required or not can be checked by the USB driver version.

Start the Windows Device Manager while the personal computer is connected to the CPU module with USB, right-click "MITSUBISHI Easysocket Driver" and select "Properties".

Update is necessary if the version shown in the << Driver>> tab of the properties screen is the following.

- Windows Vista®: "2.0.0.0" or earlier
- · Windows® 7: "3.0.0.0" or earlier



(b) Upgrade procedure



(To the next page)

- 1) Connect the personal computer to the CPU module with USB cable.
- 2) Start the Windows Device Manager, right-click "MITSUBISHI Easysocket Driver", and select "Uninstall".

4 - 21 4 - 21




3) The warning dialog box shown on the left appears. Select "Delete the driver software for this device." and click the OK button.

4) Disconnect the USB cable and reconnect it to the same USB port after 5 seconds.

[Windows Vista®]

The confirmation dialog box the following screen appears.

Select "Ask me again later".




[Windows® 7]

The following balloon appears for a little while.



↓ (To the next page)




5) Right-click "Unknown device" in the Windows Device Manager and select "Update Driver Software...".


REMARKS

If there are several unknown devices and a driver to be upgraded cannot be specified, right-click "Unknown device" and select "Properties".


The "Unknown device", whose "Hardware Ids" is "USB\VID_06D3&PID_1800" in the "Details" tab of the "Unknown device Properties" dialog box, is the upgrade target.



6) The dialog box shown on the left appears.
Select "Browse my computer for driver software".



(To the next page)



7) The dialog box shown on the left appears.

Set the installation location of this product,


"Easysocket\USBdrivers" and click Next.

The left dialog box shows an example when

"C:\MELSEC\Easysocket\USBdrivers" is set.

When multiple MELSOFT products have been installed, set the installation location of the first-installed product.

[Windows Vista®]




8) If the confirmation dialog box shown on the left appears, select "Install this driver software anyway" or Install.

[Windows® 7]



(To the next page)

4 - 24 4 - 24



9) The confirmation dialog box shown on the left appears. Select Close. Upgrade is completed.

(2) Procedure for upgrading the USB driver for GOT connection

(a) Check method


While the personal computer is connected to GOT with USB, power off and then on the GOT and then start the Windows Device Manager.

If "MITSUBISHI GOT1000 USB Controller" is not displayed under

"Universal Serial Bus controllers", and "Unknown device" is displayed under "Other devices", the driver needs to be upgraded.


The "Unknown device", whose "Hardware Ids" is

"USB\VID_06D3&PID_01E0" in the "Details" tab of the "Unknown device Properties" dialog box, is the upgrade target.




(b) Upgrade procedure

- 1) Connect the personal computer to the GOT with USB cable.
- Start the Windows Device Manager, right-click "Unknown device", and select "Update Driver Software...".




(To the next page)

4 - 26 4 - 26



3) The confirmation dialog box shown on the left appears. Select "Browse my computer for driver software".



4) The dialog box shown on the left appears.


Set the installation location of this product,

"EZSocket\EZSocketGOT\Drivers" and click Next.

The left dialog box shows an example when

"C:\MELSEC\EZSocket\EZSocketGOT\Drivers" is set.

When multiple MELSOFT products have been installed, set the installation location of the first-installed product.



(Completion)


5) The confirmation dialog box shown on the left appears. Select Close. Upgrade is completed.

4.2 Uninstallation

This section explains the operation for removing GX Configurator-QP from the hard disk.

Displayed screens may differ depending on the operating system. In such a case, uninstall GX Configurator-QP with referring to "Remarks".

(1) Uninstalling GX Configurator-QP



↓ (To the next page) 1) Double-click "Add/Remove Programs" on the Control Panel.


To display the Control Panel, choose [Start] \rightarrow [Settings] \rightarrow [Control Panel].

REMARKS

When using Windows® XP, choose "Add or Remove Programs" from the Control Panel. For Windows Vista® and Windows® 7, select "Uninstall a program" in the "Control Panel" window

To display the Control Panel, choose [Start] - [Control Panel].

4 - 28 4 - 28



↓ (To the next page) 2) Choose "GX Configurator-QP".

After selection, click Add/Remove.

REMARKS

The screen shown on the left is the one for Windows® 98.

The displayed screen varies with the operating system.

Depending on the used operating system, perform the following operation.

<Windows® 2000 Professional and Windows® XP>

- (a) Click "Add/Remove Programs".
- (b) Choose "GX Configurator-QP".
- (c) Click the Change/Remove button.

<Windows Vista® >

Select "GX Configurator-QP" in the "Uninstall or change a program" window and click "Uninstall/Change".*


<Windows® 7>

Double-click "GX Configurator-QP" in the "Uninstall or change a program" window.*


* : When user account control is enabled in Windows Vista®, the following screen appears.

Click Continue or Yes.

[Windows Vista®]



[Windows® 7]






3) Confirm that the file may be removed.


Clicking the Yes button starts uninstallation.

Clicking the No button stops uninstallation.



4) If the left screen has appeared, click the No To All button.

If you click the Yes or Yes To All button, the shared file of the Windows® compatible MELSOFT software is removed. Therefore, click the No To All button when removing GX Configurator-QP only.




(Completion)

5) When the removal completed message appears, click the OK button.


When the completed message appears, uninstallation is complete.

4.3 Starting GX Configurator-QP


This section explains how to start GX Configurator-QP from the start menu.



- Move the cursor from [Start] → [Programs*]
 → [MELSOFT Application].
 - *: [All Programs] is shown for Windows XP, Windows Vista $^{\circ}$, and Windows 7.



2) Click [GX Configurator-QP].




3) GX Configurator-QP starts.

4 - 31 4 - 31

4.4 Exiting GX Configurator-QP

This section describes how to exit GX Configurator-QP.

(1) Menu-driven exit method



Click the [Project] \rightarrow [Exit] menu. GX Configurator-QP ends.

(2) Title bar-driven exit method



Click and choose [Close].

Alternatively, click at the right end of the title bar.

Point

In the online status such as the monitor or test mode, you cannot exit GX Configurator-QP.

In any of the following cases, end the program after choosing the offline status. Monitor mode (refer to Section 10.2)

The first though the first to be considered to the first to the considered to the first to the f

Test mode (refer to Section 10.4)

Online status for checking connect (refer to Section 7.4)

REMARK

When a new project has been created or a project has been modified but is not yet saved, the confirmation dialog box appears to ask you whether you will save that project or not.

When you do not want to save it, click the No button.

When you want to save it, click the Yes button.

When you save a new project, choose [Save as Project].


For further information, refer to Section 6.1.

5. SCREEN MAKEUP AND BASIC OPERATIONS

This chapter explains the screen makeup and the display selection, window arrangement and other operations of GX Configurator-QP.

5.1 Screen Makeup and Display Selection

This section provides the screen makeup of GX Configurator-QP.



(1) Display selection and window arrangement operations

You can use the following drop-down menu to choose to display or hide any toolbar or arrange windows.

Menu Operation	Description
[View] → [Project tree view] [Toolbar] [Test toolbar] [Online toolbar]	Used to display or hide the corresponding toolbar.
[View] → [Status bar]	Used to display or hide the status bar.
$[View] \to [Select\ block\ start\ no]$	Used to choose any of block numbers 0 to 4 to be displayed on the block start data edit window. (Refer to Section 8.5.1)
[Window] → [Cascade]	Used to overlap multiple windows. The above screen gives a cascade example
[Window] → [Tile vertically]	Used to lay multiple windows side by side.
[Window] → [Arrange icons]	Used to arrange windows which have been reduced to small icons (minimized).
$[Window] \to [All\ close]$	Used to close all open windows.

5 - 1 5 - 1

5.2 Basic Operations

(1) Basic operation for project tree view


(a) Opening a window

The currently open project appears on the project tree view. Double-click the project name or click \pm to show its functions. (From the keyboard, choose the project name and press the "—" key.)

Double-click the function name or click \boxplus to show the window types. (From the keyboard, choose the function name and press the " \to " key.)

Double-click the window name to open that window.


(From the keyboard, choose the window name and press the "Space" key.)



(b) Changing the active project


Any online operation except for monitor, sampling (signal) monitor and sampling (buffer) monitor is performed for the module to which the active project is connected, separately from the active window.


To change the active project, right-click the project name and click [Set Active Project].





When multiple projects are open, confirm the active project before starting any online operation except for monitor, sampling (signal) monitor and sampling (buffer) monitor.

(2) Basic operation for dialog boxes









1) Tab Click the setting item name to select.

2) Text box Type numerals/characters.

3) Command button Click this button when executing "OK", "Cancel" etc., or when displaying the dialog box.

4) Radio button Click O to choose one item among multiple choices.

5) List box Click to list choices, then click the item to be chosen.

6) Check box To execute any item, click to check it off.

7) Spin box Used either to type a value directly or to change a value by clicking = When typing a value directly, click inside the spin box and enter the value from the keyboard. increase the value, or click I to decrease.



When performing operation from the keyboard, choose the setting item with the "Tab" key.

When there are two or more choices, use the " \leftrightarrow ", " \rightarrow ", " \uparrow " and / or " \downarrow " key.

5 - 3 5 - 3

(3) Moving the focus from the keyboard

Use the "Alt" key to move the focus to the drop-down menu.

Use the "F6" key to move the focus between the project tree view and window (edit, monitor, trace, checking connect).

(4) Shortcut key list

The following shortcut keys can be used with GX Configurator-QP.

Shortcut Key	Function (Corresponding Menu Item)	Tool Button	Shortcut Key	Function (Corresponding Menu Item)	Tool Button
Ctrl+N	New project file		Ctrl+Y	Clear row	_
Ctrl+O	Open project file	1	Ctrl+B	Select block start no	_
Ctrl+S	Save		Ctrl+T	Write to module	
Ctrl+G	Change module type		Ctrl+M	Monitor On/Off	4
Ctrl+P	Print		Ctrl+F4	Close active window	_
Ctrl+X	Cut	X	Ctrl+F6	Change active window	_
Ctrl+C	Сору		F1	Help	_
Ctrl+V	Paste			Change active window	
Ctrl+A	Select All		Alt+F4	Evit/along dialog boy	_
Ctrl+J	Jump	_		Exit/close dialog box	

(5) Tool button list

The following table lists the tool buttons of GX Configurator-QP.

Toolbar Type	Tool Button	Function (Corresponding Menu Item)	Toolbar Type	Tool Button	Function (Corresponding Menu Item)
		New project file		F)	Test On/Off
	≧	Open project file		•	All axis stop command
		Save		•	Error reset #1
Toolbar	*	Cut		2	Error reset #2
		Сору		3	Error reset #3
		Paste		3	Error reset #4
	a	Print		191	M code Off #1
	***	Read from module	Test	2	M code Off #2
		Write to module	toolbar	3	M code Off #3
Online toolbar	器	Verify module		4	M code Off #4
toolbai		Monitor On/Off		\mathcal{F}_{i}	Operation Test #1
		Check module		> 2	Operation Test #2
				~	Operation Test #3
				7 4	Operation Test #4
					Positioning data edit in TEST MODE
				础	Teaching

Project

6

6. PROJECT CREATION

A project is a collection of parameters, servo parameters, positioning data and block start data.

<GX Configurator-QP project makeup>

Parameters (Axis #1 to #4)
There are basic parameters 1, basic parameters 2, extended parameters 1, extended parameters 2, OPR basic parameters and OPR extended parameters.

Servo parameters (Axis #1 to #4: QD75M, QD75MH and LD77 only)
Data transferred from the QD75M, QD75MH and LD77 to the servo amplifier.
<QD75M>

They include the servo basic parameters, servo reguration parameters and servo extended parameters.

<QD75MH/LD77>

They include the servo amplifier series, basic setting parameters, extension setting parameters and I/O setting parameters, extended control parameters, special setting parameters.

Positioning data (Axis #1 to #4)

Data used to set the control data such as positioning control method and addresses. Data No. 1 to 600 can be set for each axis.

Block start data (Axis #1 to #4)

Data used to attach a condition to a positioning control start and set the repeat count. Note: Equivalent to the start block data of the AD75 positioning module.




When executing "New Project" or "Save as Project", you cannot use the following characters and symbols in the project path and project name to be specified.


/ , : ; * " < > | \\ COM LPT AUX CON PRN NUL CLOCK\$

6.1 Creating a New Project


Set the QD75/LD75/LD77 model used to create a new project and the project items.



1) Click the [Project] \rightarrow [New Project] menu (\square).



2) Click the "Reference" button of the Module type in the [New Project] dialog box.




3) Choose the Select type and Select Axis radio buttons.

4) Click the "OK" button.

(To the next page)

6

(From the preceding page)



*1 Example)

Project path: C\MELSEC• • • • QD75\

Project name: Sample01 When setting the following:

C:\MELSEC\ • • • QD75P\Sample01\Sample01_Q75

Within 150 characters

*2 To utilize the data read from the QD75/LD75/LD77, refer to "HELPFUL OPERATION (PART 2)" in this section.

- 5) Set the project save path.
 The project save path defaults to
 C:\MELSEC\QD75P.
 When changing it, refer to "HELPFUL
 OPERATION (PART 1)" in this section.
- 6) Set the project name.

 When specifying the project file name, you can use a total of up to 150 characters to set the project path and project name.

When setting the project path and project name, the total number of characters should be within 150

This screen assumes that the project name is "Sample1".

- 7) Set the project title as required.
- 8) Click the "OK" button.
 This creates a new project.




HELPFUL OPERATION (PART 1)

You can perform the operation of changing the project save path while simultaneously checking the project tree view.

In step 5) on the preceding page, click the Project file set "Reference" button. When the following dialog box appears, choose the project save path from the project tree view or type it from the keyboard.

This operation is also used to perform such operations as "Open Project", "Save Project" and "Delete Project".





When saving a project, you cannot set "Untitled" in Project name. Also, do not use "Untitled n (n: 1, 2, 3)" in Project name. If you read "Untitled 1" and create a new project in default setting, "Untitled2" appears on the Project tree view.




HELPFUL OPERATION (PART 2)

When utilizing the data written to the QD75/LD75/LD77 to create a new project, perform the following operation.

- 1. Set the Module type, project save path, project name and project title in the New Project dialog box.
- 2. Click the "New Project read to module" check box.
- 3. Click the "OK" button.
- 4. Click the "OK" button in the instruction dialog box.
- 5. Set the interface, I/O address and others in the Connection setup dialog box (refer to Section 7.1).
- 6. Click the "OK" button.
- 7. Set the type and range of the data to be read in the Read from module dialog box (refer to Section 9.1).
- 8. Click the "OK" button to read the positioning data, block start data and parameters in the specified range from the QD75/LD75/LD77.

<New module data reading procedure>






When New Project read to module is performed for new project creation, the QD75/LD75/LD77 connected has precedence if the QD75/LD75/LD77 model of the project differs from the QD75/LD75/LD77 model connected.

After completion of reading, choose the [Project] \rightarrow [Change module type] menu to change the model. (Refer to Section 11.1.2.)

6.2 Opening the Existing Project





- 1) Click the [Project] \rightarrow [Open Project] menu (\square).
- Click the project name.
 For the setting operation of referring to the project save path, refer to "HELPFUL OPERATION (PART 1)" in Section 6.1.
- 3) Click the "Open" button.
- 4) The specified project opens.

5) To open multiple projects, repeat the operations in steps 1) to 3).

The open projects are displayed on the project tree view.




 Projects created with GX Configurator-QP Version 2.33K or later cannot be opened with GX Configurator-QP Version 2.32J or earlier.
 Install GX Configurator-QP of the latest version.

• Recently opened projects (files) can be opened from the project menu

Up to four projects can be displayed.

Note that any projects not saved do not remain in the project menu.

In the initial setting, the [Latest file] menu item appears.



6.3 Saving the Project



PURPOSE

The project file which is currently edited is saved.



BASIC OPERATION


- 1. Set the project to be saved as the active project. (Refer to Section 5.2.)
- 2. To perform save operation, click the [Project]→[Save Project] menu (□). To perform save as operation, click the [Project] → [Save as Project] menu. When specifying the project file name, you can use a total of up to 150 characters to set the project path and project name.

When setting the project path and project name, the total number of characters should be within 150.

For the operation of setting the project save path and project name, refer to "HELPFUL OPERATION (PART 1)" in Section 6.1.



DISPLAY/SETTING SCREEN






HELPFUL OPERATION

When you want to change the title in the same project name, perform the following operation.

- 1. Double-click "Project information" on the Project tree view.
- 2. Click the unchecked "Modified title" check box in the Project information window and change the current title.
- 3. Click the [Project] → [Save Project] menu.





When saving a project, you cannot set "Untitled" in Project name.
Also, do not use "Untitled n (n: 1, 2, 3)" in Project name. ☐ If you read "Untitled 1" and create a new project in default setting, the same project name (Untitled 1) appears on the Project tree view.

6.4 Closing the Project



PURPOSE

The open project is closed.



BASIC OPERATION

- 1. Set the project to be closed on the project tree view.
- 2. Click the [Project] → [Close Project] menu.
- 3. If any setting has been changed, the dialog box appears to confirm whether the project will be saved or not.

Click the "Yes" button to save and close the project.

Click the "No" button to close the project without saving it.



6 - 9 6 - 9

6.5 Deleting the Project



PURPOSE

The project is deleted from HD, FD, etc..




BASIC OPERATION

- 1. Click the [Project] → [Delete Project] menu.
- 2. In the Delete project file dialog box, choose the project you want to delete and click the "Delete" button.
 - Refer to "HELPFUL OPERATION (PART 1)" in Section 6.1 for the operation of changing the project save path.
- 3. As the project file deletion confirmation dialog box appears, click the "Yes"
- 4. The project is deleted.



DISPLAY/SETTING SCREEN



6 - 106 - 10

6.6 Reading other Format Files

6.6.1 Reading SW1RX/IVD/NX-AD75P / GX Configurator-AP format file



PURPOSE

The positioning data, M code comments, block start data, condition data, parameters, servo parameters are read from the file of the MELSEC-A series software package (SW1—AD75P, GX Configurator-AP) as a new project of GX Configurator-QP. (Note that they cannot be read to the LD75/LD77 project.)




BASIC OPERATION

- 1. Click the [Project] \rightarrow [Import file] \rightarrow [File reading of SW1RX/IVD/NX-AD75P] / [File reading of SW0D5C-AD75P] menu.
- 2. Choose the file in the Open dialog box and click the "Open" button.
- 3. Click the "OK" button in the read destination confirmation dialog box.
- 4. Set the QD75 model, project save path, project name and project title in the Other file type project dialog box. (Refer to Section 6.1 "HELPFUL OPERATION (PART 1)".)
- 5. Click the "OK" button.



DISPLAY/SETTING SCREEN



(The screen shows an example of GX Configurator-AP file read.)



DISPLAY/SETTING DATA

Item	Description
Look in	Choose the project save path of the file you will read.
File name	Set the file name you will read.
Files of type	SW1RX/IVD/NX-AD75P File (*.d75) or SW0D5C-AD75P File (*.w75) appears.
"Up One Level" button	Click this button to show the folder one level above the currently displayed folder.
"List" button	Click this button to list files and folders.
"Details" button	Click this button to display the file and folder in detail.
"Open" button	Click this button to read the file.

6 - 11 6 - 11



- Since there are no four-axis type AD75 positioning modules, the positioning data, block start data and parameters of the fourth axis are not read if the QD75 model of the save destination project is of the four axis type.
- Note the following when the file in the GX Configurator-AP or SW1
 —-AD75P format has been read to GX Configurator-QP.

$[\mathsf{AD75P} \to \mathsf{QD75P/QD75D}]$

	Da	ata Type	Read to GX Configurator-QP		
	Start bias	speed	Section is changed from basic parameter 2 to bas parameter 1.		
		Over limit			
		Under limit			
		Drive unit ready]		
		Stop signal	These are new items and therefore not read.		
	I/O logic	External signal	Default setting.		
	I/O logic	Zero phase signal	Default Setting.		
		Zeroing dog			
		MPG	1		
Parameter		DCC			
		Command PLS signal	Output pulse logic selection to drive unit has been changed to this name.		
	Stepping motor mode				
	Manual p	ulse generator selection	These are disused items and therefore read- disabled.		
	ACC/DEC	C time unit selection	uisavicu.		
	Near path	n control mode selection	This is a disused item and therefore read-disabled. (Because near path control mode is fixed)		
	Manual p	ulse generator input	These are new items and therefore read-disabled		
	Speed-po	sition function selection	Default setting.		
Positioning	SLV axis		This is a new item and therefore read-disabled. Default setting.		
data	Positionin	ng comment	Not read from SW1AD75P.		
Block start data			Start block data has been changed to this name. Because of reduction in number of blocks, block numbers 5 to 10 are read-disabled. "Stop" in special start is replaced by "Wait start". *		
Indirect data			This is a disused item and therefore read-disabled.		

^{* :} After file reading, condition data setting is needed.

$[\underline{\text{AD75P}} \rightarrow \text{QD75M/QD75MH, AD75M} \rightarrow \text{QD75P/QD75D}]$

	Data Type	Read to GX Configurator-QP
Parameter		Default actting since parameter data differ
Servo para	meter	Default setting since parameter data differ.
	SLV axis	This is a new item and therefore read-disabled. Default setting.
data	Positioning comment	Not read from SW1AD75P.
Block start data		Start block data has been changed to this name. Because of reduction in number of blocks, block numbers 5 to 10 are read-disabled. "Stop" in special start is replaced by "Wait start". *
Indirect data		This is a disused item and therefore read-disabled.

* : After file reading, condition data setting is needed.

Point

ı	Г٨	Ο.	751	Λ .	· QE	751	111	JU.	フにN	ΛL	J1
ı	м	ט	/ OII	/I →	· WL	<i>יו</i> סו	VI/C	טג	יוכ ז	ИГ	71

	Da	ata Type	Read to GX Configurator-QP		
	Start bias	speed	Section is changed from basic parameter 2 to basic parameter 1.		
		Over limit			
		Under limit			
	I/O logic	Stop signal	These are new items and therefore not read.		
		External signal	Default setting.		
		Zeroing dog			
		MPG			
Parameter	ACC/DEC	time unit selection	This is a disused item and therefore read-disabled.		
	Near path	control mode selection	This is a disused item and therefore read-disabled. (Because near path control mode is fixed)		
	External o	command function selection	External start function selection has been changed to this name.		
		→ On-time permissible nge setting	Permissible restart range has been changed to this name.		
	Manual poselection	ulse generator input	These are new items and therefore read-disabled. Default setting.		
	Speed-po	sition function selection			
Servo	When ser H-BN)"	vo series is "MR-H-B (MR-	Values of "MR-H-BN" are read.		
parameter	When sen	vo series is "MR-J-B" *1	Default values of "MR-J2S-B" are read.		
*1	When sen	vo series is "MR-J2-B"	Values of "MR-J2-B" are read. *2		
	When ser	vo series is "others"	Default values of "MR-J2S-B" are read.		
•	ositioning SLV axis		This is a new item and therefore read-disabled. Default setting.		
data	Positionin	g comment	Not read from SW1⊡-AD75P.		
			Start block data has been changed to this name.		
Block start	data		Because of reduction in number of blocks, block		
DIOCK Start Mata			numbers 5 to 10 are read-disabled.		
			"Stop" in special start is replaced by "Wait start". *3		
Indirect dat	a		This is a disused item and therefore read-disabled.		

- *1: Default values are used for the QD75MH, since parameter contents are different. Make setting according to the used servo.
- *2: The default values of the MR-J2S-B are read since the QD75M is incompatible. Make setting according to the used servo.
- *3: The MR-J2-B data are read intact. When using them with the MR-J2S-B or MR-J2-Jr, change the servo series to the "MR-J2S-B/MR-J2-Jr". If additions or extension settings have been made in the program, check the data of each setting item.
- *4: After file reading, condition data setting is needed.

6.6.2 Reading the CSV format file



PURPOSE

GX Configurator-QP allows CSV format files created with spreadsheet software, etc. be read as positioning data (axis #1 to #4). (Parameters, servo parameters, and block start data cannot be read.)

The creating method and reading operation of CSV format data are described below.



- If all items that make up positioning data have not been entered, CSV format data cannot be read, resulting in an error.
- Since CSV format data is read axis-by-axis, create CSV format data noting which axis (#1/#2/#3/#4) data is being created.

(1) CSV format data creating method

The following sheet indicates the items and values of CSV format data set on a column basis.

<Example of data set to spreadsheet software>

		0.0 O. aa		p. 00.00.						
	Α	В	C	D	Е	F	G	Н		J
1	2	Α	2	0	1	1000	0	500	0	1
2	2	F	2	0	1	1000	1000	500	0	2
3	2	Α	2	0	1	-1000	0	500	0	3
4	2	F	2	0	1	-1000	-1000	500	0	0
5	0	Α	2	0	1	0	0	500	0	0
6										
L		1		,	. ,	1 /	. ,	\	1 /	
1)	2)	3)	4)	5)	6)	7)	8)	9)	10)	11)

<Data set to the above spreadsheet software was read with GX Configurator-QP>

No.	Pattern	CTRL method	SLV axis	ACC(ms)	DEC(ms)	Positioning address [pls]	Arc Address [pls]	Command speed [pls/sec]	Dwell time [ms]	M code
1	2:LOCUS	A:ABS line2	Axis #2	0;1000	0;1000	1000	0	500	0	1
2	2:LOCUS	F:ABS ArcRGT	Axis #2	0;1000	0;1000	1000	1000	500	0	2
3	2:LOCUS	A:ABS line2	Axis #2	0;1000	0;1000	-1000	0	500	0	3
4	2:LOCUS	F:ABS ArcRGT	Axis #2	0;1000	0;1000	-1000	-1000	500	0	0
5	0:END	A:ABS line2	Axis #2	0;1000	0;1000	0	0	500	0	0
6										

Number	Setting	Remarks
1)	Set the positioning control pattern in column 1 from left. Set any value from 0 to 2.	
2)	Set the operation method in column 2 from left. Set it with 1 to 9 and A to Z.	
3)	Set the interpolation axis for two-axis interpolation control in column 3 from left.	
4)	Set the host axis for single-axis or three-/four-axis interpolation control.	Refer to Section 8.3
5)	Set the accel time No. in column 4 from left. Set it from 0 to 3.	for details of data
6)	Set the decel time No. in column 5 from left. Set it from 0 to 3.	corresponding to
7)	Set the address in column 6 from left.	alphanumeric
8)	Set the circular positioning address in column 7 from left.	values to be set.
9)	Set the command speed in column 8 from left.	
10)	Set the dwell time in column 9 from left.	
11)	Set the M code in column 10 from left.	

(2) CSV format file reading operation



BASIC OPERATION

- 1. On the project tree view ,set the active project whose CSV format file will be read. (Refer to Section 5.2.)
- 2. Click the [Project] → [Import file] → [File reading of CSV form positioning data]
- 3. Click the "Yes" button in the dialog box which confirms that the read CSV format data will replace the present positioning data.
- 4. Choose the axis in the Object axis selection dialog box and click the "OK" button.
- 5. Choose the file and file type in the Open dialog box and click the "Open" button.
- 6. Click the "OK" button in the read confirmation dialog box.




DISPLAY/SETTING SCREEN

[Object axis selection dialog box]



[Open dialog box]





DISPLAY/SETTING DATA

Item	Description
Object axis selection dialog	Choose the axis whose positioning data will be read in the CSV format.
box	
Look in	Choose the project save path of the file you will read.
File name	Set the file name to be read to the project.
Files of type	CSV File (*.CSV) appears.
"Up One Level" button	Click this button to show the folder one level above the currently displayed folder.
"List" button	Click this button to list files and folders.
"Details" button	Click this button to display the file and folder in detail.
"Open" button	Click this button to read the file.

6 - 15 6 - 15

6.7 Write to CSV Format File



PURPOSE

The positioning data set in the project of GX Configurator-QP is saved in the CSV format file.

Refer to Section 6.6.2 (1) for the positioning data setting items and CSV format data.




BASIC OPERATION

- 1. On the project tree view, set as the active project the project whose positioning data will be saved in the CSV format file. (Refer to Section 5.2.)
- 2. Click the [Project] → [Export file] → [File writing of CSV form positioning data] menu.
- 3. Choose the axis in the Object axis selection dialog box and click the "OK" button.
- 4. Set the save location and file name in the Save As dialog box and click the "Save" button.
- 5. Click the "OK" button in the write confirmation dialog box.




DISPLAY/SETTING SCREEN

[Object axis selection dialog box]



[Save As dialog box]



6 - 16 6 - 16



DISPLAY/SETTING DATA

Item	Description
Object axis selection dialog box	Choose the axis whose positioning data will be saved in the CSV format.
Save in	Choose the drive or folder where the data will be saved.
File name	Set the file name to be saved in the other format file.
Files of type	CSV File (*.CSV) appears.
"Up One Level" button	Click this button to show the folder one level above the currently displayed folder.
"Create New Folder" button	Click this button to create a "new folder".
"List" button	Click this button to list files and folders.
"Details" button	Click this button to display the file and folder in detail.
"Save" button	Click this button to save the other format file.

6 - 17 6 - 17 7. SYSTEM CHECKING FROM PERIPHERAL DEVICE

Specify the QD75/LD75/LD77 to be accessed per project, also check connections with the external equipment (servo amplifiers, servo motors, etc.), and conduct initial operation tests of the servo motors.

7.1 Connection Setup



PURPOSE

Choose an the interface connected to the QCPU, LCPU, serial communication module, or Q corresponding MELSECNET/H network remote I/O module, and set the I/O address of the QD75/LD75/LD77 to be accessed.




BASIC OPERATION

- 1. Click the [Online] \rightarrow [Connection setup] menu.
- 2. Choose the interface in the Connection setup dialog box and set the I/O address, etc.
- 3. After the setting is completed, click the "OK" button.



DISPLAY/SETTING SCREEN



7

7 - 1 7 - 1



DISPLAY/SETTING DATA

Item		Description
PC	Interface	Choose the type of the personal computer side interface. [For QD75 projects] "RS-232C", "USB", "Ethernet direct", or "Q series bus" can be selected. When using a PC CPU module, select "Q series bus". When "Ladder logic test" is selected for the programmable controller side interface, the personal computer side interface cannot be selected. [For LD75/LD77 projects] "RS-232C", "USB", or "Ethernet direct" can be selected. When "RS-232C" is selected for the personal computer side interface, "PLC" is selected for the programmable controller side interface, and the personal computer is directly connected to the LCPU using RS-232 cable, an RS-232 adapter (optional item) is required. When "via GOT transparent mode" is selected for the programmable controller side interface, "RS-232C" or "USB" can be set for the personal computer side interface. Since settable items depend on the selection status of "via GOT transparent mode", if the item is selected, reconfigure the settings. When "Serial communication" is selected for the programmable controller side interface and "via GOT transparent mode" is not selected, the personal computer side interface is fixed to "RS-232C".
	COM setting Transmission	Choose a COM port when the personal computer side interface is "RS-232C". The selection range is "COM1" to "COM10". Choose a transmission speed when the personal computer side interface is "RS-232C".
	speed	The selection range is "9.6kbps" to "115.2kbps".
	Interface	Choose the type of the programmable controller to be connected. [For QD75 projects] "PLC", "Serial communication" or, "Ladder logic test" can be selected. When connecting via Q corresponding serial communication module, select "Serial communication". When connecting to GX Simulator, select "Ladder logic test". (Start GX Simulator from GX Developer beforehand.) When "Q series bus" is set for the personal computer side interface, the PLC side interface is fixed to "PLC". [For LD75/LD77 projects] "PLC" or "Serial communication" can be selected. When connecting via L corresponding serial communication module, select "Serial communication".
	PLC type	Select the model of the control CPU of the positioning module to communicate with or "Remote I/O".
PLC	Multi PLC specification	Select the CPU No. of the control CPU of the positioning module to communicate with in a multiple CPU system configuration. [For QD75 projects] "Non-choice", "PLC No.1", "PLC No.2", "PLC No.3", or "PLC No.4" can be selected. For a single CPU system configuration, select "Non-choice" or "PLC No. 1". [For LD75/LD77 projects] Since the projects are not supported in the multiple CPU system configuration, this item is fixed to "Non-choice".
	via GOT transparent mode	Select this item when connecting GX Configurator-QP to the programmable controller via GOT1000 series. This item can be selected when "RS-232C" or "USB" is chosen in the personal computer side interface, and "PLC" or "Serial communication" is chosen in the programmable controller side interface. When choosing "via GOT transparent mode", select a CPU module that supports the GOT transparent mode (other than "Remote I/O" and "Q12DCCPU-V").

7 - 2 7 - 2

It	em	Description		
PLC	Туре	Select a connection type between GOT1000 series and the programmable controller when using the GOT transparent mode. [For QD75 projects] This item can be set when "via GOT transparent mode" is selected. "Direct coupled" or "Bus" can be selected. When "Serial communication" is set for programmable controller side interface, the connection type between GOT1000 series and serial communication module is fixed to "Direct coupled". [For LD75/LD77 projects] The connection type between GOT1000 series and the programmable controller is fixed to "Direct coupled".		
I/O adr.		Set the I/O address (start I/O number) of the positioning module to be accessed in hexadecimal.		
Wait time		Set the time-out period until when the positioning module accepts a request from GX Configurator-QP. When time-out occurs, the operating axes all stop.		
Timeout time		Set the suspension time of communication judged as a communication error.		
Comm. test		Whether the access target CPU module set in the Connection Setup dialog box can be communicated normally to the positioning module or not is tested. When normal communication can be made, the types of the positioning module and CPU module are displayed.		



- If you set the personal computer interfaces to the same COM port in GX Configurator-QP and GX Developer, set the baudrate to the same speed.
 If they are started at the same time, the baudrate set first has priority and the baudrate set later is ignored.
- If GX Configurator-QP is forced to end in the test mode, a time-out occurs due to the elapse of the wait time and the QD75/LD75/LD77 cancels the test mode.
- A communications error may occur if communications are made with the QCPU/LCPU after setting of any of the resume function, suspend setting, powersaving function and standby mode of the peripheral device. For this reason, do not set the above functions when communicating with the QD75/LD75/LD77.
- If the USB cable is disconnected/connected, the QCPU/LCPU is reset, or power is switched on/off frequently during communications with the QCPU/LCPU, a communications error may occur and the system may not recover from the error. Hence, place the system offline when disconnecting/connecting the USB cable, resetting the QCPU/LCPU, or switching power on/off. If the system does not recover from the communications error, completely disconnect the USB cable once and reconnect it after more than 5 seconds has elapsed. (An error may occur at the initial communications after this operation, but the system will function properly from the second time onwards.)
- A communication error may occur depending on the combination of the personal computer model, USB cable and so on.
 In that case, refer to the message displayed and perform operation again.
- If the baudrate is changed at the serial port of the personal computer (personal computer interface) to perform fast communication, communications may not be made or a communications delay may occur due to a communications retry depending on the performance of the personal computer.
 If communications cannot be made for fast communication, reduce the baudrate and restart communication.
- If "Multiple PLC specification" is set for the "PLC No. 2", "PLC No. 3" or "PLC No. 4" in the PLC side setting, that setting is made valid only when the QD75 of function version "B" or later is used. To confirm the function version of the QD75, refer to "Section 7.3 Checking the Positioning Module Function Version (OS Information)".

REMARK

When the programmable controller interface is "Serial communication" (Serial communication module), the serial communication module switches must be set on the PLC parameter I/O assignment setting screen of GX Developer.

Refer to GX Developer Operating Manual, for the way to make settings in the I/O assignment setting screen.

For details more information on the switch settings, refer to user's manual of the serial communication module used.

Switch setting examples are listed below.

Item	Desc	Setting	
Switch 1	CH1 communication speed	CH1 transmission setting	0726H
Switch 2	-	CH1 communications protocol	0008H
Switch 3	CH2 communication speed	CH2 transmission setting	0727H
Switch 4	-	CH2 communications protocol	0000H
Switch 5	Module sta	0000H	

Detailed description of settings

ltem	Setting
Operation setting	Independent setting
Data bit setting	8
Parity bit yes/no setting	Yes
Odd/even parity bit	Odd
Stop bit setting	1
Sum check yes/no setting	Yes
Online change enable/disable setting	Enable
Setting change enable/disable setting	Disable
Transmission speed setting	19200bps
Communications protocol	For Q corresponding serial communication module: Connecting GX Developer
	For L corresponding serial communication module: MELSOFT Connection

7.1.1 Setting for connection via GOT (GOT transparent mode)



PURPOSE


This section explains how to set GX Configurator-QP connected to the QCPU/LCPU or serial communication module by the GOT transparent mode. For cables connected to GOT, settings and precautions for GOT, refer to the GOT1000 Series Connection Manual (Mitsubishi Products).



BASIC OPERATION


(1) System configuration example

The following system configuration example shows the setting method. For system configuration in which the GOT transparent mode can be used, refer to Section 2.1.




(2) Setting method

After connecting GOT and the personal computer, and GOT and the programmable controller, set the GOT transparent mode in the [Connection setup] screen by the following procedure.



1) Choose [Online] → [Connection setup].

2) Choose "USB" in "Interface" of "PC".



- Choose "PLC" in "Interface" of "PLC" and "Q06UDH" in "PLC type".
 (When connecting to a serial communication module, choose "Serial communication" in "Interface" of "PLC".)
- Select "via GOT transparent mode". (The setting of "Interface" of "PC" may be changed by the "Interface" setting of "PLC". In this case, set "Interface" of "PC" again.)
- 5) Choose "Direct coupled" in "Type". (Choose "Bus" in "Type" when connecting the QCPU and GOT in bus connection. When connecting to the LCPU or a serial communication module, "Type" is fixed to "Direct coupled".)

7.2 System Monitor



PURPOSE

Check the module configuration, I/O address, Module type and Module axis status of the station (system) connected.

(Note that this function is not available for LD75/LD77 projects.)




BASIC OPERATION

- 1. Set the connection target. (Refer to Section 7.1.)
- 2. Click the [Tool] → [System monitor] menu.
- 3. The QD75 on the connected station appears in the System monitor dialog box.
- 4. Click the QD75 illustration and check the I/O address, CPU management, Module type and Module axis status.
- 5. To exit, click the "Close" button.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description	
System monitor	Shows the connection target programmable controller system. Clicking the QD75 illustration shows the module information.	
Module information	Shows the I/O address, CPU management, module type and module axis statuses.	
"Update" button	Click this button to show the latest system information.	

7 - 8 7 - 8

7.3 Checking the Positioning Module Function Version (OS Information)



PURPOSE

Depending on the function version of the positioning module, this software may not be compatible with some functions. (Refer to Appendix 2.)

Before setting various data, check the function version (product information) of the positioning module with the setting software.




BASIC OPERATION

- 1. Specify the connection target. (Refer to Section 7.1.)
- 2. Click the [Online] \rightarrow [OS information] menu.
- 3. Check the function version in the OS information dialog box.
- 4. To exit, click the "Close" button.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description		
Connected type	Indicates the model of the connected QD75/LD75/LD77.		
Product information	Indicates the function version of the connected QD75/LD75/LD77. The function version "B" is displayed on the above display/setting screen.		

7 - 9 7 - 9

7.4 Checking Connect



PURPOSE


Make sure that the cables between the QD75P/QD75D/LD75 and servo amplifiers or external devices, and between servo motors and servo amplifiers are connected

(Note that this function is not available for the QD75M/QD75MH/LD77.)



BASIC OPERATION

- 1. Power on the positioning control system and STOP the programmable controller CPU.
- 2. Set the connection target. (Refer to Section 7.1.)
- 3. Choose Checking connect.



- 4. Click the "Online" button in the Checking connect window.
- 5. The online processing (test mode shift) confirmation dialog box appears. Click the "Initialize" button to check connection after initializing the QD75/LD75. Click "OK" to check connection without initializing the QD75/LD75.
- 6. Make sure that the external I/O signals are in the following states.

Drive unit ready, Upper limit, Lower limit: ON (red)


Stop signal: OFF (gray)

If any of the above states is not established, refer to "HELPFUL OPERATION (1)" and "HELPFUL CORRECTIVE ACTIONS" in this section.

- 7. Check whether the following signals from the external devices are ON or OFF. Stop signal, External command.
- 8. Set the JOG speed.
- 9. Press the "FWD" or "REV" button to start JOG operation. Hold down the button to continue JOG operation.
- 10. Perform JOG operation and check the operation, rotation direction and feed speed of the servo motor.
- 11. Perform JOG operation and check whether Zero phase and DOG signals turn on or off.
- 12. Perform JOG operation and check whether the upper and lower limit switches
 - Refer to "HELPFUL OPERATION (2)" in this section for the way to restore an axis stop due to OFF of the upper/lower limit switch.
- 13. When an error has occurred, check the error code definition with the help function (refer to Section 11.10), then click [Online] \rightarrow [Test] \rightarrow [Error reset] \rightarrow [Error reset #1 to #4] menu (to 1.).
- 14. To exit, click the "Offline" button, and click the "OK" button in the test mode end confirmation dialog box.

7 - 10 7 - 10

DISPLAY/SETTING SCREEN



DISPLAY/SETTING DATA

Item	Description	
Operation monitor	Indicates the current feed value, feed speed, error No. and warning No. of each axis.	
JOG speed	Set the speed for JOG operation.	
JOG direction	Press the "FWD" or "RVS" button of the axis for JOG operation to start JOG operation.	
External input output signal	Indicates the external I/O signal states (ON: Red, OFF: Gray) of the QD75/LD75.	
"Offline" button	Click this button to end the QD75/LD75 test mode and end Checking connect.	
"Online" button	Click this button to start the QD75/LD75 test mode and execute Checking connect.	

7 - 11 7 - 11



HELPFUL OPERATION (1)

Perform the following operation if the I/O logic states of the drive unit ready, upper/lower limit switch and stop signal are different from the initial settings (negative logic).

- 1. In the extended parameters, set the logic signals in which the following states are established during normal operation. (Refer to Section 8.1.) Drive unit ready, upper limit, lower limit: ON Stop signal: OFF
- 2. Write the parameters to the QD75/LD75. (Refer to Section 9.1.)
- 3. Perform steps 1 to 5 in the basic operation of this section.
- 4. Click the "No" button in the Move online dialog box.
- 5. The operation steps to be performed hereafter are the same as steps 7 to 14 in the basic operation of this section.



HELPFUL OPERATION (2)

Perform the following operation to restart the axis which was brought to an alarm stop as the upper/lower limit switch had turned OFF during JOG operation.

- 1. Click [Online] \rightarrow [Test] \rightarrow [Error reset] \rightarrow [Error reset #1 to #4] menu ($\boxed{\Phi}$ to $\boxed{\Phi}$).
- 2. Perform JOG operation to move the axis to within the upper or lower limit range.



+ HELPFUL CORRECTIVE ACTIONS

Take the following corrective actions when Checking connect cannot be completed properly.

Status	Corrective Action		
Chaoking connect connect	Check the connection of cables with the QD75/LD75.		
Checking connect cannot start	In Connection setup, check whether the interface, PLC type and other settings are correct.		
Start	(Refer to Section 7.1.)		
Drive unit ready signal is	Check that the servo amplifier is powered on.		
Drive unit ready signal is OFF	Check the connection of the external I/O signal connector.		
OFF	Change the extended parameter I/O logic.		
Unner/lesses limit eignelie	Check the connection of the external I/O signal connector.		
Upper/lower limit signal is OFF	Check for contact of the upper/lower limit switch.		
OFF	Change the extended parameter I/O logic.		
	Check the connection of the external I/O signal connector.		
Stop signal is ON	Check the status of the stop switch.		
	Change the extended parameter I/O logic.		
JOG operation cannot be			
performed.	Check that JOG speed setting is not "0".		
Error/warning occurred	Check the error/warning code using the help function, and remove the cause.		

7 - 12 7 - 12

8. DATA SETTING

Set the parameters, servo parameters, positioning data and block start data to be written to the QD75/LD75/LD77, and check the setting ranges and matching of the data using the simulation or error check function.

Write the preset parameters, servo parameters, positioning data and block start data to the QD75/LD75/LD77 before starting positioning operation.

Refer to Section 9.1 for the operation to write the data to the QD75/LD75/LD77.

8.1 Parameter Setting

Set the parameters necessary to exercise positioning control.

For parameter settings, refer to the user's manual for the positioning module used.



PURPOSE

There are the following four parameter types.

- · Basic parameters
- Extended parameters
- OPR basic parameters
- OPR extended parameters

The basic and extended parameters are divided into parameters 1 needed for system start and parameters 2 optimized according to the connected external devices and control.



BASIC OPERATION


1. Choose Parameter.



2. Make setting in the parameter edit window.



DISPLAY/SETTING SCREEN



Q

Double-click the cell and make setting in the text box or list box.

In the text box, you can set the maximum value/minimum value/default value with the right-click menu.


Right-click a cell and select "Calculate electric gear" to display the calculation result of movement amount per pulse used for electric gear function.

For the electric gear function and movement amount per pulse, refer to the user's manual for the positioning module used.

When performing operation from the keyboard, enter the value and press the "Enter" key to determine the value.

In the list box which shows the set value and set data (example 3:pulse), pressing the "space" key displays a list.

Make selection with the " \uparrow " or " \downarrow " key, and press the "Enter" key to determine the value.





• In the parameter edit window, the indications have the following meanings.

Blue characters : Default (initial value) setting

Black characters : Setting other than default (no error)

Red : Setting range error

• Since changing the unit setting changes the setting range, any setting other than the default (black characters) may result in a setting range error.

After changing the unit setting, execute an error check to confirm the setting.

• "Speed-position function selection" in "Extended parameter 1" can be set when the QD75 of function version "B" or later, LD75, or LD77 is used.

To confirm the function version of the QD75/LD75/LD77, refer to "Section 7.3 Checking the Positioning Module Function Version (OS Information)".

Q

8.2 Servo Parameter Setting



PURPOSE

Set the servo parameters to be transferred from the QD75M, QD75MH and LD77 to the servo amplifiers via the SSCNET (Servo System Controller NETwork) or SSCNETIII.

For servo parameters, the following four types are available.

- <QD75M>
- Servo basic parameters
- · Servo regulation parameters
- Servo extended parameters
- · Servo extended parameters 2
- <QD75MH/LD77>
- · Servo amplifier series
- Basic setting parameters
- Gain/filter parameters
- Extension setting parameters
- I/O setting parameters
- Extended control parameters
- · Special setting parameters

For settings, refer to the instruction manuals of the servo amplifiers and servo motors used.



BASIC OPERATION

1. Choose Servo Parameter.



2. Make setting in the parameter edit window.



DISPLAY/SETTING SCREEN

[Servo parameter setting screen (QD75M)]

Kind	Item	Axis #2	Axis #3	-
	Servo series	3:MR-J2S-B	3:MR-J2S-B	
	Amplifier setting	0:Used in incremental system	0:Used in incremental system	0
	Regenerative brake option	0:Not used	0:Not used	
	External dynamic brake	0:No	0:No	
Servo basic parameter	Motor type	80:Automatic setting	80:Automatic setting	8
parameter	Motor capacity	0	0	
	Servo motor speed	1 x1000r/min	1 x1000r/min	
	Feedback pulse	255:Depending on the motor resolution pulses.	255:Depending on the motor resolution pulses.	25 mot
	Rotation direction	0:Forward(CCW) with the increase of address.		0 the
	Auto tuning	1:Auto tuning mode 1	1:Auto tuning mode 1	1:


[Servo parameter setting screen (QD75MH/LD77)]

Kind		Item	Avie #1	Avis #2
Servo amplifier series	Servo amplifier series		1:MRJ3-8	4:MR-J3-B Linear
	Control mode	Control mode selection	0:Semi closed loop system	4:Linear control mode
	Regenerative brake option	Selection of regenerative brake option	00: Regenerative brake option is not used	00: Regenerative brake option is not used
	Absolute position detection system	Selection of absolute position detection system	0.Used in incremental system	0:Used in incremental system
	Function selection A-1	Servo forced stop selection	0:Valid (Use the forced stop signal.)	0:Valid (Use the forced stop signal.)
Basic	Auto turning	Gain adjustment mode setting	1:Auto tuning mode 1	1:Auto tuning mode 1
setting parameters	Auto tuning response		12:37.0Hz	12:37.0Hz
	In-position range		100 pulse	100 pulse
	Rotation direction selection (Moving direction selection)		B:Forward rotation (CCW) with the increase of the positioning address.	0:Positive direction with the increase of the positioning address
	Encoder output pulse		4000 pulse/rev	4000
	Encoder output pulse 2		0	0
Gain/filter parameters	Adaptive tuning mode (Adaptive filter II)	Filter tuning mode selection	0:Filter OFF	0:Filter OFF
	Vibration suppression control filter turing mode (Advanced vibration suppression control)	Vibration suppression control tuning mode	0.Vibration suppression control OFF	0:Vibration suppression control OFF
	Feed forward gain		0%	0%

Double-click the cell and make setting in the text box or list box.

Right-click on each text box and select the maximum, minimum, or default value from the pop-up menu. (When one servo amplifier is selected for QD75MH/LD77, the applicable default setting values are automatically determined.)

When one servo amplifier series is selected, a warning message appears on the screen. If the "Yes" button is selected, the applicable default setting values for each servo amplifier series can be determined automatically. If the "No" button is selected, the change of the servo amplifier series is cancelled.




Set "Auto tuning response" of QD75MH/LD77 by moving the slider from the auto tuning response dialog box.



When performing operation from the keyboard, enter the value and press the "Enter" key to determine the value.

In the list box which shows the set value and set data (example 3:pulse), pressing the "space" key displays a list.

Make selection with the " \uparrow " or " \downarrow " key, and press the "Enter" key to determine the value.





• In the parameter edit window, the indications have the following meanings.

Blue characters : Default (initial value) setting

Black characters : Setting other than default (no error)

Red : Setting range error

The default (initial) values set in the change of the servo amplifier series are displayed in black.

- When the servo amplifier series is set to "Not used", communication with the servo amplifier does not start. Always select the servo amplifier to be used.
- Since changing the unit setting changes the setting range, any setting other than
 the default (black characters) may result in a setting range error.
 After changing the unit setting, execute an error check to confirm the setting.
- For GX Configurator-QP version 2.18U or later, the initial value for "Servo response" has been changed from "0005" to "0002".

The parameter setting items and setting values of QD75M have been added to GX Configurator-QP Version 2.13P or later. (Refer to Appendix 3)

The following table indicates operations that will be performed if the project created on GX Configurator-QP Version 2.13P or later is opened on GX Configurator-QP Version 2.12N or earlier.

Туре	Item	Setting (Set Value)	Operation Performed when Project Is Opened using GX Configurator- QP earlier than Version 2.12N	Action
Servo parameter (for MR-J2S-B)	Regenerative brake option	For version 2.13P to 2.17T, "B: MR-RB31", "C: MR-RB51" For version 2.18U or later, "00: Not used" "01: FR-RC, FR-BU" "05: MR-RB32", "06: MR-RB34" "07: MR-RB54", "08: MR-RB30" "09: MR-RB50", "0B: MR-RB31" "0C: MR-RB51", "0E: Standard + fan" "10: MR-RB51", "0E: Standard + fan" "10: MR-RB032", "11: MR-RB12" "12: MR-RB14", "13: MR-RB5E" "14: MR-RB5E + fan", "15: MR-RB67" "16: MR-RB67 + fan", "17: MR-RB9F" "18: MR-RB9F + fan", "80: MR-RB3H-4" "81: MR-RB5H-4", "82: MR-RB3G-4" "83: MR-RB5G-4", "84: MR-RB34-4" "85: MR-RB54-4", "86: MR-RB1L-4" "87: MR-RB3L-4"	Cell (table) is shown red (outside the setting range). Error check results in error.	Since the setting is retained, it can be saved or written as-is.
Servo parameter (for MR-J2S-B)	Zeroing condition setting selection	"0: It is necessary to pass through one Z-phase after power on." "1: There is no need to pass through one Z-phase after power on."	Not displayed	Since the setting is retained, it can be saved or written as-is.

The defaults (initial values) are displayed if the project created using GX Configurator-QP earlier than Version 2.12N is opened using GX Configurator-QP Version 2.13P or later.

8.3 Positioning Data Setting

This section describes the positioning data setting, the addition of circular interpolation control to the positioning data by specifying a sub point, and speed setting using the axis speed calculation function.

This section also explains the M code comment setting in which the M codes assigned to the positioning data are annotated with comments.

8.3.1 Positioning data



PURPOSE

Set the positioning data such as the operation pattern, control method, SLV axis, acceleration time No., deceleration time No., address and command speed. For details on positioning data, refer to the user's manual for the positioning module used.



BASIC OPERATION

1. Choose the axis to which the positioning data will be set.



2. Set the data in the positioning data edit window.



DISPLAY/SETTING SCREEN

## Samp	# Sample01 / QD75D4 / Positioning data Axis #1 (I/O : 0)							
No.	Pattern	CTRL method	SLV axis	ACC(ms)	DEC(ms)	Positioning address [pls]	Arc Address [pls]	
1	2:LOCUS	A:ABS line2	Axis #2	0;1000	0;1000	964	0	
2	2:LOCUS	D:ABS ArcMP	Axis #2	3;1500	3;1500	964	979	
3	0:END	A:ABS line2	Axis #2	0;1000	0;1000	0	0	
4								
5								
6								
7								
8								
9								
10								
11	1:CONT	1:ABS line1	-	2;1200	3;1500	2000	0	
12	1:CONT	1:ABS line1	-	2;1200	3;1500	3000	0	
13	0:END	1:ABS line1	-	2;1200	3;1500	0	0	
14								-1
1	•							

Double-click the cell and make setting in the text box or list box. For "SLV axis", choose it from the SLV axis set dialog box when the control method is 2-axis interpolation control.



When performing operation from the keyboard, enter the value and press the "Enter" key to determine the value.

For "Pattern', "CTRL method", "ACC" and "DEC", press the "space" key to display a list. Make selection with the " \uparrow " or " \downarrow " key, and press the "Enter" key to determine the value.



DISPLAY/SETTING DATA

Item	Description						
	Indicates the No. of the positioning data.						
N.	The positioning data that can be ranges from No. 1 to 600.						
No.	However, No. 1 to 100 are displayed in the initial setting.						
	To change the display range, use the option function (refer to Section 11.5).						
	Choose the operation pattern for positioning control.						
D-#	The selection range is 0 to 2.						
Pattern	0: END (End command) 2: LOCUS (continue locus positioning control)						
	1: CONT (continue positioning control)						
	Choose the operation positioning control method from among 1 to 9 and A to Z.						
	1: ABS line 1 (Axis #1 Linear control (ABS))						
	2: INC line 1 (Axis #1 Linear control (INC))						
	3: Feed 1 (Axis #1 Fixed-feed control)						
	4: FWD V1 (Axis #1 Speed control (Forward))						
	5: RVS V1 (Axis #1 Speed control (Reverse))						
	6: FWD V/P (Speed-Position switching control (Forward))						
	7: RVS V/P (Speed-Position switching control (Reverse))						
	8: FWD P/V (Position-Speed switching control (Forward))						
	9: RVS P/V (Position-Speed switching control (Reverse))						
	A: ABS line 2 (Axis #2 Linear interpolation control (ABS))						
	B: INC line 2 (Axis #2 Linear interpolation control (INC))						
	C: Feed 2 (Fixed-feed control by Axis #2 linear interpolation)						
	D: ABS ArcMP (Circular interpolation control with sub point specified (ABS))						
	E: INC ArcMP (Circular interpolation control with sub point specified (INC))						
	F: ABS ArcRGT (Circular interpolation control with center point specified (ABS/CW))						
	G: ABS ArcLFT (Circular interpolation control with center point specified (ABS/CCW))						
CTRL method	H: INC ArcRGT (Circular interpolation control with center point specified (INC/CW))						
CTAL Method	I: INC ArcLFT (Circular interpolation control with center point specified (INC/CCW))						
	J: FWD V2 (Axis #2 Speed control (Forward))						
	K: RVS V2 (Axis #2 Speed control (Reverse))						
	L: ABS line 3 (Axis #3 Linear interpolation control (ABS))						
	M: INC line 3 (Axis #3 Linear interpolation control (INC))						
	N: Feed 3 (Fixed-feed control by Axis #3 linear interpolation)						
	O: FWD V3 (Axis #3 Speed control (Forward))						
	P: RVS V3 (Axis #3 Speed control (Reverse))						
	Q: ABS line 4 (Axis #4 Linear interpolation (ABS))						
	R: INC line 4 (Axis #4 Linear interpolation (INC))						
	S: Feed 4 (Fixed-feed control by Axis #4 linear interpolation)						
	T: FWD V4 (Axis #4 Speed control (Forward))						
	U: RVS V4 (Axis #4 Speed control (Reverse))						
	V: NOP (NOP instruction)						
	W: Address CHG (Current value changing)						
	X: JUMP (JUMP instruction)						
	Y: LOOP (Declear the begining of LOOP to LEND section)						
	Z: LEND (Declear the end of LOOP to LEND section)						

8 - 7 8 - 7

Item	Description
SLV axis	Set the interpolation axis when the control method is linear interpolation control (2 axes) or circular interpolation control. Use the SLV axis set dialog box.
ACC DEC	Choose the ACC time or DEC time from among 0 to 3 and set in the basic parameters 2 and extended parameters 2.
Positioning address	Set the address for the absolute system or the travel distance for the incremental system. Set a new current value when the control method is an address change.
Arc Address	Set the address of the sub point or center point designated for circular interpolation control.
Command speed	Set the command speed for positioning. Set the command speed to "-1" to exercise control at the current speed.
Dwell time	 Control method is other than "JUMP" Set the delay time till the next positioning data completion in the range 0 to 65535ms. Control method is "JUMP" Set any position from No. 1 to 600 of the JUMP destination.
M code	 Control method is other than "JUMP" or "LOOP" Set the M code used to perform work, process, etc. in synchronization with positioning control in the range 1 to 65535. Control method is "JUMP" Set any of the condition data No. 1 to 10 which is used as the JUMP instruction execution condition. Setting of the condition data whose condition operator is "Simultaneously start axis set" is invalid. Set "0" to execute the JUMP instruction unconditionally. Control method is "LOOP" Set the repeat count within the range 1 to 65535.
Positioning comment	Assign a comment per positioning data. You can set a comment of up to 32 characters.



The colors of the cells (list) in the positioning data edit window have the following

meanings.

Yellow : Setting must not be made since the data is on the interpolation axis

side of interpolation control.


Red : Item needing setting is not yet set or is in error.

Gray : Setting need not be made (setting value is invalid).1)




HELPFUL OPERATION (1)

When you want to use a smooth arc (curve) on an intersection of two consecutive linear interpolation controls, you can perform the following operation to insert the circular interpolation control positioning data between the linear interpolation controls.



- 1. Open the positioning data edit window of the reference axis to which sub arc setting will be made.
- 2. Click the [Edit] → [Assistance arc] menu.
- 3. Set "Data" and "SubArc Radius" in the SubArc Setting dialog box.
- 4. Click the "Calculation" button.
- 5. The positioning data overwrite confirmation dialog box appears. Click the "OK" button.



- Open the positioning data edit window of axis 1 which is used as the reference axis.
- Click the [Edit] → [Assistance arc] menu.
- Set "1" to "Data" and "50" to "SubArc Radius".
- Click "OK" in the positioning data overwrite dialog box.
- The address of data No. 1 is changed and data No. 2 changes to circular interpolation control data. The original data of data No. 2 is set to data No. 3.



- Since the selected No. and next No. are overwritten by the positioning data created in sub arc setting, leave the next No. as NOP (empty).
- In either of the following cases, you cannot make sub arc setting. The control method is other than 2-axis linear interpolation control or fixeddistance feed 2.
- Positioning data setting is in error.

8 - 9 8 - 9




HELPFUL OPERATION (2)


Perform the following operation when you want to determine the command speed from the time needed to complete positioning. Use the axis speed calculation function to calculate the command speed from the travel distance, acceleration time, deceleration time, time needed for positioning completion and so on. (Note that the QD75M, QD75MH and LD77 cannot be used.)

- 1. Open the positioning data edit window of the corresponding axis. (Active status)
- 2. Click the [Edit] → [Speed of axis setting] menu.
- 3. Set the Rating, Feedback, Start position, End position, Operation interval and Data No. in the Axis speed calculation dialog box, and choose ACC interval and DEC interval.
- 4. Click the "Calculation" button to show the operation result in the Confirmation dialog box.
- 5. Click "OK" in the Confirmation dialog box to change the command speed to that of the operation result.

[Axis speed calculation dialog box]



[Confirmation dialog box]



8 - 10 8 - 10

Point

- Axis speed calculation is to be made for the control method of 1-axis linear control (ABS).
- If the axis speed calculated exceeds the speed limit value, setting it to the positioning data will result in an error.
- You cannot perform axis speed calculation if the set number of pulses output exceeds the performance of the QD75/LD75.

For QD75P1/P2/P4 and LD75P4 (open collector output type)

Number of output pulses ((rated speed) \times (number of feedback pulses) / 60) \leq 200kpps

For QD75D1/D2/D4 (differential driver output type)

Number of output pulses ((rated speed) \times (number of feedback pulses) / 60) \leq 1Mpps

For LD75P4 (differential driver output type)

Number of output pulses ((rated speed) \times (number of feedback pulses) / 60) \leq 4Mpps

8 - 11 8 - 11

8.3.2 M code comment



PURPOSE

Set comments to M codes which are required for control exercised in synchronization with positioning control.

M code comments are data which can be saved only in the personal computer. Up to 50 comments can be set for each axis.



BASIC OPERATION


1. Choose the positioning data of the axis to which the M code comments will be



- 2. Click the [Edit] \rightarrow [M code comment] menu.
- 3. Set the M code comments.
- 4. To exit, click the "OK" button in the M code comment dialog box.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description
M code	Set the M code No. to be commented.
Mandanamant	Set a comment of up to 32 characters.
M code comment	Up to 50 comments can be set for each axis.
"OK" button	Click this button to finish the setting.
"Delete" button	Click this button to delete the selected comment.

8 - 12 8 - 12

8.4 Simulation



PURPOSE

Execute simulation (virtual positioning) with the set positioning data to check the operation of the axis.

The axis speed is displayed as waveform data for 1-axis control or as locus data for 2-axis interpolation control.

You cannot perform simulation for 3-/4-axis interpolation control.



BASIC OPERATION

1. Open the positioning data edit window.





- 2. Click the [Edit] → [Simulation] menu.
- 3. Type the Positioning Start No. of positioning data in the simulation window.
- 4. Setting or changing the positioning data being simulated in the positioning data edit window shows the simulation result at the point of data input.
- 5. To exit, click the "Close" button.



DISPLAY/SETTING SCREEN

[Waveform data for 1-axis control]





[Locus data for 2-axis interpolation control]



DISPLAY/SETTING DATA

Item	Description
Positioning start No	Set the first positioning data No. from which simulation starts. Simulation is performed on the data from the specified No. to the "END" of the operation pattern.
Magnify	Used to enlarge or reduce the simulation result in the vertical and horizontal directions. Moving the side to the right enlarges the result.
"Fixed ratio" check box	Click the unchecked check box to enlarge/reduce the result in the vertical and horizontal directions by the same ratio.
Time/Speed (Wave data)	Shows the time and axis speed at the position clicked in the simulation result display.
#1 to #4 axis (Locus data)	Shows the coordinates at the position clicked in the simulation result display. In the screen example, the coordinates shown are those of Axis #1 used as the reference axis and Axis #2 used as the interpolation axis.
Simulation result	Shows the simulation result. Changing the positioning data also changes the simulation result in synchronization. For 2-axis interpolation control, the reference axis is in the horizontal direction and the interpolation axis is in the vertical direction. For 1-axis control, time is in the horizontal direction and the axis speed is in the vertical direction. Use the scroll bars to move the display area.


REMARK

In the locus data for circular interpolation control, lines may be broken due to a data processing error during drawing.



HELPFUL OPERATION

When you want to try the command speeds (Wave) or addresses (Locus) at the setting of the positioning data, you can set or change the positioning data while simultaneously checking the simulation result.



8.5 Block Start Data Setting

Set the block start data for controlling a positioning start and the condition data used as a condition for a special start.



The block start data is equivalent to the start block data of the AD75.

8.5.1 Block start data



PURPOSE

Specify the positioning data No. as a point, and set the block start data which sets the starting condition, execution order and execution count to each point.

You can set up to 50 points per block.

There are blocks No. 0 to 4 per axis.



BASIC OPERATION

1. Choose the block start data.



2. Make settings in the block start data edit window.



DISPLAY/SETTING SCREEN

Point No.	Pattern	Data No.	Special start	Param	Condition data
1	1:CONT	1	0:Normal start	0	
2	0:END	11	1:COND start	1	(800) = (100000)
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					

Double-click the cell and make settings in the text box or list box.

When performing operation from the keyboard, enter the value and press the "Enter" key to determine the value.

For "Pattern" and "Special start", press the "space" key to display a list. Make selection with the "↑" or "↓" key, and press the "Enter" key to determine the value.

8 - 16 8 - 16



DISPLAY/SETTING DATA

Item	Description					
Point No.	Shows the point numbers 1 to 50.					
Detter	Select whether positioning control is ended at the point where positioning was completed or					
Pattern	positioning control will be continued to the next point.					
Data Na	Set the positioning data No. specified at the point.					
Data No.	The setting range is positioning data No. 1 to 600.					
	Choose the type of positioning control start per point.					
	The selection range is 0 to 6.					
	0: Normal start					
	1: COND start					
Special start	2: Wait start					
Special start	3: SIMU start					
	4: FOR loop					
	5: FOR condition					
	6: NEXT start					
	For details on special start, refer to the user's manual for the positioning module used.					
	When you set a conditional start, wait start, simultaneous start or FOR condition in Special					
	start, set any of the condition data No. 1 to 10 as its condition. (Refer to Section 8.5.2.)					
Param	When you set FOR loop in Special start, set the repeat count.					
	The setting range is 0 to 255.					
	Setting "0" makes the repeat count limitless.					
	When you set a conditional start, wait start, simultaneous start or FOR condition in Special					
	start, the data of the parameter-set condition data No. appears.					
Condition data	Double-clicking opens the condition data edit dialog box.					
	When you set FOR loop in Special start, the "repeat count" appears.					
	Nothing appears when you set a normal start or NEXT start in Special start.					




HELPFUL OPERATION

The block start data to be edited defaults to block No. 0.

Perform the following operation to change the block to be edited to any of block No.

- 1. Open the block start data edit window.
- 2. Click the [View] \rightarrow [Select block start data no] menu.
- 3. Choose the block to be edited in the Block No. change dialog box, and click the "OK" button.



8 - 17 8 - 17

8.5.2 Condition data



PURPOSE

Set the condition data which will be the starting conditions of the conditional start, wait start, simultaneous start and FOR condition in the block start data.



BASIC OPERATION

1. Choose the block start data of the axis to which the condition data will be set.




- 2. Click the [Edit] \rightarrow [Condition data edit] menu.
- 3. Choose the data No. to be set in the Condition data list dialog box.
- 4. Click the "Edit" button in the Condition data list dialog box.
- 5. Choose the condition operator and condition identifier in the Condition data edit dialog box, and set the condition values.
- 6. Click the "OK" button in the Condition data edit dialog box.
- 7. To exit, click the "Close" button in the Condition data list dialog box.




DISPLAY/SETTING SCREEN

[Condition data list dialog box]



[Condition data edit dialog box]



8 - 18 8 - 18



DISPLAY/SETTING DATA

Item	Description					
No.	Shows the condition data No.					
Condition data	Shows the condition data set in the Condition data edit dialog box.					
"Edit" button	Click this button to display the Condition data edit dialog box.					
"Delete" button	Click this button to delete the condition data at the cursor.					
	Choose the type of the condition operator of the condition data.					
	• * *=P1					
	• * *!=P1					
	• * *<=P1					
	• * *=>P1					
	• P1<= * *<=P2					
Condition operator	• * *<=P1, P2<= * *					
	• Device=ON					
	Device=OFF					
	Simultaneously start axis set					
	** indicates the value stored in buffer memory.					
	P1 and P2 indicate parameters (values set as desired).					
	Device indicates the X/Y device.					
	Choose the object of the condition operator.					
	• If the condition operator is comparison between ** and P1 and/or P2					
	Choose the buffer memory size of 16 or 32 bits.					
Condition identifier	If the condition operator is device=ON/OFF					
	Choose the device type of X device or Y device.					
	• If the condition operator is simultaneously start, choose the axes to be started at the same					
	time.					
	Set the condition object to the condition operator.					
	• If the condition operator is comparison between ** and P1 and/or P2					
	Set the buffer memory address in **.					
Text box	Set to P1 and/or P2 the value of the size set in Condition identifier.					
TCAL BOX	If the condition operator is device=ON/OFF					
	Set the device name.					
	If the condition operator is simultaneously start					
	Set the positioning data No. of the axes to be started at the same time.					
"OK" button	By clicking this button, the settings appear in the Condition data list dialog box.					



HELPFUL OPERATION

When setting the condition data consecutively, click in the Condition data edit dialog box.

Since this causes the Condition data edit dialog box to be kept open if you click the "OK" button, you can edit the condition data by switching it to the Condition data list dialog box.

8 - 19 8 - 19

8.6 Error Check



PURPOSE

Execute an error check to check the set parameters, servo parameters, positioning data and block start data for mismatches and setting omissions.

For error check range, refer to the user's manual for the positioning module used.




BASIC OPERATION

- 1. Set the error-checked project as the active project on the project tree view. (Refer to Section 5.2.)
- 2. Click the [Tool] \rightarrow [Error check] menu.



DISPLAY/SETTING SCREEN






DISPLAY/SETTING DATA

Item	Description
Error check item	In the check box, set the data on which error check will be made.
"Check" button	Click this button to start error check.
"Jump" button	Click this button to show the error locations.
	When error check is completed, the number of errors and error locations appear.
Error check result	On the above screen, error locations are the command speed of axis #1 positioning data No.
	7 and the parameter at point No. 1 of axis #1 block No. 0.

8 - 20 8 - 20

9. WRITING TO/READING OF/VERIFICATION OF POSITIONING MODULE DATA

Perform write to module/read from module/verify module data, data write from QD75/LD75/LD77 buffer memory to flash ROM, and QD75/LD75/LD77 initialization.



9.1 Write to Module/Read from Module/Verify Module Data



PURPOSE

Write, read and verify the data set in the project (parameters, servo parameters, positioning data, block start data) on an axis by axis basis.



- Write to module executes a write to the QD75/LD75/LD77 which is set in the active project. When performing batch write to multiple QD75/LD75/LD77s, use the multimodule batch write function. (Refer to Section 11.1.4)
 - Note that data cannot be batch-written simultaneously to the positioning module of MELSEC-Q series and that of MELSEC-L series on the same route.
- Whether write to module may be performed or not is determined by the PLC state check setting in Option setting. (Refer to Section 11.5)
- When trying operation while simultaneously changing the positioning data, you can use the positioning data test edit function to write only the positioning data during a test. (Refer to Section 11.7.2)




BASIC OPERATION

- 1. Place the QCPU/LCPU in the STOP status. When performing write to QD75/LD75/LD77 without putting the QCPU/LCPU in the STOP status, change the PLC state check setting in Option setting.
- 2. As an active project, set the project used for write to QD75/LD75/LD77/read from QD75/LD75/LD77/verify QD75/LD75/LD77 data. Refer to Section 5.2 for the active project setting.
- 3. Click the [Online] → [Write to module] (| |)/[Read from module] (| |)/Verify module data] (🔠) menu.
- 4. Set the data type and range in the Write to module/ Read from module/Verify module data dialog box.
- 5. Click the "OK" button to start operation.
- 6. For module data verify, the verify result appears.

9 - 2 9 - 2

DISPLAY/SETTING SCREEN


<Write to module> <<Main>> tab screen



<Positioning data>> tab screen
Parameter data
Servo parameter data

Paramete	Servo pa	vo parameter data.			
Main	Positioning data			Block start data	
Current type	QD75M4	PLC type	Q02(H)	1/0 No.	20
		. —	1		600
Axis #1 Po	ositioning dat	g	- '	-	600
Axis #2 Po	ositioning dat	a	1		600
✓ Axis #3 Po	ositioning dat	a	1	-	600
Axis #4 Po	ositioning dat	a [1	-	600


<<Block start data>> tab screen




<<Parameter data>> tab screen



<<Servo parameter data>> tab screen



<Verify module data>
[Verify result dialog box]





DISPLAY/SETTING DATA

Item	Description				
Positioning data	Set the data used for write to QD75/LD75/LD77/read from QD75/LD75/LD77/verify				
Block start data	QD75/LD75/LD77 data from positioning data, block start data and parameters.				
Parameter	Block start data includes condition data.				
"Flash ROM write" check	When performing write to QD75/LD75/LD77, set a request to write from buffer memory to				
box	flash ROM at the same time.				
Current type	Set the model of the QD75/LD75/LD77 connected to the peripheral device and the range of write/read/verify.				
< <positioning data="">> tab</positioning>	Click the corresponding tab to display the screen which is used to set the axes and ranges of				
< <block data="" start="">> tab</block>	the data for write to QD75/LD75/LD77/read from QD75/LD75/LD77/verify QD75/LD75/LD77				
< <parameter data="">> tab</parameter>	data.				
«Desitioning data» tab	Set the axes of the positioning data used for write to QD75/LD75/LD77/read from				
< <positioning data="">> tab</positioning>	QD75/LD75/LD77/verify QD75/LD75/LD77 data.				
screen	Also, set the positioning data No.s in the write/read/verify range on an axis by axis basis.				
COROL start datass tab	Set the axes of the block start data used for write to QD75/LD75/LD77/read from				
< <block data="" start="">> tab</block>	QD75/LD75/LD77/verify QD75/LD75/LD77 data.				
screen	Also, set the range of the QD75/LD75/LD77 write/read/verify block on an axis basis.				
< <parameter data="">> tab</parameter>	Set the axes used for write to QD75/LD75/LD77/read from QD75/LD75/LD77/verify				
screen	QD75/LD75/LD77 data.				
< <servo data="" parameter="">></servo>	Set the axes used for write to QD75/LD75/LD77/read from QD75/LD75/LD77/verify				
tab screen	QD75/LD75/LD77 data				
O	Click this button to start write to QD75/LD75/LD77/read from QD75/LD75/LD77/verify				
"OK" button	QD75/LD75/LD77 data.				
	After QD75/LD75/LD77 data verify is completed, differences between the QD75/LD75/LD77				
	and project appear.				
	The screen displays that the speed limit value of the axis #1 basic parameter 2 and the				
Verify result dialog box	software stroke limit upper/lower limit value of the extended parameter 1 differ between the				
	QD75/LD75/LD77 and project.				
	If there are more than 100 mismatches, verify processing is suspended as soon as the				
	number of mismatches reaches 100.				



- Only data configured for setting items of GX Configurator-QP can be verified. GX Configurator-QP.
- The following data are saved in the peripheral device only and write to QD75/LD75/LD77/read from QD75/LD75/LD77/verify QD75/LD75/LD77 data cannot be performed.

M code comments

Positioning data comments

• Performing auto tuning on QD75MH/LD77 may change some servo parameters to auto tuning results, causing a verification error.

9.2 Servo Amplifier Data Read



PURPOSE

Read the servo parameters used in the servo amplifiers to the QD75M buffer memory.

(Note that they cannot be read in QD75P/QD75D/QD75MH/LD75/LD77 projects.)



The servo parameters read to the QD75M buffer memory are not written to the flash ROM. To write them to the flash ROM, write them to the flash ROM separately.



BASIC OPERATION

- Place the QCPU in the STOP status.
 When performing servo amplifier data read without putting the QCPU in the STOP status, change the PLC state check setting in Option setting.
- 2. On the project tree view, set the required project as an active project. (Refer to Section 5.2.)
- 3. Click the [Online] → [Servo amplifier data read] menu.
- 4. Click the "Action" button in the servo amplifier data read dialog box.

9.3 Flash ROM write request



PURPOSE

Issue the command to write the QD75/LD75/LD77 buffer memory data to the flash ROM.

Write from buffer memory to flash ROM is batch-performed in the full ranges of the parameters, servo parameters, positioning data and block start data (including condition data).



Whether the flash ROM request may be performed or not is determined by the PLC state check setting in Option setting. (Refer to Section 11.5)



BASIC OPERATION

- Place the QCPU/LCPU in the STOP status.
 When performing the flash ROM write request without putting the QCPU/LCPU in the STOP status, change the PLC state check setting in Option setting.
- 2. On the project tree view, set the required project as an active project. (Refer to Section 5.2)
- 3. Click the [Online] \rightarrow [Flash ROM request] menu.
- 4. Click the "Action" button in the Flash ROM request dialog box.
- 5. Click the "Yes" button in the execution confirmation dialog box.

9.4 Module Initialization



PURPOSE

When the system is renewed, for example, initialize the QD75/LD75/LD77 flash ROM and buffer memory to place them in the factory-set status (default settings).



Whether module initialization may be performed or not is determined by the PLC state check setting in Option setting. (Refer to Section 11.5)



BASIC OPERATION

- Place the QCPU/LCPU in the STOP status.
 When performing module initialization without putting the QCPU/LCPU in the STOP status, change the PLC state check setting in Option setting.
- 2. On the project tree view, set the required project as an active project. (Refer to Section 5.2)
- 3. Click the [Online] \rightarrow [Initialize module] menu.
- 4. Click the "Action" button in the Initialize module dialog box.
- 5. Click the "Yes" button in the execution confirmation dialog box.

10. POSITIONING DEBUGGING

Debug positioning operation by checking the parameters, positioning data and other data set to the QD75/LD75/LD77 for errors, monitoring the positioning operation, and performing various operation tests by positioning data test operation and JOG operation.



All axes stop if a communications error occurs, e.g. GX Configurator-QP is forced to end, the peripheral device is powered off, or the connection cable is disconnected, in the test mode.

In addition, the test mode of the QD75/LD75/LD77 is canceled after the wait time (set value \times 500ms) in Connection setup has elapsed.



HELPFUL OPERATION (PART 1)

If an error has occurred during monitoring or testing, perform the following operation.

- 1. Check the axis status using Operation monitor (refer to Section 10.2.2).
- 2. When the axis status indicated is error, click the "Message" button and check the error code and message.
- 3. For the error code, confirm the error cause and its corrective action using the error/warning help.
- 4. Click the [Online] \rightarrow [Test] \rightarrow [Error reset] \rightarrow [Error reset #1 to #4] menu (\blacksquare to **4**).
- 5. Remove the error cause according to the corrective action.



HELPFUL OPERATION (PART 2)

To turn off the M code during monitoring or testing, perform the following operation.

Click the [Online] \rightarrow [Test] \rightarrow [M code off] \rightarrow [M code off #1 to #4] menu (| \blacksquare | to



HELPFUL OPERATION (PART 3)

To stop all operating axes during monitoring or testing due to an external equipment fault, etc. perform the following operation.

Click the [Online] \rightarrow [Test] \rightarrow [All axis stop] menu ($| \bullet \bullet \rangle$).

10 - 1 10 - 1

10.1 Error Check Module Data



PURPOSE

Execute an error check on the parameters, servo parameters, positioning data and block start data stored in the buffer memory of the specified QD75/LD75/LD77.

For actions taken for check results, refer to the user's manual for the positioning module used.



BASIC OPERATION


- 1. Choose the [Online] \rightarrow [Error check module data] menu ($\stackrel{\square}{\mathbb{R}}$).
- 2. Operation differs depending on the target module of the active project.
 - For the QD75, connected QD75 is displayed in the System monitor dialog box. Clicking the corresponding QD75 illustration will open the Error check module data dialog box.
 - For the LD75 and LD77, the Error check module data dialog box for the target module of the active project will open.

Refer to Error Check (Section 8.6) for the operation that follows.


10 - 2 10 - 2

DISPLAY/SETTING SCREEN

[System monitor dialog box]



[Error check module data dialog box]



10.2 Monitor

Monitor the positioning data and block start data execution states on an axis by axis basis, or perform detailed monitor of the error histories, signal states, present values, speeds, etc. on a project basis.

10.2.1 Monitoring the positioning data/block start data




PURPOSE

From the positioning data/block start data edit window of any axis, monitor the positioning data No.s or block No.s and point No.s being executed.



BASIC OPERATION

1. Choose the positioning or block start data edit window.




- 2. Click the [Online] \rightarrow [Monitor] \rightarrow [Monitor On/Off] menu ($|\Omega|$).
- 3. To exit, click the [Online] \rightarrow [Monitor] \rightarrow [Monitor On/Off] menu ($|\mathbb{R}|$).





DISPLAY/SETTING SCREEN

[For positioning data monitor]





DISPLAY/SETTING DATA

Item	Description
Positioning data	For positioning data monitor, the positioning data in execution is highlighted.
monitor/block start data	For block start data monitor, the point in execution is highlighted.
monitor	

10 - 4 10 - 4

10.2.2 Operation monitor



PURPOSE

Monitor the feed present value, axis feed speed, axis status, positioning data No. executed last, error/warning code occurring currently, and M code of each axis. This monitor is used to confirm the basic axis states.



BASIC OPERATION

1. Choose Operation monitor.




- 2. Click the "Monitor start" button.
- 3. To exit, click the "Monitor stop" button.1. Choose Operation monitor.



DISPLAY/SETTING SCREEN


[Operation monitor dialog box]



[Comment dialog box]



[Error/Warning message dialog box]





DISPLAY/SETTING DATA

Item	Description
Title bar	Shows the project name and I/O address.
Feed present value	Indicates the feed present value.
	Buffer memory address (Axis #1): 800, 801
Axis feed speed	Indicates the feed speed.
	Buffer memory address (Axis #1): 812, 813
Axis status	Indicates the axis status.
	Buffer memory address (Axis #1): 809
	Indicates the positioning data No. in execution.
l No.	Note that if other than the positioning data No. is specified for operation, its starting number
No	is displayed.
	Buffer memory address (Axis #1): 835
D-#	Indicates the positioning data pattern in execution.
Pattern	Buffer memory address (Axis #1): 838
OTDI	Indicates the positioning data control method in execution.
CTRL method	Buffer memory address (Axis #1): 838
OLV	Shows the interpolation axis when the control method is 2-axis linear interpolation control or
SLV axis	circular interpolation control.
400	Indicates the acceleration and deceleration times selected in the positioning data in execution.
ACC	For the acceleration and deceleration times, refer to Parameter Setting (Section 8.1).
DEC	Buffer memory address (Axis #1): 838
	Shows the error and warning codes when an error and warning have occurred.
Error	"0" is displayed when no error/warning has occurred.
Warning	The error/warning codes can be confirmed in [Help].
	Buffer memory address (Axis #1/error): 806, Buffer memory address (Axis #1/warning): 807
M code	Indicates the M code of the positioning data in execution.
IVI Code	Buffer memory address (Axis #1): 808
"History" button	Click the corresponding button to display the history, signal, operation or servo monitor dialog
"Signal" button	box.
"#1 Operation status" button	The operation monitor dialog box appears per axis.
"#2 Operation status" button	Refer to Section 10.2.3 for history monitor.
"#3 Operation status" button	Refer to Section 10.2.4 for signal monitor.
"#4 Operation status" button	Refer to Section 10.2.5 for operation monitor.
"Servo monitor" button	Refer to Section 10.2.6 for servo monitor.
"Comment" button	Click this button to display the dialog box which shows the positioning data or M code
Comment batton	comments in execution.
"Message" button	Click this button at error occurrence to show the Error/Warning message dialog box.
"Monitor start" button	Click this button to start monitor.
"Monitor stop" button	Click this button to stop monitor.
Comment dialog box	Shows the positioning data or M code comments in execution.
Error/Warning message dialog box	Shows the error or warning which is occurring per axis.
	The error code and error name are in the top field.
	The warning code and error warning are in the bottom field.

10.2.3 History monitor



PURPOSE

Monitor the error, warning and start histories stored in the QD75/LD75/LD77 buffer memory during operation monitor.




BASIC OPERATION

- 1. Perform the basic operation in Section 10.2.2 to display the operation monitor window.
- 2. Click the "History" button on the operation monitor window.
- 3. Click the <<Error history>>/<<Warning history>>/<<Start history>> tab.




DISPLAY/SETTING SCREEN

[Error history monitor]



[Warning history monitor]






DISPLAY/SETTING DATA

Item	Description
Title bar	Shows the I/O address of the QD75/LD75/LD77 being monitored.
No	Represents the order of errors/warnings which occurred since power-on.
	If more than 16 errors/warnings occurred, the older ones are deleted.
Axis	Shows the axis where the error/warning occurred.
	Buffer memory address (newest error): 1293
	Buffer memory address (newest warning): 1358
Code	Shows the error/warning code.
	Buffer memory address (newest error): 1294
	Buffer memory address (newest warning): 1359
Time	Shows the error/warning occurrence time in hour:minute:second format.
	Buffer memory address (newest error): 1295, 1296
	Buffer memory address (newest warning): 1360, 1361
Message	Shows the error/warning name.

10 - 7 10 - 7

DISPLAY/SETTING SCREEN

[Start history monitor]



DISPLAY/SETTING DATA

Item	Description
Title bar	Shows the I/O address of the QD75/LD75/LD77 being monitored.
No	Represents the order of starts since power-on.
	If there are more than 16 starts, the older ones are deleted.
Axis	Indicates the axis started.
	Buffer memory address: 1212
	Indicates the start command destination.
044	The command destination is the programmable controller CPU, GX Configurator-QP or
Start	external signal.
	Buffer memory address: 1212
	Indicates the type of operation started.
Mode	The positioning data No. is displayed for operation which uses the positioning data.
	Buffer memory address: 1213
Time	Indicates the start occurrence time in hour:minute:second format.
	Buffer memory address: 1214, 1215
Result	Shows OK for a normal start.
	Shows the error code when an error occurs.
	The definition of the error code displayed can be confirmed by the help function.
	Buffer memory address: 1216

10.2.4 Signal monitor



PURPOSE

Monitor the I/O signals (X/Y device), external I/O signals and status signals of the QD75/LD75/LD77.

For details on the signals, refer to the user's manual for the positioning module used.





BASIC OPERATION

- 1. Perform the basic operation in Section 10.2.2 to display the operation monitor window.
- 2. Click the "Signal" button in the operation monitor window.
- 3. Click the <<X Device>>/<<P Device>>/<<External I/O signal>>/<<Status signal>>/<<Servo status signal>> tab.



DISPLAY/SETTING SCREEN





(Screen example: Screen displayed when the QD75M is chosen in model selection)



DISPLAY/SETTING DATA


Item	Description
Title bar	Shows the I/O address of the QD75/LD75/LD77 being monitored.
X Device	Displays the On/Off states of the QD75/LD75/LD77 input signals.
Y Device	Displays the On/Off states of the QD75/LD75/LD77 output signals.
	The Y device type depends on the model chosen in model selection.



Signal monitor for Pre-reading start function (Y14 to Y17: Axis # \square execution prohibition flags) is compatible with the QD75 of function version "B" or later. To confirm the function version of the QD75/LD75/LD77, refer to "Section 7.3 Checking the Positioning Module Function Version (OS Information)".

DISPLAY/SETTING SCREEN

[External I/O signal monitor]



(Screen example: Screen displayed when the QD75P or QD75D is chosen in model selection)




DISPLAY/SETTING DATA


Item	Description
Title bar	Shows the I/O address of the QD75/LD75/LD77 being monitored.
External I/O signal	Shows the On/Off states of the QD75/LD75/LD77 's external I/O signals.
	The displayed external I/O signal type depends on the model chosen in model selection.
	Buffer memory address (Axis #1): 816
Valid external command	Shows whether the start, V/P switch and P/V switch commands given by the external start
	signals are valid (●) or invalid (○).
	Buffer memory address (Axis #1): 1505

DISPLAY/SETTING SCREEN

[Status signal monitor]



[Servo status signal monitor]



(Screen example: Screen displayed when the QD75M is chosen in model selection)



DISPLAY/SETTING DATA

Item	Description
Title bar	Shows the I/O address of the QD75/LD75/LD77 being monitored.
Status signal	Shows the On/Off states of the QD75/LD75/LD77 's status signals.
	Buffer memory address (Axis #1): 817
Servo status signal	Shows the On/Off states of the QD75/LD75/LD77 's servo status signals.
	The servo status signals are displayed only when the QD75M/QD75MH/LD77 is chosen in
	model selection.
	Buffer memory address (Axis #1): 877 (QD75M)/876, 877 (QD75MH/LD77)

10.2.5 Axis operation monitor



PURPOSE

Monitor the settings, states and others of the axis control data, velocity/position control, position/velocity control, original point return and JOG/MPG operation during operation monitor.

With operation monitor, you can check the detailed states of operation and the QD75/LD75/LD77 settings made with the program or peripheral device.

For each monitor item, refer to the user's manual for the positioning module used.





BASIC OPERATION

- 1. Perform the basic operation in Section 10.2.2 to display the operation monitor window
- 2. Click the "<Axis #1 to #4> Operation" button in the operation monitor window.
- Click the <<Axis control data>>/<<Velocity/position
 control>>/<<Position/velocity control>>/<<OPR>>/<<JOG/MPG>> tab in the
 Operation dialog box.



DISPLAY/SETTING SCREEN





(Screen example: Axis #1 operation monitor screen displayed when the QD75M is chosen in model selection)




DISPLAY/SETTING DATA

Item	Description
Title bar	Shows the I/O address of the QD75/LD75/LD77 being monitored.
	Shows the destination for positioning control.
	For velocity/position switching control or position/velocity switching control, "0" is displayed
Target value	for velocity control and the destination appears for position control.
	"0" is shown for other operations.
	Buffer memory address (Axis #1): 818, 819
	Indicates the current position whose original point is the inherent position determined by the
Machine feed value	machine (mechanical coordinates).
Macrille leed value	On completion of OPR, this value indicates the original point address.
	Buffer memory address (Axis #1): 802, 803
	Shows the actual current value.
	The original point address is displayed at completion of OPR.
Actual current value	The actual current value is displayed only when the QD75M/QD75MH/LD77 is chosen in
	model selection.
	Buffer memory address (Axis #1): 850, 851
Current value changed	Shows the feed current value changed with the positioning start No. 9003.
value	Buffer memory address (Axis #1): 1506, 1507
Velocity change value	Shows the value of speed change made during positioning operation or JOG operation.
velocity change value	Buffer memory address (Axis #1): 1514, 1515
Over ride value	Indicates the override speed set in the program.
Over fide value	Buffer memory address (Axis #1): 1513
Step mode	Indicates the type of the step operation set in the program.
Otop mode	Buffer memory address (Axis #1): 1544
	Shows that the step operation set in the program is valid.
Step valid flag	● (ON) indicates that the step operation is valid.
	Buffer memory address (Axis #1): 1545
Velocity change flag	Shows ● (ON) during speed changing.
volocity change hag	Buffer memory address (Axis #1): 831
Velocity change 0 flag	Shows ● (ON) when the speed is changed to 0 for speed changing.
velocity change o mag	Buffer memory address (Axis #1): 817 (b10)
Valid external command	Shows that the external command signal set in the program is valid.
	● (ON) indicates that the start, velocity/position switching or position/velocity switching by
	the external command signal is valid.
	Buffer memory address (Axis #1): 1505
Skip command	Indicates the skip command given in the program.
	Shows ● (ON) when the skip command is given.
	Buffer memory address (Axis #1): 1547

10 - 14 10 - 14

[Velocity/position control monitor]




(Screen example: Axis #1 operation monitor screen)

DISPLAY/SETTING DATA

Item	Description				
	Indicates the target speed for positioning data, OPR or JOG operation.				
	For interpolation control, the composite speed or reference axis speed is displayed for the				
Target speed	reference axis and 0 appears for the interpolation axis.				
	Buffer memory address (Axis #1): 820, 821				
	Shows the speed of the axis operating actually in any operation.				
Food annual	For interpolation control, the composite speed or reference axis speed is displayed for the				
Feed speed	reference axis and 0 appears for the interpolation axis.				
	Buffer memory address (Axis #1): 804, 805				
	Indicates the current speed.				
	For interpolation control, the composite speed or reference axis speed is displayed for the				
Current speed	reference axis and 0 appears for the interpolation axis.				
	0 appears for JOG operation or MPG operation.				
	Buffer memory address (Axis #1): 810, 811				
Movement amount after	Indicates the travel distance under position control when velocity control is changed to				
velocity / position switching	position control during velocity/position switching control.				
ON	Buffer memory address (Axis #1): 814, 815				
Movement amount change	Indicates the value set to the velocity/position switching control travel correction register in				
	the program.				
register value	Buffer memory address (Axis #1): 1526, 1527				
	Indicates the velocity/position switching latch flag for the status signal. ● (ON) indicates that				
V/P switching latch flag	velocity control is switched to position control.				
	Buffer memory address (Axis #1): 817 (b1)				
	Indicates the velocity/position switching enable flag set in the program.				
V/P switching enable flag	 (ON) indicates that switching by the velocity/position switching signal is valid. 				
	Buffer memory address (Axis #1): 1528				
	Indicates the signal for differentiating between velocity control and position control.				
Velocity control flag	● (ON) during velocity control.				
	Buffer memory address (Axis #1): 817(b0)				

[Position/velocity control monitor]




(Screen example: Axis #1 operation monitor screen)



DISPLAY/SETTING DATA

Item	Description				
T	Indicates the target speed for positioning data, OPR or JOG operation.				
	For interpolation control, the composite speed or reference axis speed is displayed for the				
Target speed	reference axis and 0 appears for the interpolation axis.				
	Buffer memory address (Axis #1): 820, 821				
	Shows the speed of the axis actually operating in any operation.				
Feed speed	For interpolation control, the composite speed or reference axis speed is displayed for the				
r eeu speeu	reference axis and 0 appears for the interpolation axis.				
	Buffer memory address (Axis #1): 804, 805				
	For interpolation control, the composite speed or reference axis speed is displayed for the				
Current speed	reference axis and 0 appears for the interpolation axis.				
Current speed	0 appears for JOG operation or MPG operation.				
	Buffer memory address (Axis #1): 810, 811				
Position/velocity switching	Displays the contents of register which stores the position/velocity change control designated				
control command velocity	speed as set in the program.				
register value	Buffer memory address (Axis #1): 1530, 1531				
	Indicates the position/velocity switching latch flag for the status signal. ● (ON) indicates that				
P/V switching latch flag	position control is switched to velocity control.				
	Buffer memory address (Axis #1): 817 (b5)				
	Indicates the position/velocity switching enable flag set in the program.				
P/V switching enable flag	● (ON) indicates that switching by the position/velocity switching signal is valid.				
	Buffer memory address (Axis #1): 1532				
	Indicates the signal for differentiating between velocity control and position control.				
Velocity control flag	● (ON) during velocity control.				
	Buffer memory address (Axis #1): 817(b0)				

[OPR monitor]




(Screen example: Axis #1 operation monitor screen displayed when the QD75M is chosen in model selection)

DISPLAY/SETTING DATA

Item	Description				
Movement amount after near-point dog On	Indicates the travel distance of the axis during OPR from the position where the limit switch is turned on by the dog to the position where OPR is completed. Buffer memory address (Axis #1): 824, 825				
Torque limit storing value	Shows the torque limit setting or torque change value. Buffer memory address (Axis #1): 826				
OPR movement amount again	Indicates the movement amount when the axis is moved to the zero point by re-travel. This item is displayed only when the QD75M, QD75MH, or LD77 is selected in Select module type. Buffer memory address (Axis #1): 848, 849				
Command in-position flag OPR request flag OPR completed flag	Displays the status signals related to OPR. ●: ON ○: OFF Buffer memory address (Axis #1): 817 (b2 : Command in-position flag, b3 : OPR request flag, b4 : OPR completed flag)				
Lower limit Upper limit Zero phase signal Zeroing signal DDC signal	Shows the external I/O signals related to OPR. (The zero phase signal and DDC signal are displayed when the QD75P,QD75D or LD75 is selected in model selection.) ●: ON ○: OFF Buffer memory address (Axis #1): 816 (b0 : Lower limit, b1 : Upper limit, b5 : Zero phase signal, b6 : Zeroing signal, b8 : DDC signal)				

[JOG/MPG monitor]



(Screen example: Axis #1 operation monitor screen)

DISPLAY/SETTING DATA

Item	Description				
Foward JOG Reverse JOG	Indicates the direction during JOG operation in the program.				
JOG speed	Indicates the axis speed during JOG operation in the program. Buffer memory address (Axis #1): 1518, 1519				
JOG speed limit value	Indicates the JOG operation limit value set in the extended parameters 2. Buffer memory address (Axis #1): 48, 49				
JOG ACC time JOG DEC time	Shows the acceleration time and deceleration time set in the extended parameters 2. Buffer memory address (Axis #1): 50 (JOG ACC time), 51 (JOG DEC time)				
Enable/Disable	Shows if manual pulse operation is allowed or not. Permission setting in the test mode from the peripheral device is not displayed. Buffer memory address (Axis #1): 1524				
Manual pulse input mode	Shows the MPG pulse input mode set in the extended parameters 1. Buffer memory address (Axis #1): 33				
Indicates the factor per MPG output pulse set in the program is multiplied by to fir number of input pulses. Buffer memory address (Axis #1): 1522, 1523					

10.2.6 Servo monitor



PURPOSE

Monitor the servo status, torque control/servo load ratio, servo parameter setting contents and servo parameter error of the QD75M, QD75MH or LD77 during operation monitor.

With servo monitor, you can check the states and others of the servo amplifiers and servo motors connected to the QD75M, QD75MH or LD77.

For each monitor item, refer to the user's manual for the positioning module used and the instruction manuals of the servo amplifiers and servo motors used.




BASIC OPERATION

- 1. Perform the basic operation in Section 11.1.2 to display the operation monitor main screen.
- 2. Click the "Servo monitor" button on the operation monitor main screen.
- 3. Click the <<Servo status>> / <<Torque control/Servo load ratio>> / <<Servo parameter setting contents>> / << Servo parameter error>> tab in the servo monitor dialog box.



DISPLAY/SETTING SCREEN

[Servo status]



(Screen example: Axis #1 operation monitor screen displayed when the QD75M is chosen in model selection)

10 - 19 10 - 19




DISPLAY/SETTING DATA

Item	Description			
Martin and Community	Shows the servo motor speed. The unit is the number of revolutions per minute.			
Motor revolution number	Buffer memory address (Axis #1): 854, 855			
	Shows the movement amount of the servo motor. The unit is a movement amount per			
Motor movement amount	second. (For the MR-J3-B linear only)			
	Buffer memory address (Axis #1): 854, 855			
	Shows the value of current to the servo motor.			
Motor current value	Buffer memory address (Axis #1): 856			
	Shows the errors of the feed present value and actual present value in terms of the number			
Deviation counter value	of deviation counter pulses.			
	Buffer memory address (Axis #1): 852, 853			
	Shows the servo status signals.			
Servo status signals	●: ON ○: OFF			
	Buffer memory address (Axis #1): 877			



DISPLAY/SETTING SCREEN

[Torque control/Servo load ratio]



(Screen example: Axis #1 operation monitor screen displayed when the QD75M is chosen in model selection)



DISPLAY/SETTING DATA


Item	Description			
Torque control setting	Shows the torque limit value set in the extended parameter 1 (refer to Section 8.1).			
value	Buffer memory address (Axis #1): 26			
Torque output setting value	Shows the torque output value set in the program.			
	Buffer memory address (Axis #1): 1552			
Torque changed value	Shows the new torque value set in the program.			
	Buffer memory address (Axis #1): 1525			

Item	Description				
Torque control storing	Shows the torque limit value or new torque value valid for the running servo motor.				
value	Buffer memory address (Axis #1): 826				
	Shows the regenerative load factor relative the permissible value of the regenerative brake				
Revival load proportion	resistor selected in the servo basic parameter (refer to Section 8.2).				
	Buffer memory address (Axis #1): 878				
Execution load proportion	Shows the load factor relative to the rated torque.				
	Buffer memory address (Axis #1): 879				
Peak load proportion	Shows the peak load factor relative to the rated torque.				
	Buffer memory address (Axis #1): 880				




(1) QD75M

[Servo parameter setting contents]



(2) QD75MH/LD77

[Servo parameter setting contents]





DISPLAY/SETTING DATA

(1) QD75M


Item	Description					
Auto tuning Load inertia Position control gain1 Velocity control gain1 Position control gain2	Shows the auto tuning values set in the servo basic parameters (refer to Section 8.2) and the values of load inertia, each control gain and speed integral compensation set in the servo extended parameters (refer to Section8.2). When auto tuning is executed, the settings made according to the auto tuning results are					
Velocity control gain2 Integral speed compensation	displayed. Buffer memory address (Axis #1): 857, 858, 859, 860, 861, 862, 863					

(2) QD75MH/LD77

Item	Description
Auto tuning	
Ratio of load inertia moment (mass) to servo motor inertia moment	Shows the auto tuning mode set in the servo basic parameters (refer to Section 8.2) and the values for the ratio of load inertia moment (mass) to servo motor inertia moment, each control gain and integral speed compensation set in the gain/filter parameters (refer to
Model loop gain	Section 8.2). When guts tuning is executed, the settings made according to the guts tuning results are
Position control gain	When auto tuning is executed, the settings made according to the auto tuning results are displayed.
Velocity control gain	Buffer memory address (Axis #1): 30108, 30124, 30125, 30126, 30127, 30128
Integral speed compensation	

(1) QD75M

[Servo parameter error Monitor]



(2) QD75MH/LD77

[Servo parameter error Monitor]

Parameter No.	
8	Parameter name
8	Auto tuning
Axis #2	
Parameter No.	Parameter name
0	(Normal status)
	Parameter name
22	Feed forward gain
Axis #4	
Axis #4 Parameter No.	Parameter name



DISPLAY/SETTING DATA

(1) QD75M

Item	Description				
	Shows the servo parameter types and their error judgments. No. indicates the lower 2 digits of the buffer memory address where the Axis #1 servo parameters of the QD75M are stored.				
	No.	Code	Servo Parameter	QD75M Servo Parameter Storage Buffer Memory Address (Axis #1)	
	1	AMS	Amplifier setting	101	
	2	REG	Regenerative brake option	102	
Servo parameter error	3	MTY	Motor type	103	
Corvo parameter error	4	MCA	Motor capacity	104	
		•	•	•	
		•	•	•	
	•	•	•	•	
	Displays an error judgment per servo parameter item of each axis. On: Error Off: No error Buffer memory address (Axis #1): 870, 871, 872, 873, 874				

(2) QD75MH/LD77

Item	Description				
	For each axis, shows parameter No. and name of the servo parameter in which an error has occurred. Parameter No. is assigned in ascending order according to servo parameter No. of QD75MH.				
	Parameter	Servo Parameter			
	No.	No.	Parameter name.		
	1	PA01	Control mode		
	2	PA02	Regenerative brake option		
	3	PA03	Absolute position detection system		
	•	•	•		
Servo parameter error	•	•	•		
Corro parameter error	<u> </u>	•	•		
	18	PA18	For manufacturer setting		
	19	PB01	Adaptive tuning mode (Adaptive filter II)		
	•	•	•		
	•	•	•		
	•	•	•		
	For details on servo parameters, refer to the user's manual for the positioning module used and the instruction manuals of the servo amplifiers and servo motors used.				
	If there is no error, shows "0" for the parameter No. and "Normal state" for the parameter				
	name.				
	Buffer memory address (Axis #1): 870				

10 - 24 10 - 24

10.3 Sampling Monitor

Monitor the ON/OFF of any registered signals and the buffer memory values while simultaneously sampling them.

10.3.1 Sampling signal monitor



PURPOSE

You can monitor the ON/OFF of the specified X/Y devices, external I/O signals, status signals and servo status signals in the timing chart.



BASIC OPERATION

- 1. Choose Sampling monitor (signal).


 Monitor → Sampling monitor(Signal)

 Double-click.
- 2. Click the "Setup" button in the Sampling monitor (signal) window.
- 3. Set the signals in the Sampling monitor dialog box.
- 4. Click the [Online] \rightarrow [Monitor] \rightarrow [Monitor On/Off] menu (| |).
- 5. Check the monitor results.
- 6. To exit, click the [Online] \rightarrow [Monitor] \rightarrow [Monitor On/Off] menu ($|\mathbb{A}|$).



DISPLAY/SETTING SCREEN

[Sampling monitor (signal)]





[Sampling monitor dialog box]

DISPLAY/SETTING DATA

Item	Description		
"Setup" button	Click this button to display the Sampling monitor dialog box.		
	ON/OFF states are shown in the HIGH/LOW timing chart.		
Sampling monitor result	The sampling cycle time changes with the sampling interval.		
	The timing chart is enlarged or reduced according to the screen size.		
Sampling intervals	Choose the sampling intervals from among "50ms", "100ms", "250ms", "500ms", "750ms".		
Signal type	Choose the types of the sampled signals from the X Device, Y Device, EXT I/O signal, Status signal and Servo status signal.		
Signal item	Choose the signals to be sampled.		
"OK" button	Click this button to close the Sampling monitor dialog box and display the settings in the Sampling monitor (signal) window.		

10.3.2 Sampling buffer monitor



PURPOSE

You can monitor the buffer memory storage values of the specified QD75/LD75/LD77 as waveform data.




BASIC OPERATION

1. Choose Sampling monitor (Buffer).




- 2. Click the "Setup" button in the Sampling monitor (Buffer) window.
- 3. Set the buffer memory addresses, upper limit value and lower limit value in the Sampling Buffer area data setting dialog box.
- 4. Click the [Online] \rightarrow [Monitor] \rightarrow [Monitor On/Off] menu (
- 5. Check the monitor results.
- 6. To exit, click the [Online] \rightarrow [Monitor] \rightarrow [Monitor On/Off] menu ($| \Re |$).





10 - 27 10 - 27



[Sampling Buffer area data setting dialog box]



DISPLAY/SETTING DATA


Item	Description
"Setup" button	Click this button to display the Sampling Buffer area data setting dialog box.
	Shows the buffer memory values as waveform data.
Sampling monitor result	The sampling cycle time changes with the sampling interval.
	The waveform data are enlarged or reduced according to the screen size.
Sampling intervals	Choose the sampling intervals from among "50ms", "100ms", "250ms", "500ms", "750ms".
Buffer area data	Set the QD75/LD75/LD77 buffer memory addresses and device sizes to be sampled. Click the unchecked check box when monitoring double word data such as the feed present
	value and feed speed. The setting range is buffer memory addresses 800 to 1499. The setting range for double-word data is 800 to 1498, and only even addresses may be set.
Upper limit Lower limit	Set to 0 when not performing sampling. Set the upper and lower limit values to be displayed as waveform data. The waveform data near the upper limit value may not appear when the sampling screen is redisplayed by switching the windows, for example. In that case, set the upper limit value to a value larger than the sampled value, and also change the lower limit value to reduce the difference between the upper and lower limit values.
"OK" button Click this button to close the Sampling Buffer area data setting dialog box and of settings in the Sampling monitor (Buffer) window.	



HELPFUL OPERATION

If you do not know the buffer memory addresses of the QD75/LD75/LD77, you can set them by the following operation.

Right-click the text box in the Sampling Buffer area data setting dialog box. The buffer memory addresses and device sizes of the data selected from the right-click menu are set automatically.





If sampling is performed while "Double word" is set for "Buffer memory data", acquired data may be separated.

10.4 Test

Place the QD75/LD75/LD77 in the test mode during operation monitor, and test the positioning start, present value change, speed change, OPR, JOG or MPG operation. Each operation of the QD75P/QD75D/LD75 can be tested in the cableless mode using its module alone.



 Before performing the OPR, JOG operation, positioning data or other test in the test mode, read the manual carefully, fully ensure safety, and set the programmable controller CPU to STOP.

Incorrect operations can damage the machine or cause an accident.

(1) Test mode ON operation

Perform the following operation to place the QD75/LD75/LD77 in the test mode.

- Set the required project as the active project.
 Refer to Section 5.2 for the active project setting.
- 2. Click the [Online] \rightarrow [Test] \rightarrow [Test On/Off] menu (\square).
- Click the "Yes" button in the all displayed window closing confirmation dialog box.
- 4. Click unchecked "Agreement with Module data" in the following dialog box.



- 5. Choose Write or Read and click the "OK" button.

 Refer to Section 9.1 for writing to and reading from the positioning module.
- 6. Click the "OK" button in the test mode confirmation dialog box.
- 7. To exit from the test mode, click the [Online] \rightarrow [Test] \rightarrow [Test On/Off] menu($|\mathbb{T}|$).



- (1) When conducting a test in the cableless mode, you cannot perform start, velocity/position switching and position/velocity switching under the control of external input signals and OPR which requires near point dogs and zero phase signal.
 - Since the feed present value cannot be cleared by OPR, make the present value change test (refer to Section 10.4.2) to clear it.
- (2) If an error occurred due to cable disconnection during a test in the wiring-less mode, an attempt to shift to the test mode again after cable reconnection may display the dialog box "The module is already under TEST MODE." In this case, shift to the test mode after resetting the programmable controller CPU.
- (3) In the test mode, JOG or other operation may respond slower depending on the running condition of the personal computer.
 In such a case, take the following actions.
 - Close all applications except GX Configurator-QP so that they are not run concurrently.
 - Set the transmission speed to 38.4kbps or higher in Connection Setup (refer to Section 7.1).



HELPFUL OPERATION

Perform the following operation when you want to test the positioning data or block start data before installing external equipment such as the servo amplifiers and motors.

- 1. Click the [Online] \rightarrow [Test] \rightarrow [Cableless mode] menu.
- 2. Choose the test mode by performing the above operation.
- 3. The operation that will follow is the same as in the corresponding test. Refer to the corresponding pages.
- 4. To finish, exit from the test mode and click the [Online] \rightarrow [Test] \rightarrow [Cableless model menu.

10.4.1 Positioning start test



PURPOSE


Specify the positioning data No. or block start data point No. and perform test operation.



BASIC OPERATION

- 1. Put the QD75/LD75/LD77 in the test mode in accordance with Section 10.4 (1).
- 2. Click the [Online] → [Test] → [Operation test] → [Operation test #1 to #4] menu (| 🏂 | to | 🏂 |).
- 3. Click the <<Position start>> tab in the TEST MODE setting dialog box.
- 4. Make external command setting when enabling velocity/position switching or position/velocity switching under the control of external command signal.
- 5. Choose Start mode.
- 6. Set Data No. or Block start No. and multiple axis sync start data No. according to Start mode.
- 7. When using a step start to perform test operation, click the unchecked "Step Start" check box to choose the step start type.
- 8. Clicking the "Start" button starts test operation from the specified positioning data or point.
- 9. To exit, click the "Close" button.

10 - 32 10 - 32



DISPLAY/SETTING DATA

Item	Description		
Monitor item	Shows the axis status.		
	Choose the start mode of test operation. • Positioning start Test operation is started from the specified positioning data No.		
Start type	Block start Test operation is started from the specified block point No.		
	Multiple axis sync start Test operation is started from the positioning data No. specified per axis.		
Data No.	Set the positioning data No. for the positioning start mode.		
Block No.	Set the block No. for the block start mode.		
Point No.	et the point No. for the block start mode.		
Multiple axis sync start data No.	Set the positioning data No. to each axis for the multiple axis sync start mode.		
"EXT. command" button	Clicking this button shows the external command dialog box and allows you to set external command enable, velocity/position switching enable or position/velocity switching enable.		
"Continue" button	Click this button during step standby to make a step start from the next positioning data No.		
"Start" button	Click this button to start test operation from the preset positioning data No. or point No.		
"Re-start" button	Click this button during an axis stop to resume test operation from the stop position.		
"Break off" button	Click this button to suspend positioning control during test operation.		
"Skip" button	Click this button at a step start to skip over continuous positioning control or continuous locus control to the next positioning data. Skip is valid up to the positioning data next to the end of the operation pattern.		

Item	Description				
Step start request	When performing a step start, click the unchecked step start check box. When you made it valid, choose the step start type. • Data No. units Independently of the operation pattern, operation is started from the specified positioning data No., and is performed and brought to a step standby status per data. • Deceleration units When the operation pattern is continuous locus control, test operation is performed up to continuous positioning control or the last positioning data. Speed No.1 No.2 No.3 No.4 Time Continuous Continuous Continuous Continuous Continuous Continuous Deceleration unit step Data No. unit step After operation, axis is brought to standby.				
"All axis stop" button	Click this button to stop all axes.				
"Stop" button	Click this button to stop the axis. Clicking the "Re-start" button resumes test operation from the stop position.				
< <feed present="" value<br="">CHG>> tab <<speed chg="">> tab <<opr>> tab <<jog mpg="">> tab</jog></opr></speed></feed>	Click the tab to show the corresponding test screen. Present value change testRefer to Section 10.4.2. Speed change testRefer to Section 10.4.3. OPR testRefer to Section 10.4.4. JOG/MPG testRefer to Section 10.4.5.				

10.4.2 Present value change test



PURPOSE

Change the feed present value of the QD75/LD75/LD77 to the specified address.



BASIC OPERATION

- 1. Place the QD75/LD75/LD77 in the test mode in accordance with Section 10.4 (1).
- 2. Click the [Online] \rightarrow [Test] \rightarrow [Operation test] \rightarrow [Operation test #1 to #4] menu (\nearrow 1 to \nearrow 2).
- 3. Click the <<Feed present value CHG>> tab in the TEST MODE setting dialog box.
- 4. Type a new value in the text box and click the "Present value change" button.
- 5. To exit, click the "Close" button.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description
Monitor item	Shows the axis status.
Present value change	Set a new feed present value.
"Present value change" button	Click this button to change the present value.
"All axis stop" button	Click this button to stop all axes.
"Stop" button	Click this button to stop the axis.
< <position start="">> tab <<speed chg="">> tab <<opr>> tab <<jog mpg="">> tab</jog></opr></speed></position>	Click the tab to show the corresponding test screen. Positioning start testRefer to Section 10.4.1. Speed change testRefer to Section 10.4.3. OPR testRefer to Section 10.4.4. JOG/MPG testRefer to Section 10.4.5.

10.4.3 Speed change test



PURPOSE

Make a speed and/or acceleration/deceleration time change to the axis operating in the positioning start, OPR or JOG operation test to check the adequate speed and/or acceleration/deceleration time.




BASIC OPERATION

- Place the QD75/LD75/LD77 in the test mode in accordance with Section 10.4

 (1).
- 2. Click the [Online] \rightarrow [Test] \rightarrow [Operation test] \rightarrow [Operation test #1 to #4] menu (\nearrow 1 to \nearrow 1).
- 3. Perform positioning start test (refer to Section 10.4.1), OPR test (refer to Section 10.4.4) or JOG/MPG operation test (refer to Section 10.4.5) in the TEST MODE setting dialog box.
- 4. Click the <<Speed CHG>> tab in the TEST MODE setting dialog box.
- 5. When changing the acceleration/deceleration time, click the unchecked "ACC/DEC time set enable" check box and set the acceleration/deceleration time.
- 6. Make a speed change test on the running axis.
- 7. To exit, click the "Close" button.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description			
Monitor item	Shows the axis status.			
Speed CHG	Set a new speed to replace the command speed, OPR speed or JOG operation speed of running axis. The speed limit value is changed if the value is greater than the speed limit value set in be parameters 2.			
"REQ. present value change value" button	Click this button to change the speed.			
Speed override	Set the multiplying factor (%) of the speed overriding the command speed, OPR speed or JOG operation speed. Override also influences the new speed resulting from speed change. The override value once executed is valid during the test mode. The setting range is 1 to 300%.			
"REQ. speed override" button	Click this button to execute override. Clicking this button in the standby status of the axis makes the override speed valid at the next start. A speed change is also made when this button is clicked for the running axis.			
"ACC/DEC time set enable" check box	Used to set whether an acceleration/deceleration time change is enabled or disabled at a speed change. Click the unchecked check box to change the acceleration/deceleration time when a speed change is made.			
ACC time DEC time	Set the acceleration time and deceleration time to be changed as soon as a speed change is made. When "ACC/DEC time set enable" is disabled (not checked), the setting is invalid.			
"All axis stop" button	Click this button to stop all axes.			
"Stop" button	Click this button to stop the axis.			
< <position start="">> tab <<feed chg="" present="" value="">> tab <<opr>> tab <<jog mpg="">> tab</jog></opr></feed></position>	Click the tab to show the corresponding test screen. Positioning start testRefer to Section 10.4.1. Present value change testRefer to Section 10.4.2. OPR testRefer to Section 10.4.4. JOG/MPG testRefer to Section 10.4.5.			

10 - 37 10 - 37

10.4.4 OPR test



PURPOSE

Perform an OPR test to set up an original point and correct the preset OPR basic parameters and OPR extended parameters.




BASIC OPERATION

- 1. Place the QD75/LD75/LD77 in the test mode in accordance with Section 10.4 (1).
- 2. Click the [Online] \rightarrow [Test] \rightarrow [Operation test] \rightarrow [Operation test #1 to #4] menu (\nearrow).
- 3. Click the <<OPR>> tab in the TEST MODE setting dialog box.
- 4. Check the OPR method, OPR speed and Original point address.
- 5. Choose the OPR type and click the "REQ. OPR" button.
- 6. To exit, click the "Close" button.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description		
Monitor item	Shows the axis status.		
OPR type	Chose the type of a starting method used in the OPR test. • Machine OPR OPR is performed using the dog or zero phase signal depending on the OPR method. Performed when the original point is set up. • High speed OPR Operation of positioning to the original point is performed in the travel distance calculated from the mechanical feed distance and the original point address set to the OPR basic parameters after the original point has been set up.		
"REQ. OPR" button	Click this button to start OPR set for the OPR method.		
OPR method OPR speed OP address	Show the data set in the OPR basic parameters.		
"All axis stop" button	Click this button to stop all axes.		
"Stop" button	Click this button to stop the axis.		
< <position start="">> tab</position>	Click the tab to show the corresponding test screen.		
< <feed present="" td="" value<=""><td>Positioning start testRefer to Section 10.4.1.</td></feed>	Positioning start testRefer to Section 10.4.1.		
CHG>> tab	Present value change testRefer to Section 10.4.2.		
< <speed chg="">> tab</speed>	Speed change testRefer to Section 10.4.3.		
< <jog mpg="">> tab</jog>	JOG/MPG testRefer to Section 10.4.5.		



HELPFUL OPERATION

The following operation example is given for original point setup when the OPR method is the count type 2).

- 1. Perform steps 1 to 5 in BASIC OPERATION in this section to make an OPR test of the machine OPR type.
- 2. If there is a difference between the position of the original point set up in the OPR test and the expected position, perform JOG/MPG operation test(refer to Section 10.4.5) to correct the position.
- 3. Check the difference between the feed present value and original point address.
- 4. Make correction of the difference to "Travel distance after DOG" in the OPR extended parameters.

10 - 39 10 - 39

10.4.5 JOG/MPG operation test



PURPOSE

When debugging positioning control by JOG or MPG operation, you can conduct the following tests.

- · Forward/reverse direction checking
- Checking of the ON/OFF of the external input signals such as upper/lower limit switch, zero phase and dog signals
- Speed and acceleration/deceleration operation tests
- Measurement of backlash compensation by forward or reverse operation
- Measurement of accurate addresses and travel distances




BASIC OPERATION

- Place the QD75/LD75/LD77 in the test mode in accordance with Section 10.4 (1).
- 2. Click the [Online] \rightarrow [Test] \rightarrow [Operation test] \rightarrow [Operation test #1 to #4] menu (\nearrow 1 to \nearrow 2).
- 3. Click the <<JOG/MPG>> tab in the TEST MODE setting dialog box.
- 4. When performing JOG operation, set "1" or more for JOG velocity and "0" for Inching value, and press the "FWD JOG" or "RVS JOG" button.
- 5. When performing inching operation, set the inching travel value and press the "FWD JOG" or "RVS JOG" button.
- 6. When performing MPG operation, set the MPG input magnification, click unchecked MPG Enable flag, and use the manual pulse generator.
- 7. To exit, click the "Close" button.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description			
Monitor item	Shows the axis status.			
JOG speed	Set the speed for JOG operation. You cannot set any value beyond the JOG speed limit. JOG speed is ignored for inching operation.			
Inching movement amount	Set the movement amount for inching operation. Set "0" for JOG operation.			
"FWD JOG" button "RVS JOG" button	Set the mouse pointer to the required arrow and press the left button of the mouse or press the space key to start JOG operation. • When inching value is "1" or more Every time you press the button, the pulse equivalent to the inching value is output. Acceleration/deceleration processing is not performed. • When inching value is "0" Hold down the left button of the mouse or the space key to continue operation at the specified JOG speed. The movement amount increments by one unit (mm, degree, inch, pulse). When the axis motion direction is opposite, change the rotation direction setting in basic parameters 1.			
Manual pulse input	Set the multiplying factor per pulse input from the manual pulse generator for MPG			
magnification	operation.			
"MPG Enable flag" check box	Check this flag to enable MPG operation in the test mode.			
"All axis stop" button	Click this button to stop all axes.			
"Stop" button	Click this button to stop the axis.			
< <position start="">> tab</position>	Click the tab to show the corresponding test screen.			
< <feed present="" td="" value<=""><td colspan="3">Positioning start testRefer to Section 10.4.1.</td></feed>	Positioning start testRefer to Section 10.4.1.			
CHG>> tab	Present value change testRefer to Section 10.4.2.			
< <speed chg="">> tab</speed>	Speed change testRefer to Section 10.4.3.			
< <opr>> tab</opr>	OPR testRefer to Section 10.4.4.			



The inching value is at the given ratio of the JOG speed limit value, and an error will occur if it is greater than the value calculated by the following expression.

· Unit setting of "mm"

JOG speed limit value (mm/min) \times 0.00295 = inching value (μ m)

- Unit setting of "inch" or "degree"
 - JOG speed limit value (inch/min, degree/min) \times 0.0000295 = inching value (inch, degree)
- Unit setting of "pulse"
 - JOG speed limit value (pls) \times 0.00177 = inching value (pls)

10.5 Servo On/Off



PURPOSE

In the test mode of the QD75M, QD75MH or LD77 switch off the electromagnetic brake of the servo motor to coast the motor.



The following conditions must be satisfied to switch servo On/Off.

- <Servo On>
- The servo amplifier of the corresponding axis is in the ready On status and servo Off status.
- The corresponding axis is in other than the error occurrence/step error occurrence status.
- <Servo Off>
- The servo amplifier of the corresponding axis is in the servo Off status.
- The corresponding axis is in the standby/stop/step standby status.



🗒 BASIC OPERATION

- Choose the [Online] → [Test] → [Test On/Off] menu (□) to place the QD75M, QD75MH or LD77 in the test mode.
- 2. To put all axes in the servo Off status simultaneously, click the [Online] \rightarrow [Test] \rightarrow [All axis Servo On/Off] menu.
 - To switch servo Off axis-by-axis, click the [Online] \rightarrow [Test] \rightarrow [Tool] \rightarrow [#1 Servo Off command] / [#2 Servo Off command] / [#3 Servo Off command] / [#4 Servo Off command] menu.
- 3. To switch servo On, click the [Online] \rightarrow [Test] \rightarrow [All axis Servo On/Off] menu.

11. USEFUL FUNCTIONS

Out of the functions that can be performed on GX Configurator-QP, this chapter describes the functions and operations useful for project execution, positioning data setting, etc. and the functions which support settings.

This chapter also explains the teaching function which imports the feed present value to the address, the function which writes positioning data in the test mode, the function which prints project setting data, and the trace function which displays operation results as waveform/locus data.

11.1 Useful Functions for Projects

This section describes the functions and operations which are helpful for utilizing project data to create projects and for changing set data.

11.1.1 Verifying the project data



PURPOSE

Compare and verify the parameters, servo parameters, positioning data, block start data and condition data of the project set as the active project and the saved project.




BASIC OPERATION

- 1. Set the verify source project as the active project. (Refer to Section 5.2.)
- 2. Click the [Project] → [Verify Project] menu (🔠).
- 3. Choose the verify target project in the Verify project dialog box (1) and click the "Verify" button.
- 4. Set the types and ranges of the data to be verified in the Verify project dialog box (2).
- 5. Click the "OK" button.
- 6. Check the results in the Verify result dialog box.




DISPLAY/SETTING SCREEN

[Verify project dialog box (1)]




11 - 1 11 - 1

[Verify project dialog box (2)]



[Verify result dialog box]



DISPLAY/SETTING DATA

Item	Description		
Project name	Click the project name of the verify destination.		
Project save path	Shows the project save path of the verify destination.		
"Reference" button	Click this button to display the Project tree dialog box (refer to Section 6.1).		
"Verify" button	Click this button to show the Verify project dialog box (2).		
Verify project dialog box (2)	Set the types and ranges of the data to be verified.		
Verify result dialog box	Shows up to 100 different settings between the project set as the active project and the specified project. If the number of mismatches exceeds 100, verify processing is suspended as soon as the number of mismatches reaches 100.		

11.1.2 Changing the model after data setting



PURPOSE

Change the QD75 model after setting the parameters, positioning data or other

If you choose "New Project read to module" in New Project, the model is the same as the QD75 at the read destination. Therefore, when utilizing the data for the other model, change the QD75 model after completion of read.

(Note that a model cannot be changed in LD75 and LD77 projects, and cannot be changed to LD75 or LD77 in QD75 projects.)




BASIC OPERATION

- 1. Set the required project as the active project. (Refer to Section 5.2.) If in the monitor or test mode, choose the offline status.
- 2. Click the [Project] → [Change module type] menu.
- 3. To close the screen being displayed, click the "OK" button in the confirmation dialog box.
- 4. Choose a new model in the Select module type dialog box.
- 5. Click the "OK" button.



DISPLAY/SETTING SCREEN



11 - 3 11 - 3



DISPLAY/SETTING DATA

Item	Description
Select type	Choose the model (type with the exception of the axis number) of the QD75.
Select Axis	Choose the number of axes of the QD75.
"OK" button	Click this button to change the model.



- Note that the model of MELSEC-Q series positioning module cannot be changed to that of MELSEC-L series.
- Independent of the QD75 model selected for the project, all data that can be set in the edit mode are saved in the project.

In a new project whose number of axes is 1, the parameters, positioning data, block start data, etc. of undisplayed Axis 2 to Axis 4 are saved. (However, the data of Axis 2 to Axis 4 are initial values.)

When the project whose number of axes is 4 is saved after changing to a model for 1 or 2 axes, the data of Axis 3/Axis 4 is saved unchanged.

Therefore, the model can be changed without restriction on the model selected when a new project is created.

• Depending on the combination of QD75 models, data may not be converted as shown in the following table.

Conversion	Conversion destination			
source	QD75P	QD75D	QD75M	QD75MH
QD75P	0	0	\triangle	\triangle
QD75D	0	0	\triangle	\triangle
QD75M	\triangle	\triangle	0	•
QD75MH	\triangle	\triangle	A	0

- O: Conversion available
- \triangle : Conversion is available for positioning data and block start data only. As default values are set to parameters and servo parameters resetting is required.
- ▲: Conversion is available for positioning data, block start data and parameter only. As default values are set to servo parameters, resetting is required.

11.1.3 Intelligent function utility



PURPOSE

Make setting to read the following data automatically from the QD75/LD75/LD77 buffer memory to the QCPU/LCPU devices (e.g. data registers).

The set data are stored in the intelligent function module parameters of the GX Developer project.

- Feed present value
- Machine feed value
- Feed speed

- Error No.
- Warning No.
- Enable M code

Axis operating status

Auto refresh allows the above data of the QD75/LD75/LD77 to be imported to the QCPU/LCPU without creation of a program.



BASIC OPERATION

- 1. Set the required project as the active project. (Refer to Section 5.2.)
- 2. Click the [Tool] → [Intelligent function utility] menu.
- 3. Choose the target GX Developer project in the GX Developer project dialog box.
- 4. The intelligent function module utility starts.
- 5. Set Start I/O No., Package name and Module model name.
- 6. Click the "Auto refresh" button.
- 7. Assign the programmable controller CPU side devices to the auto refresh items in the Auto refresh setting dialog box.
- 8. Click the "End setup" button.
- 9. Click the "Exit" button in the Intelligent function module utility.
- 10. Click the "Yes" button in the intelligent function module parameter save confirmation dialog box.

The intelligent function module utility can be started to execute the auto refresh setting in GX Developer.

To start the intelligent function module utility in GX Developer, click [Tools] → [Intelligent function utility] menu → "Auto refresh" button.

Then, follow the above procedure of the basic operation from 5 to 10 to set the auto refresh.

11 - 5 11 - 5

🔲 D


DISPLAY/SETTING SCREEN

For starting the intelligent function module utility with GX Configurator-QP

[GX Configurator-QP screen]




[GX Developer project dialog box]





For starting the intelligent function module utility with GX Developer

[GX Developer screen]



[Intelligent function module utility]





[Intelligent function module utility]



DISPLAY/SETTING DATA

Item	Description		
Project save path	Choose the save destination of the GX Developer project to which auto refresh setting will be made.		
GX Developer project	Choose the GX Developer project to which auto refresh setting will be made.		
Start I/O No.	Set the first I/O No. (I/O address) of the QD75/LD75/LD77.		
Package name	Choose the positioning module.		
Module model name	Choose the model of the QD75/LD75/LD77.		
Intelligent function module parameter setting module	Shows the module to which the initial setting or auto refresh setting has been made in the intelligent function module utility.		
"Auto refresh" button	Click this button to show the auto refresh setting dialog box.		
"Delete" button	Click this button to make deletion from the intelligent function module parameter setting module.		
PLC side Device	Set the programmable controller side devices to be automatically refreshed for the QD75/LD75/LD77 items. Data is automatically refreshed between the set devices and QD75/LD75/LD77 buffer memory.		
"Make text file" button	Used to save the auto refresh settings as text data. Clicking this button shows the text file creation dialog box, where you set the save destination drive/path and file name.		
"End setup" button	Click this button to register the auto refresh setting and close the dialog box.		



- The PLC side devices set for auto refresh store the QD75/LD75/LD77 data. Do not store other values using a program (e.g. FROM and MOV instructions).
- Number of parameters that may be set on GX Configurator-QP
 The programmable controller CPU modules and MELSECNET/H network
 system's remote I/O station for use with installed intelligent function modules have
 restrictions on the number of parameters that may be set on GX Configurator.

Target of Installing Intelligent Function	Max. Number of Set Parameters	
Modules	Initial setting	Auto refresh setting
Q00J/Q00/Q01CPU	512	256
Q02/Q02H/Q06H/Q12H/Q25HCPU	512	256
Q02PH/Q06PH/Q12PH/Q25PHCPU	512	256
Q02UCPU	2048	1024
Q03UDCPU/Q04UDHCPU/Q06UDH/ Q13UDH/Q26UDH/Q03UDE/Q04UDEH/ Q06UDEH/Q13UDEH/Q26UDEHCPU	4096	2048
L02CPU	2048	1024
L26CPU-BT	4096	2048
MELSECNET/H remote I/O station	512	256


Hence, when multiple intelligent function modules are installed on the remote I/O station, set GX Configurator so that a total of the set parameters of all intelligent function modules does not exceed the maximum number of set parameters of the remote I/O station.

Calculate the total of the set parameters separately for the initial setting and auto refresh setting.

The number of parameters that may be set on GX Configurator-QP per module is as follows.

Target Module	Initial setting	Auto refresh setting
QD75P1, QD75D1, QD75M1, QD75MH1		7 (max. number of set parameters)
QD75P2, QD75D2, QD75M2, QD75MH2		14 (max. number of set parameters)
QD75P4, QD75D4, QD75M4, QD75MH4,		28 (max. number of set parameters)
LD75P4, LD75D4, LD77MH4		

Example) How to count the number of set parameters for auto refresh setting



This single line is counted as one parameter that has been set. A blank is counted out.

All setting items of this setting screen are added to the numbers of other intelligent function modules to calculate a sum total.

11.1.4 Multi module batch write



PURPOSE

Batch write to multiple QD75/LD75/LD77s.



- Note that data cannot be batch-written simultaneously to the positioning module of MELSEC-Q series and that of MELSEC-L series on the same route.
- Whether multi module batch write may be performed or not is determined by the PLC state check setting in Option setting. (Refer to Section 11.5)




BASIC OPERATION


- 1. Open all projects to be batch written.
- 2. Specify the connection target in each project. (Refer to Section 7.1.)
- 3. Click the [Online] \rightarrow [Writing of batch of multi module] menu.
- 4. Choose the write target project from the project list in the Writing multi module dialog box, and click the ">>Selected" button. (The dialog box for choosing the items to be written to the module appears.)
- 5. Set the types and ranges of the data to be written and click the "OK" button.
- 6. Repeat the above steps 4 to 5 for the projects to be batch written.
- 7. Click the "Write" button in the Writing multi module dialog box.



DISPLAY/SETTING SCREEN

[Writing multi module dialog box]







DISPLAY/SETTING DATA

Item	Description
Project list	Shows a list of the projects open in GX Configurator-QP.
Write selected project	Shows the projects for which multi module batch write will be performed. Make selection from the project list.
">>Selected" button	Click this button to register the project selected on the project list side to the write selected project side and display for that project the dialog box for selecting the items to be written to the module.
"< <deleted" button<="" td=""><td>Click this button to return the project selected on the write selected project side to the project list side.</td></deleted">	Click this button to return the project selected on the write selected project side to the project list side.
"Set" button	Click this button to display the dialog box for selecting the items to be written to the module for the project selected on the write selected project side.
< <main>> <<positioning data="">> <<block data="" start="">> <<parameter data="">> <<servo data="" parameter="">> tab screen</servo></parameter></block></positioning></main>	Set the types and ranges of the data to be written to each project. The setting items are the same as in write to QD75/LD75/LD77. (Refer to Section 9.1.)
"Write" button	Click this button to batch write the projects registered as the write selected projects to the QD75/LD75/LD77.

11.2 Edit Functions for Data Setting

This section explains the edit functions which can be used for positioning data or block start data setting.


11.2.1 Cut/copy/paste

These functions cut/copy and paste some part of the positioning or block start data settings.

Also these functions cut/copy the values entered in Microsoft® Excel or Word table and pastes them to the positioning data or block start data of GX Configurator-QP.

(1) Cut

Used to cut the selected range.



- 1) Choose the area to be cut.
- Click the [Edit] → [Cut] menu ().
 Alternatively, click [Cut] in the right-click menu.
- Positioning address [pls] No. Pattern CTRL method SLV axis ACC(ms) DEC(ms) 1:CONT 1:ABS line1 0;1000 1;1500 1:CONT 1:ABS line1 3:800 2;1200 1;1500 1:CONT 1:ABS line1 0;1000 1:CONT 1:ABS line1 0;1000 1;1500 5 0:END 1:ABS line1 3;800 2;1200
- 3) The values in the selected range change to initial values.

(2) Copy

Used to copy the selected range to the clipboard of Microsoft® Windows® Operating System.


No.	Pattern	CTRL method	SLV axis	ACC(ms)	DEC(ms)	Positioning address [pls]	_
1	1:CONT	1:ABS line1	-	0;1000	1;1500	50000	
2	1:CONT	1:ABS line1	-	3;800	2;1200	100000	
3	1:CONT	1:ABS line1	-	0;1000	1;1500	70000	
4	1:CONT	1:ABS line1	-	0;1000	1;1500	150000	
5	0:END	1:ABS line1	-	3;800	2;1200	0	
6							J.,
41						1	. 🗆


- 1) Choose the area to be copied.
- 2) Click the [Edit] \rightarrow [Copy] menu (). Alternatively, click [Copy] in the right-click menu.

(3) Paste

Used to paste the cut or copied data to the selected range. Note that paste may not be made if:

- The control method is not set to the data of paste destination;
- The data of cut or copy destination is different in control method from the data of paste destination; or
- The item cut or copied is different from the item of paste destination.






- 1) Choose the paste destination (copy destination) of the data cut (copied).
- Click the [Edit] → [Paste] menu ().
 Alternatively, click [Paste] in the right-click menu.
- 3) The values in the selected range change to the cut (copied) data.


(4) Copying and pasting from Microsoft® Excel/Word table

Used to copy values entered into the Microsoft® Excel/Word table and paste them to positioning data or block start data of GX Configurator-QP.

[Example of copying Microsoft® Excel data and pasting them to positioning data]



 Choose and copy the Excel table.



2) Choose the setting range in the positioning data and click the [Edit]


→ [Paste] menu (ⓐ).




HELPFUL OPERATION (1)

When making the same setting for multiple positioning data or block start data, perform the following operation to make batch setting in the selected range. Note that batch setting may be made for the same item (column) only. It cannot be made if you selected multiple items (columns).


1) Choose the batch setting range.



2) Entering the value from the keyboard sets it on the top row of the selected range.



3) Press the Enter key on the keyboard or click the other items with the mouse to change the other rows of the selected range to the same setting.



11 - 13 11 - 13




HELPFUL OPERATION (2)

Perform the following operation to cut/copy and paste all ranges of the positioning data or block start data displayed.

1. Click the [Edit] \rightarrow [Select all] menu.

[Result of clicking [Select all] in the positioning data edit window]





- When "data No. 1 to data No. 100" has been selected in the data No. setting of the GX Configurator-QP option function, positioning data No. 101 to No. 600 are not included in the selection range.
- For the block start data, only the block to be edited is the selection range
- If data do not match between the axes, data of all ranges cannot be pasted. In that case, perform the axis copy (refer to Section 11.3.1).

11.2.2 Jump



PURPOSE

Move the cursor to the data No. specified for a positioning data edit window. Alternatively, move the cursor to the point No. specified in the block start data edit window.




BASIC OPERATION

- 1. Click the [Edit] → [Jump] menu.
- 2. Set the positioning data No. or block start data point No. of the jump destination in the JUMP dialog box.
- 3. Click the "OK" button.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description
Jump data No.	Set the positioning data No. or the block start data point No. of the jump destination.
"OK" button	Click this button to move the cursor to the specified No.

11.2.3 Clearing the rows/columns



PURPOSE

Clear only the rows or columns selected in the positioning data window or block start data edit window.



BASIC OPERATION

- 1. Choose the rows (columns) which you want to initialize in the positioning data or block start data edit window.
- Click the [Edit] → [Clear row]/[Clear column] menu.
 Alternatively, click the [Clear row]/[Clear column] menu in the right-click menu.

	[Example of clearing the rows]								
### Sam	ple1 / QD7	5D4 / Positioning	data Axis	#1 (I/O : I	0)		_ □	×	
No.	Pattern	CTRL method	SLV axis	ACC(ms)	DEC(ms)		ositioning dress [pls]	À	
1	1:CONT	1:ABS line1	-	0;1000	0;1000		40000	_	
2	1:CONT	1:ABS line1	-	0;1000	0;1000		20000		
3	1:CONT	1:ABS line1	-	0;1000	0;1000		5000		
4									
5									
6									
7	1:CONT	1:ABS line1	-	0;1000	0;1000	4	25000		
8	1:CONT	1:ABS line1	-	0;1000	0;1000		45000		
9	1:CONT	1:ABS line1	-	0;1000	0;1000		30000		
10	1:CONT	1:ABS line1	-	0;1000	0;1000		0	٠I	
1		1	1	1	1		Þ	1/1.	

The selected rows are cleared (to the default values).

[Example of clearing the columns]

No.	Pattern	CTRL method	SLV axis	ACC(ms)	DEC(ms)	Positioning address [pls]
1	1:CONT	1:ABS line1	-	0;1000	0;1000	0
2	1:CONT	1:ABS line1	-	0;1000	0;1000	0
3	1:CONT	1:ABS line1	-	0;1000	0;1000	0
4	1:CONT	1:ABS line1	-	0;1000	0;1000	0
5	1:CONT	1:ABS line1	-	0;1000	0;1000	0
6	1:CONT	1:ABS line1	-	0;1000	0;1000	0
7	1:CONT	1:ABS line1	-	0;1000	0;1000	0
8	1:CONT	1:ABS line1	-	0;1000	0;1000	0
9	1:CONT	1:ABS line1	-	0;1000	0;1000	0
10	1:CONT	1:ABS line1	-	0;1000	0;1000	0

The selected columns are cleared (to the default values).

11.2.4 Initializing the data



PURPOSE

Initialize the parameters, servo parameters, positioning data and block start data (including condition data) of the active project axis-by-axis.

Note that the project data saved in the QD75/LD75/LD77, HD and FD are not initialized.




BASIC OPERATION

- 1. Set the project to be initialized as the active project. (Refer to Section 5.2.)
- 2. Click the [Tool] → [Initialize data] menu.
- 3. Set the types and axes of the data to be initialized in the Data initialize dialog box.
- 4. Click the "OK" button.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description
Positioning data	Set the axes of the positioning data to be initialized. Check "ALL" to initialize the positioning data of all axes.
Block start data	Set the axes of the block start data to be initialized. Check "ALL" to initialize the block start data of all axes.
Parameter data	Set the axes of the parameters to be initialized. Check "ALL" to initialize the parameter data of all axes.
Servo parameter data	Set the axes of the parameters to be initialized. Check "ALL" to initialize the servo parameter data of all axes.
"OK" button	Click this button to initialize the data.

11 - 17 11 - 17

11.3 Copying the Data

Copy the positioning data, block start data, parameters and servo parameters, set to the project axis-by-axis.

Also, copy the set block start data to another block.

When copying data to another project, use copy/paste of the edit function. (Refer to Section 11.2.1.)

11.3.1 Copying the data on an axis basis (Axis copy)



PURPOSE

Using the axis copy function, copy the positioning data, block start data, parameters and servo parameters of any axis to another axis of the same project.



When the axis copy is performed, data may not match between the axes. After performing the axis copy, please carry out an error check (refer to Section 8.6).




🗒 BASIC OPERATION

- Display any of the parameters (refer to Section 8.1), servo parameters (refer to Section 8.2),positioning data (refer to Section 8.3) and block start data (refer to Section 8.5) edit windows.
- 2. Click the [Edit] \rightarrow [Axis copy] menu.
- 3. Set the axis of the copy source, the types of the data to be copied, and the axis of the copy destination.
- 4. Click the "OK" button.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description
Copy source data	Choose the axis of the copy source and set the data to be copied.
Copy destination	The block start data includes condition data. Set the axis of the copy destination.
"OK" button	Click this button to copy the data.

11.3.2 Block start copy



PURPOSE

Using the block start copy function, copy the block start data to the other blocks. The block start copy function is performed to copy data between blocks in the same project.




BASIC OPERATION

- 1. Display the block start data edit window (refer to Section 8.5).
- 2. Click the [Edit] → [Block start copy] menu.
- 3. Set the block No. of the copy source and the block No. of the copy destination.
- 4. Click the "OK" button.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description
Copy source block No.	Choose the copy axis and the block No. of the copy source.
Copy destination block No.	Set the copy axis and the block No. of the copy destination. Multiple blocks can be set at the same time.
"OK" button	Click this button to copy the data.

11 - 19 11 - 19

11.4 Navigation Function



PURPOSE

Perform the operations necessary to use the QD75P and QD75D, from setting of the parameters and positioning data to write to QD75P and QD75D, monitor and test in the wizard format.


(The navigation function is unavailable for the QD75M,QD75MH, LD75,and LD77.) For parameter settings, refer to the user's manual for the positioning module used.




BASIC OPERATION

- 1. Set the connection target. (Refer to Section 7.1.)
- 2. Click the [Tool] → [Navigation] menu.
- 3. When the Navigation function screen appears, perform operation using the following procedure.

If the QD75P and QD75D is not loaded, steps 4) to 10) cannot be executed.



- 1) Choose the model name.
- 2) Click the "Start" button.




3) Make setting on the parameter edit 1 screen. After setting, click the "Next>>" button.

Clicking the button shows the hint for the corresponding item.

Set each parameter.
(Screen is eliminated for simplicity)


(To the next page)

* To change the setting, click the "<<Back" button to return to the preceding screen.



(From the preceding page)


 Choose the axis in Change axis and set the positioning data.
 After setting, click the "Next>>" button.



5) Set I/O address

To write data to the flash ROM of the QD75P and QD75D at the same time, click unchecked "Write to flash ROM".


6) Click the "Write to QD75" button. When write is completed, click the "Next>>" button.



- 7) Click the "Monitor start" button.
- 8) Click the "Test start" button.

(To the next page)

(From the preceding page)



- 9) Set the positioning data No. in Start and click the "Start" button to start test operation. Use the "Stop", "Error reset" and/or "M code OFF" button as necessary.
- 10) When the test is over, click the "Test stop" button. After exiting from the test mode, click the "Next>>" button.



11) When saving the set parameters and positioning data, click the "Save as project" button. When not saving them, click the "End" button.



12) Click the "Yes" button to terminate the navigation function.

11.5 Option Setting



PURPOSE

Set the option function of GX Configurator-QP.

The option function is used to make settings for write to module and set the display range of positioning data.




BASIC OPERATION

- 1. Click the [Tool] \rightarrow [Option] menu.
- 2. Make settings in the Option settings dialog box.
- 3. To exit, click the "OK" button.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description								
Flash ROM write	Select whether data will be written to flash ROM or not in the initial setting for write to module. • YESChoose Yes to make the initial setting that data will be written to flash ROM when write to module is performed. • NOChoose No to make the initial setting that data will not be written to flash ROM when write to module is performed.								
Write data enable flag	When you check this check box, any changes in the test mode using positioning data test edit or teaching are retained after the end of the test mode. When you do not check this check box, data changes in the test mode are made invalid and return to the previous data at the end of the test mode.								
Positioning data set	Choose the range of the positioning data No. to be displayed on the positioning data edit window. • Data No. 1 to No. 100Shows positioning data No. 1 to 100. • RangeShows positioning data No. 1 to 600.								
	Make selection who module, multi module is executed. (Defauted Since the set data or basis, the selected of you do not choose (QD75/LD75/LD77	lle batch It is "cheo on the Op set value e PLC sta	write, fla cked") otion scre s apply t ate checl ignal) of	sh ROM een is sav o all proje c, write ca	write requived not or ects. annot be sponding	uest or Q n a project performe n module	D75/LD7 ct basis led when is ON.	75/LD77 ir out on an	nitialization
	PLC state	ST	OP	except	STOP	ST	OP	except	STOP
PLC state check	X0 status of corresponding module	ON	OFF	ON	OFF	ON	OFF	ON	OFF
	Write processing	× (Note 2)	0	× (Note 1)	× (Note 1)	× (Note 2)	0	× (Note 2)	0
NOVII by the r	Note 1 : "Please ma the option s Note 2 : "The QD75 QD75/LD7:	screen. " a 5/LD75/LD 5/LD77 RE	ppears. 77 READ` EADY sigr	Y signal is ial." appea	turned on	ove the ch	neck on th		e check on
"OK" button	Click this button to	aetermine	e tne set	data.					



When you increased the display range in positioning data display No. setting, it will take longer until the positioning data edit window appears.

When positioning data No. 101 onwards are not necessary, choose data No. 1 to No. 100. (The positioning data No. defaults to data No. 1 to No. 100.)

11.6 Printing the Project Data

Print the positioning data, block start data, parameters and servo parameters set in the project.

11.6.1 Printer setting



PURPOSE

Choose the printer connected to the peripheral device, paper and printing orientation.

For printer setting, refer to Microsoft® Windows® Operating System manual. Also, for the printer properties, refer to the printer manual as they depend on Microsoft® Windows® Operating System manual printer driver used.




BASIC OPERATION

- 1. Click the [Project] → [Printer setup] menu.
- 2. Set the printer, etc.
- 3. To exit, click the "OK" button.



DISPLAY/SETTING SCREEN



(The screen shows the setting for Windows® 95.)

11 - 25 11 - 25

11.6.2 Printing



PURPOSE

Print the positioning data, block start data (including condition data), parameter data and servo parameter data of the active project.




BASIC OPERATION

- 1. Set the project to be printed as the active project. (Refer to Section 5.2.)
- 2. Click the [Project] → [Print] menu ().
- 3. Set the axes and data types and ranges to be printed.
- 4. Click the "Print preview" button.
- 5. Clicking the "Print" button shows the Print dialog box.
- 6. Click the "OK" button in the Print dialog box to start printing.




DISPLAY/SETTING SCREEN


<< ltem specification>> tab screen




<<Block start data>> tab screen



<< Positioning data>> tab screen




<< Parameter data>> tab screen




11 - 26 11 - 26


<<Servo parameter data>> tab screen



(Screen example: Screen displayed when the QD75M is chosen in model selection)


[Print preview screen]





(Screen example: Screen displayed when the QD75MH/LD77 is chosen in model selection)

[Print dialog box]





DISPLAY/SETTING DATA

Item	Description						
Print project	Shows the project name to be printed.						
1 Till project	The project selected on the project tree view is to be printed.						
Axis specification	Set the axes whose data will be printed.						
Print data	Set the types of data to be printed.						
Positioning data No.	Set the printing ranges of positioning data.						
Positioning data No.	You can add positioning data and M code comments as additional information.						
Block start data No.	Set the printing range of block start data.						
BIOCK Start data No.	You can add condition data as added information.						
Parameter data	Set the parameter types to be printed.						
Servo parameter data	Set the servo parameter types to be printed.						
"Printer setting" button	Click this button to display the Print setting dialog box (refer to Section 11.6.1).						
"Print" button	Click this button to show the Print dialog.						
"Print preview" button	Click this button to display the Print preview.						
"Next Page" button	Click the corresponding button to preview the next or previous page.						
"Prev Page" button	Click the corresponding battor to preview the flext of previous page.						
"One Page/Two Page"	Click this button to switch the preview between 1 page display and 2 page display.						
button							
"Zoom In" button	Click the "Zoom In" button to enlarge the preview display.						
"Zoom Out" button	Click the "Zoom Out" button to reduce the preview display.						
Printer Name	Select the printer name.						
"Properties" button	Click this button to display the printer property dialog box.						
1 Toperties button	For the printer properties, refer to the printer manual.						
Print range	Set the range of printing.						
Copies	Set the number of copies printed.						
"OK" button	Click this button to start printing.						

[Positioning data print example]

				SLV						I	Dwell	
١o.	Pattern	CTRL	method	axis	ACC	DEC	Address	Arc	Address Speed	1	time M	cod
1	2:LOCUS	D:ABS	ArcMP	#2	0;1000	0;1000		0	250	1000	500	. 0
	Positi M code		commen ment	t [C∈	enter			1				
2	2:LOCUS	D:ABS	ArcMP	#2	0;1000	0;1000	10	000	500	1000	0	1
	Positi M code		comment		int1 int]				
3		com	ent	[Pa		0;1000]] 0	500	1000	500	. 0
3	M code	D:ABS	ArcMP	[Pa	int	0;1000		0 1	500	1000	500	. 0

11 - 28 11 - 28

[Block start data print example]

	Pattorn	Data No	Special start	Daram	Condition data
	1:CONT		1:COND start		(800) <= (99999)
	1:CONT		2:Wait start		(800) => (100000)
	1:CONT	20	3:SIMU start		Axis #2(No.50), Axis #3(No.60)
4	1:CONT	30	4:FOR loop	10	Repeat count
5	1:CONT	40	5:FOR condition	5	(800) = (15000)
6	0:END	50	6:NEXT start	0	
7	0:END	1	0:Normal start	0	
8	0:END	1	0:Normal start	0	
9	0:END	1	0:Normal start	0	
10	0:END	1	0:Normal start	0	

[Parameter print example]

Parameter name	Data set range	Data
OPR method	0:Zeroing DOE/4:Count#1/5:Count#2 6:Data set method	0
OPR direction	0:Forward direction (Address increase) 1:Beverse direction (Address decrease)	0
OP address	-2147483648 - 2147483647 pl;	0 pls
OPR speed	1 - 50000000 pls/s	1 pls/s
Creep speed	1 - 50000000 pls/s	1 pls/s

[Servo parameter print example]

Parameter name	Data set range	Data
Selection of regenerative brake option	00,01,02,03,04,05,06,08,03	00: Regenerative brake option is r ot used
Selection of absolute position detection system	0:Used in incremental system 1:Used in absolute position detection system	0
Output signal 3 function selection	0:Signal allocated by Output signal 3 function selection 1:Dynamic brake interlock	0
Servo forced stop selecti on	0:Valid (Use the forced stop signal.) 1:Invalid (Do not use the forced stop signal.)	0

11.7 Positioning Data Setting in Test Mode

In the test mode, import the feed address to the positioning data address and write changed positioning data to the QD75/LD75/LD77.

11.7.1 Teaching



PURPOSE

Enter the feed address of the axis moved by JOG or MPG operation into the address of the positioning data.



BASIC OPERATION


- 1. Click unchecked Write data enable flag in Option. (Refer to Section 11.5.)
- 2. Click the [Online] \rightarrow [Test] \rightarrow [Test On/Off] menu ($\boxed{ }$).
- 3. The positioning data edit window appears. (Refer to Section 8.3.1)
- 4. Clicking the [Online] \rightarrow [Test] \rightarrow [Teaching] menu ($\stackrel{\frown}{l}$) shows the feed address in the Teaching dialog box.
- 5. Click the [Online] \rightarrow [Test] \rightarrow [Operation test] \rightarrow [Operation test #1 to #4] menu (\nearrow to \nearrow).
- 6. Click the <<JOG/MPG>> tab in the TEST MODE setting dialog box.
- 7. Perform JOG or MPG operation to move the axis. (Refer to Section 10.4.5.)
- 8. Clicking the "Update" button in the Teaching dialog box displays the latest feed address.
- In the positioning data monitor window, choose the positioning data No. address or arc address where the feed address will be imported.
- Clicking the "Teaching" button enters the feed address to the positioning data No. address or arc address.
- 11. Repeat the basic operation steps 7 to 10 to continue teaching.
- 12. To end teaching, click the [Online] \rightarrow [Test] \rightarrow [Teaching] menu ($| \rightarrow$]).



If the Write data enable flag in Option is not made valid, the peripheral device does not retain the address set in the test mode.

Make the Write data enable flag invalid when you do not change the positioning data in the peripheral device.

DISPLAY/SETTING SCREEN



DISPLAY/SETTING DATA

Item	Description
Feed Address	Shows the feed address of the QD75/LD75/LD77.
"Update" button	Click this button to update the "feed address" to the latest feed address.
"Teaching" button	Click this button to enter the "feed address" into the cell selected in the positioning data edit window.
Positioning data edit	Screen used to perform teaching or positioning data test edit in the test mode.
window	Double-clicking the address or arc address influences the feed address.

11.7.2 Positioning data test edit



PURPOSE

Change the positioning data or block start data in the test mode and write them to the QD75/LD75/LD77.



BASIC OPERATION

- 1. Click unchecked Write data enable flag in Option. (Refer to Section 11.5.)
- 2. Click the [Online] \rightarrow [Test] \rightarrow [Test On/Off] menu (\square).
- 3. The positioning data/block start data edit window appears. (Refer to Section 8.3.1/Section 8.5.1.)
- 4. Click the [Online] \rightarrow [Test] \rightarrow [Edit positioning data] menu (\boxed{E}).
- 5. Edit the positioning data/block start data. (Refer to Section 8.3.1. / 8.5.1.)
- Clicking the [Online] → [Test] → [Edit positioning data] menu (]) shows the dialog box which confirms whether to write the edited data to the QD75/LD75/LD77 or not.
- 7. Click the "OK" button to write to the QD75/LD75/LD77 the positioning data or block start data changed in the test mode.
 When you click [Cancel], write to QD75/LD75/LD77 is not performed.




If the Write data enable flag in Option is not made valid, the data changed or set in the test mode are not retained.

Make the Write data enable flag invalid when you do not change the positioning data on the peripheral device.



DISPLAY/SETTING SCREEN



The data changed in the test mode are shown in green letters.

11.8 Wave Trace

Using the wave trace function in the trace mode, show the speed command (axis speed) for positioning operation as waveform data.

(Note that the QD75M, QD75MH and LD77 cannot be used.)

11.8.1 Wave trace condition setting



PURPOSE

To execute the wave trace, set the trace starting condition and the data to be traced.



BASIC OPERATION


1. Choose Wave trace.



- 2. Click the "Setting" button in the wave trace window.
- 3. Set the Trace interval, Trace trigger, Stop condition, axis and data to be traced in the Trace setting dialog box.
- 4. Click the "OK" button in the Trace setting dialog box.
- 5. For the tracing operation that follows, refer to Section 11.8.2.



DISPLAY/SETTING SCREEN



DISPLAY/SETTING DATA

Item	Description
	[For QD75P and QD75D projects]
Trace interval	Set the trace interval within the range 1 to 256.
	The interval is the set value $ imes$ 1.77ms.
	[For LD75 projects]
	Set the trace interval within the range 1 to 512.
	The interval is the set value $ imes$ 0.88ms.
	Choose the actual trace starting condition.
	No condition
Trigger condition	Trace starts at the start request of the peripheral device.
Trigger condition	Wait start
	Trace actually starts when the start signal (X10/X11/X12/X13) turns on after the start
	request from the peripheral device.
	Choose the trace stopping condition.
	Buffer full
	Trace stops when the trace data area becomes full.
	• Endless
	Trace stops at the stop request of the peripheral device.
Trace stop mode	Error stop
Trace stop mode	Trace stops when an error occurs.
	Trace point
	[For QD75P and QD75D projects]
	Trace stops when the number of trace points reaches the specified value (1 to 8192).
	[For LD75 projects]
	Trace stops when the number of trace points reaches the specified value (1 to 16384).
Data 1	
Data 2	Represents the trace data No.
Data 3	represents the trace data No.
Data 4	
Axis selection	Choose the axis whose data will be traced.
	Choose the data type to be traced.
Trace data	Command speed
Trace uala	Waveform data of the feed speed from the QD75P, QD75D and LD75 to the servo
	amplifier.
"OK" button	Click this button to close the Trace setting dialog box and display the axis number and data
OK" DUTTON	type in the wave trace window.

11 - 34 11 - 34

11.8.2 Wave trace execution



PURPOSE

Execute wave trace after setting the trace conditions in accordance with Section 11.8.1.




BASIC OPERATION

- 1. Perform the basic operation in Section 11.8.1 to set the trace conditions.
- 2. Click the "Trace" button to initialize trace.
- 3. When initialization is completed, click the "Start" button in the dialog box.
- 4. The trace data is read when the trace stop type condition is satisfied or the "Stop" button is clicked.
- 5. Check the QD75P, QD75D and LD75 control results from the displayed trace results.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description
Maximum value Minimum value	Show the maximum and minimum values during tracing of each data.
Time	Shows the tracing time.
Waveform data	Shows the trace results. The horizontal axis indicates time. The vertical axis represents the value of the traced data. Use the scroll bars to move the display position.
Horizontal Vertical	Show the display multiplying factor of the waveform data. Move to the right to enlarge or to the left to reduce.
Preserve aspect	Check this check box to make the waveform data display multiplying factor equal in the vertical and horizontal directions.
Trace data	Shows the axes and data types set in the Trace setting dialog box.
"Trace" button	Click this button to initialize trace. On completion of initialization, the "Start" button in the dialog box is made valid. Clicking the "Start" button gives a trace start request to the QD75P, QD75D and LD75. If the trigger condition is "No condition", trace starts. If the trigger condition is other than "No condition", trace actually starts when the trigger condition holds.
"Stop" button	Click this button to stop trace and show the trace results. If the stop condition is Buffer full, Error stop or Trace point, clicking the "Stop" button stops trace and shows the trace results available at that point.
"Default" button	Click this button to update the display to the latest trace data.
"Setting" button	Click this button to display the Trace condition dialog box.



HELPFUL OPERATION

Clicking the [Project] \rightarrow [Export file] \rightarrow [File writing of Trace data] menu saves the trace data and trace conditions.

To read the trace data file, perform the following operation.

- 1. In the Select module type dialog box (refer to Section 11.1.2), choose the same model as the one at the time of write.
- 2. Display the wave trace window.
- 3. Click the [Project] \rightarrow [Import file] \rightarrow [File reading of Trace data] menu.
- 4. Click the "OK" button in the on-screen trace data overwrite confirmation dialog box.
- 5. Choose the file location and file name in the file opening dialog box and click the "Open" button to show the saved waveform data and trace conditions.

11 - 36 11 - 36



- Read a waveform trace file while the Wave trace window is displayed.
- When the number of trace points is great, acquisition of trace data may take time.
- The trace data files of QD75P/QD75D and those of LD75 differ in the file extension, and they are not compatible.

Positioning module	Extension
QD75P/QD75D	.wtr
LD75	.wtl

11.9 Location Trace

Using the location trace function in the trace mode, show 2-axis interpolation control or simultaneous start (2 axes) as locus data.

(Note that the QD75M, QD75MH and LD77 cannot be used.)

11.9.1 Location trace condition setting



PURPOSE

To execute the location trace, set the trace starting condition and the data to be traced.



BASIC OPERATION


1. Choose Location trace.



- 2. Click the "Setting" button in the Location trace window.
- 3. Set the Trace trigger, Stop condition, and axis and data to be traced in the Trace setting dialog box.
- 4. Click the "OK" button in the Trace setting dialog box.
- 5. For the tracing operation that follows, refer to Section 11.9.2.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description	
	Choose the actual trace starting condition.	
Trigger condition	No condition	
	Trace starts at the start request of the peripheral device.	
	Wait start	
	Trace actually starts when the start signal (X10/X11/X12/X13) turns on after the start	
	request from the peripheral device.	
	Choose the trace stopping condition.	
	Buffer full	
	Trace stops when the trace data area becomes full.	
	• Endless	
Trace stop mode	Trace stops at the stop request of the peripheral device.	
	• Error stop	
	Trace stops when an error occurs.	
	Trace point	
	[For QD75P and QD75D projects]	
	Trace stops when the number of trace points reaches the specified value (1 to 8192).	
	[For LD75 projects]	
	Trace stops when the number of trace points reaches the specified value (1 to 16384).	
Data 1	Represents the trace data No.	
Data 2		
	Choose the combination of the axes whose data will be traced.	
Axis selection	In the locus data of the trace results, the fist axis number is for the horizontal axis and the	
	latter axis number is for the vertical axis.	
	When you selected "#1-#4", #1 is for the horizontal axis and #4 for the vertical axis.	
	Choose the data type to be traced.	
Trace data	Command position	
	Locus data of the feed address from the QD75P, QD75D and LD75 to the servo amplifier.	
"OK" button	Click this button to close the Trace setting dialog box and display the axis numbers and data	
	types in the Location trace window.	

11.9.2 Location trace execution



PURPOSE

Execute location trace after setting the trace conditions in accordance with Section 11.9.1.




BASIC OPERATION

- 1. Perform the basic operation in Section 11.9.1 to set the trace conditions.
- 2. Click the "Trace" button to initialize trace.
- 3. When initialization is completed, click the "Start" button in the dialog box.
- 4. The trace data is read when the trace stop type condition is satisfied or the "Stop" button is clicked.
- 5. Check the QD75P, QD75D and LD75 control results from the displayed trace results.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description
Maximum value Minimum value	Show the maximum and minimum values during tracing of each data.
Time	Shows the tracing time.
Locus data	Shows the trace results.
	The horizontal and vertical axes indicate the respective addresses (travel distances) of the
	axis numbers set in trace condition setting.
	(When #1-#2 is selected as the axis number to be traced, the horizontal axis is Axis #1 and
	the vertical axis is Axis #2.)
	Use the scroll bars to move the display position.
Horizontal	Show the display multiplying factor of the locus data.
Vertical	Move — he to the right to enlarge or to the left to reduce.
Preserve aspect	Check this check box to make the locus data display multiplying factor equal in the vertical
	and horizontal directions.
Trace data	Shows the axes and data types set in the Trace setting dialog box.
"Trace" button	Click this button to initialize trace.
	On completion of initialization, the "Start" button in the dialog box is made valid.
	Clicking the "Start" button gives a trace start request to the QD75P, QD75D and LD75.
	If the trigger condition is "No condition", trace starts.
	If the trigger condition is "Wait start", trace actually starts when the trigger condition holds.
	Click this button to stop trace and show the trace results.
"Stop" button	If the stop condition is Buffer full, Error stop or Trace point, clicking the "Stop" button stops
	trace and shows the trace results available at that point.
"Default" button	Click this button to update the display to the latest trace data.
"Setting" button	Click this button to display the Trace condition dialog box.



HELPFUL OPERATION

Clicking the [Project] \rightarrow [Export file] \rightarrow [File writing of Trace data] menu saves the trace data and trace conditions.

To read the trace data file, perform the following operation.

- 1. In the Select module type dialog box (refer to Section 11.1.2), choose the same model as the one at the time of write.
- 2. Display the Location trace window.
- 3. Click the [Project] \rightarrow [Import file] \rightarrow [File reading of Trace data] menu.
- 4. Click the "OK" button in the on-screen trace data overwrite confirmation dialog box.
- 5. Choose the file location and file name in the file opening dialog box and click the "Open" button to show the saved locus data and trace conditions.

11 - 41 11 - 41



- Read a location trace file while the Location trace window is displayed.
- When the number of trace points is great, acquisition of trace data may take time.
- The trace data files of QD75P/QD75D and those of LD75 differ in the file extension and they are not compatible.

Positioning module	Extension
QD75P/QD75D	.wtr
LD75	.wtl

11.10 Help



PURPOSE

With the help function, you can check the following.

- Error/Warning/List of Buffer memory Details and actions of error codes/warning codes and the buffer memory address list of the QD75/LD75/LD77• Key operations list
- · Key operations list List of GX Configurator-QP operation methods from the keyboard
- About Version of GX Configurator-QP
- · Connection to MELFANS web



BASIC OPERATION

- 1. Click the [Help] menu.
- 2. Choose an item to be checked from the following menus.
 - QD75 error/warning/buffer memory list
 - LD75 error/warning/buffer memory list
 - · LD77 error/warning/buffer memory list
 - Key operations list
 - About
 - · Connection to MELFANS web


11 - 43 11 - 43

🔲 DIS

DISPLAY/SETTING SCREEN

[Error/Warning/Buffer memory List example]









For Windows Vista® and Windows® 7, not the Help screen but the following "Windows Help and Support" window may be displayed.

Perform the following procedure to install "WinHlp32.exe" which is needed to display the Help screen. (Note: The personal computer needs to be connected to the internet.)

[Windows Vista®]



[Windows® 7]



- (1) Click the "Help" button.
- (2) The screen shown left opens. Click the link section.
- (3) The Microsoft Support Knowledge Base page opens. (http://support.microsoft.com/kb/917607/en-us)
 Following the instructions, download Windows Help program for Windows Vista® (WinHlp32.exe) or Windows Help program for Windows® 7 (WinHlp32.exe).
- (4) Install the file that has been downloaded.

11 - 45

APPENDICES

Appendix 1 Read from Module/Write to Module Reference Processing Times

The following table indicates reference time required for read/write processing from GX Configurator-QP to the positioning module.

Item		Description
Positioning module		QD75MH
	СРИ	Pentium [®] III 933MHz, Microsoft [®] Windows [®] 2000 Professional Operating System
Peripheral	Memory	64MB
device	Interface	Serial port
	Transfer speed	9600bps, 19200bps, 115200bps
	Positioning data	Axis #1 to #4: No. 1 to 600 each
Read/write Block start data Axis #1 to #4: Blo		Axis #1 to #4: Block No. 0 to 4 each
data	Parameters	Axis #1 to #4
	Servo parameters	Axis #1 to #4

• Write (QCPU direct connection)

Transfer speed 9600bps: 1 minute 32 seconds

19200bps: 47 seconds 115200bps: 17 seconds

Read (QCPU direct connection)

Transfer speed 9600bps: 1 minute 32 seconds

19200bps: 58 seconds 115200bps: 17 seconds

Appendix 2 Restrictions Depending on Function Version of QD75

Note that the following functions are invalid when the function version "B" or later of the QD75 is not used.

To confirm the function version of the QD75, refer to "Section 7.3 Checking the Positioning Module Function Version (OS Information)".

Item	Description
Connection setup	Specify the PLC No. of the multi PLC system *1 (for multi PLC system).
Parameter	Make parameter setting for speed-position switching control (ABS mode). <speed-position function="" selection=""></speed-position>
Monitoring signal	Monitor the signals for the pre-reading start function *2. <y14 #1="" #4="" 17:="" axis="" execution="" flags="" prohibition="" to=""></y14>

- *1: For details, refer to the QCPU (Q Mode) User's Manual (Function Description/Program Basic).
- *2: For details, refer to the following.
 - Type QD75P/QD75D Positioning Module User's Manual (SH-080058-B or later)
 - Type QD75M Positioning Module User's Manual (Details)
 - Type QD75MH Positioning Module User's Manual (Details)

Appendix - 1 Appendix - 1

Appendix 3 Functions Added to/Changed from the Previous Versions

The following table indicates the functions of the latest GX Configurator-QP version that are not available for SW0D5C-QD75P-E or that have been changed from those of SW0D5C-QD75P-E.

Applicable Version *	Added to /Changed Function	Description	Refer To
	Change module type	QD75M is supported.	
	Servo parameters	The function to edit the servo parameters is added.	Section 8.2
	Read/write/verify	The function to read/write/verify the servo parameters is added.	
	Monitor	The function to monitor the servo status, torque control/servo load ratio, servo parameter setting contents and servo parameter error is added.	Section 10.2.6
	Servo amplifier data read	The function to read the servo parameter data used in the servo amplifier to the QD75M buffer memory is added.	Section 9.2
GX Configurator-QP Version 2.10L	Servo On/Off	The function to switch off the electromagnetic brakes of the servo motor to bring the servo motor into a free run status is added.	Section 10.5
	Print	The function to print the servo parameters is added.	Section 11.6.2
	Applicable programmable controller CPU	"Q00JCPU, Q00CPU, Q01CPU" are added.	Chapter 1
	Operating environment	The PC CPU module is added to the peripheral devices. Microsoft® Windows® Millennium Edition Operating System (English Version) is added to the operating systems. Microsoft® Windows® 2000 Professional Operating System (English Version) is added to the operating systems.	Section 2.2
	License key FD	The license key FD that was required for installation is disused.	_
GX Configurator-QP Version 2.13P	Applicable programmable controller CPU	"Q12PHCPU, Q25PHCPU" are added.	Chapter 1
	Servo parameters	When the MR-J2S-B is selected as the servo series, "B: MR-RB31, C:MR-RB51" are added to the regenerative brake options. When the MR-J2S-B is selected as the servo series, "Zeroing condition setting selection" is added.	Section 8.2
	Connection Setup	In the PLC side setting, a change has been made to select "Remote I/O" using "PLC type".	Section 7.1
GX Configurator-QP Version 2.14Q	Multi module batch write	 A change has been made to automatically display the dialog box for selecting the items to be written to the module when the write target project is selected. 	Section 11.1.4
GX Configurator-QP Version 2.15R	Operating environment	Microsoft® Windows® XP Professional Operating System (English Version) is added to the operating systems. Microsoft® Windows® XP Home Edition Operating System (English Version) is added to the operating systems.	
GX Configurator-QP Version 2.18U	Servo parameters	MR-J2S-B servo series parameters are added/changed.	Section 8.2
	Change module type	QD75MH is supported	_
GX Configurator-QP Version 2.20W	Servo parameters	MR-J3 servo series parameters are added.	Section 8.2
GX Configurator-QP Version 2.25B	Applicable programmable controller CPU	"Q02UCPU, Q03UDCPU, Q04UDHCPU, Q06UDHCPU" are added.	Chapter 1

^{*}: The applicable version can be confirmed in Product information. For details, refer to "Section 11.10 Help".

Appendix - 2 Appendix - 2

Applicable Version *	Added to /Changed Function	Description	Refer To
GX Configurator-QP Version 2.27D	Operating environment	 Microsoft® Windows Vista® Home Basic Operating System is added to the operating systems. Microsoft® Windows Vista® Home Premium Operating System is added to the operating systems. Microsoft® Windows Vista® Business Operating System is added to the operating systems. Microsoft® Windows Vista® Ultimate Operating System is added to the operating systems. Microsoft® Windows Vista® Enterprise Operating System is added to the operating systems. 	Section 2.2
GX Configurator-QP Version 2.29F	Applicable programmable controller CPU	"Q02PHCPU, Q06PHCPU, Q13UDHCPU, Q26UDHCPU, Q03UDECPU, Q04UDEHCPU, Q06UDEHCPU, Q13UDEHCPU, Q26UDEHCPU" are added.	Chapter 1
V 6151011 2.291	Servo parameters	MR-J3 full closed servo series parameters are added.MR-J3 servo linier series parameters are added.	_
GX Configurator-QP Version 2.30G	Connection Setup	"Ethernet direct" is added to the personal computer side interface. The default value of "Timeout time" for "RS232-C" or "USB" setting is changed to 10 seconds.	
	Servo parameters	The method for executing the default (initial) settings for each servo amplifier series selected is changed.	
GX Configurator-QP Version 2.32J	Applicable programmable controller CPU	 "Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU" are added. C Controller module, "Q12DCCPU-V" is added. 	
Version 2.323	Connection setup	The GOT transparent mode is added.	
	Change module type	LD75P4, LD75D4, and LD77MH4 are supported.	_
	Applicable programmable controller CPU	L02CPU and L26CPU-BT are added.	Chapter 1
GX Configurator-QP Version 2.34L	Operating environment	 Microsoft® Windows® 7 Starter Operating System is added to the operating systems. Microsoft® Windows® 7 Home Premium Operating System is added to the operating systems. Microsoft® Windows® 7 Professional Operating System is added to the operating systems. Microsoft® Windows® 7 Ultimate Operating System is added to the operating systems. Microsoft® Windows® 7 Enterprise Operating System is added to the operating systems. 	Section 2.2
GX Configurator-QP Version 2.35M	Operating Environment	64-bit Windows® 7 is supported.	Section 2.2

^{*} : The applicable version can be confirmed in Product information. For details, refer to "Section 11.10 Help".

Appendix - 3

APPENDICES MELSOFT


Appendix 4 Uninstalling the License Key FD

At installation of this product, uninstall the license key FD if the license key FD of an older version of GX Configurator-QP is valid.

If the license key FD remains valid, this product can be installed but the license right of the older version of GX Configurator-QP is decreased by 1.



Uninstallation of the license key FD requires the same license key FD as used for installation.



 Start Explorer and click the drive where the license key FD is inserted.

Double-click "Setup.exe".

To display Explorer, choose [Start] \rightarrow [Programs] \rightarrow [Windows Explorer].



2) Click the picture of the open lock.



3) Click the "Close" button.

Appendix - 4 Appendix - 4

APPENDICES

Appendix 5 Parameter Names Shown in GX Configurator-QP Screens and Manuals

Since the parameter names of the existing software are employed for GX Configurator-QP, some parameter names shown in GX Configurator-QP screens may differ from those written in the user's manual for the positioning module used.

The following table lists parameter names shown in GX Configurator-QP screens and user's manual for the positioning module used.

GX Configurator-QP screen		User's manual f	User's manual for the positioning module used	
Parameter type	Parameter name	Parameter type	Parameter name	
	Unit		Unit setting	
	Pulse per rotation		No. of pulses per rotation	
	Travel per rotation		Movement amount per rotation	
Basic parameter 1	Unit magnification	Basic parameters 1	Unit magnification	
	Pulse output mode		Pulse output mode	
	Rotation direction		Rotation direction setting	
	Bias speed at start		Bias speed at start	
	Speed limit		Speed limit value	
Basic parameter 2	ACC time #0	Basic parameters 2	Acceleration time 0	
	DEC time #0		Deceleration time 0	
	Backlash compensation		Backlash compensation amount	
	S/W stroke LMT HIGH		Software stroke limit upper limit	
	C/V Stroke EWITTHOLI		value	
	S/W stroke LMT LOW		Software stroke limit lower limit	
	C/VV GUIGNG ENTI EGVV		value	
	S/W stroke LMT select		Software stroke limit selection	
	JOG&MPG stroke limit		Software stroke limit valid/invalid	
			setting	
	Command in-position		Command in-position width	
	Torque limit		Torque limit setting value	
	M code ON output		M code ON signal output timing	
Extended parameter 1	Speed switching mode		Speed switching mode	
	Interpolation speed mode	Detailed parameters 1	Interpolation speed designation method	
	Address update in V-control		Current feed value during speed control	
	Lower limit		Input signal logic selection: Lower limit	
	Upper limit		Input signal logic selection: Upper limit	
	Drive unit READY		Input signal logic selection: Drive unit READY	
	Stop signal		Input signal logic selection: Stop signal	
	External command		Input signal logic selection: External command	

Appendix - 5

GX C	onfigurator-QP screen	User's manual f	or the positioning module used
Parameter type	Parameter name	Parameter type	Parameter name
71			Input signal logic selection:
	Zero signal		Zero signal
		1	Input signal logic selection:
	Near-point dog signal		Near-point (dog) signal
	LUDO	- -	Input signal logic selection:
	MPG		Manual pulse generator input
Cytopdod	O	Detailed	Output signal logic selection:
Extended parameter 1	Command pls signal	parameters 1	Command pulse signal
	DCC		Output signal logic selection:
	DCC	_	Deviation counter clear
	External input selection	_	External input signal selection
	MPG mode		Manual pulse generator input
	Wi G mode	_	selection
	Speed-position function selection	-	Speed-position function selection
	Forced stop selection		Forced stop valid/invalid selection
	ACC time #1	- -	Acceleration time 1
	ACC time #2	_	Acceleration time 2
	ACC time #3		Acceleration time 3
	DEC time #1		Deceleration time 1
	DEC time #2		Deceleration time 2
	DEC time #3		Deceleration time 3
	JOG speed limit		JOG speed limit value
	JOG ACC time		JOG operation acceleration time
	JOG ACC lime		selection
	JOG DEC time		JOG operation deceleration time
	300 DEC time	-	selection
	ACC/DEC set		Acceleration/deceleration process
Extended	AGGIBLO SCI	Detailed	selection
parameter 2	S-curve ratio	parameters 2	S-curve ratio (S-pattern ratio)
	Sudden stop DEC time		Sudden stop deceleration time
	Stop group #1 Sudden stop		Stop group 1 sudden stop
	etop group m. Guadon etop	-	selection
	Stop group #2 Sudden stop		Stop group 2 sudden stop
	ottop group in a caution stop	-	selection
	Stop group #3 Sudden stop		Stop group 3 sudden stop
		-	selection
	Positioning complete signal		Positioning complete signal
		-	output time
	Cir.arc error allowance		Allowable circular interpolation
		-	error width
	External command function		External command function
			selection

Appendix - 6

GX Configurator-QP screen		User's manual for the positioning module used	
Parameter type	Parameter name	Parameter type	Parameter name
Detailed parameter 2	Speed control 10x multiplier		Speed control 10x multiplier
	device for degree axis	Detailed	setting for degree axis
	Restart allowable range when	parameters 2	Restart allowable range when
	servo OFF \rightarrow ON		servo OFF to ON
	OPR method		OPR method
	OPR direction		OPR direction
OPR	OP address	OPR	OP address
basic parameter	OPR speed	basic parameters	OPR speed
	Creep speed		Creep speed
	OPR retry		OPR retry
	OPR dwell time		OPR dwell time
	Travel setting after DOG ON		Setting for the movement amount
	Traver setting after BOO ON		after near-point dog ON
OPR	OPR ACC time		OPR acceleration time selection
	OPR DEC time		OPR deceleration time selection
	OP shift amount	OPR	OP shift amount
extended	OPR torque limit value	detailed	OPR torque limit value
parameter	Deviation command signal out	parameters	Deviation counter clear signal
parameter	time	parametere	output time
	Operation setting for home		Operation setting for incompletion
	position return incomplete		of OPR
	OP shift speed specification		Speed designation during OP shift
	Dwell time during OPR retry		Dwell time during OPR retry

Appendix - 7 Appendix - 7

INDEX

[2]
2-axis interpolation control
assisting the setting of 8- 9
simulation of8-13
trace of 11-38
[A]
Active project5- 2, 6- 8, 15, 16, 9- 2, 6,
10-30, 11-1, 3, 5, 17, 26
All axis stop 10- 1
application
ending 4-32
starting 4-31
assistance
of axis speed setting8-10
of circular interpolation control setting 8- 9
of software operation11-45
automatically
setting axis speed 8- 10
storing buffer memory values 11- 5
Axis #1 to #4
error reset of7-10, 12, 10- 1
turning off the M code ON signal of 10- 1
axis control monitor
axis copy
axis status
unio statuo 7 0, 10 0
[B]
batch write 11- 9
block
copy11-19
switching 5- 1, 8-19
block start data
error (project)8-20
error (module)10- 2
initialization11-17
setting 8-18
buffer memory
assigning to devices 11- 7
list11-43

[0]	
cable	2- 7, 7- 4
cableless test	10-30
check box	5- 3
column clear	11-16
COM port setting	7- 1
command button	
comment	
M code	8-12
positioning data	8- 8
condition	
of special start	8-16
of trace start	
condition data	
connection setup	7- 1
сору	
of block start data	11-19
of selection range	11-11
on axis basis	
CSV format positioning data file	
reading of	6-15
writing of	
cut	
[D]	
data initialization	11-17
Deleting the project	
display	
of status bar	5- 1
of toolbar	5- 1
drop-down menu	
·	
[E]	
end	
of application	4-32
of monitor	
of test	
entering present value to address	
error	
check (module)	10- 2
check (project)	
code list	
monitoring code	
monitoring the history of	
-	7 ₋ 10 12 10-1

opening project 6- 6
utilizing data6-11
[F]
file reading of SW0D5C-AD75P 6-11
file reading of SW1RX/IVD/NX-AD75P 6-11
flash ROM
initializing 9- 6
request 9- 6
function version 7- 9
[G]
GOT transparent mode2- 3, 5, 7- 6
[H]
help 11-43
history monitor10- 7
rii
I/O address
checking of7- 5
setting of 7- 3
icon
arranging of 5- 1
3 3 3
reducing window to 5- 1
reducing window to 5- 1
reducing window to 5- 1 in execution
reducing window to

[K]	
keyboard operation	
block start data edit by	8-16
focus movement by	5- 4
for dialog box	5- 3
for project tree view	5- 2
parameter edit by	8- 1
positioning data edit by	8- 3
[L]	
list	
buffer memory address	
error/warning code	
function	
menu	
shortcut key	
tool button	
list box	
location trace using	11-40
locus data	
simulation using	8-14
[M]	
M code	
comment edit	
turning off the ON signal	10- 1
makeup	
of product	
of programmable controller	
of system	
of this manual	1- <i>i</i>
menu	.
drop-down	
list	
right-click5- 2, 8- 2,	
model selection module	0- 2, 11-3
initialization	10 6
read	
verify	
write	
module version	

monitor	
during OPR	10-17
of axis control status	10-13
of axis speed10- 5	5, 15, 16
of axis status	10- 5
of block start data in execution	10- 4
of buffer memory	
of external I/O signals	
of JOG operation	
of MPG operation	
of positioning data in execution	
of status signal	
of X/Y device	
On/Off 10- 4, 5	
positioning module error/	,, <u>L</u> O, <u>L</u> 1
warning history	10- 7
under position/	10- 7
velocity switching control	10-16
under velocity/	10-10
position switching control	10_15
monitoring external I/O signals7-1	
movement	1, 10-11
	11 16
of cursor to specified data No	
of focus	5- 4
MPG operation	40.40
monitoring	
performing	10-38
multiple	
opening projects	
writing to modules	
multiple CPU setting	7- 2
[N]	
navigation	11-20
new	
creating directory	6- 4
creating project	6- 2
module read	6- 5
[O]	
On/Off	
monitor 10- 4, 5	5, 25, 27
of signal7-12, 10- 9, 10), 11, 12
test	10-27
online	
positioning data edit during	11-32
status	4-32
online toolbar	5- 1

	open	
	CSV file	6-15
	project	6- 6
	SW1RX/IVD/NX-AD75P file	6-11
	trace data file1	
	operation	
	displaying results as locus data	11-40
	displaying results as waveform data	
	JOG for specifying travel distance	
	monitor	
	monitoring status	
	test 10-32, 35, 3	
	OPR	-,, -
	monitor	10-17
	test	
	option	
ſF	기	
•	parameter	
	error (project)	8-20
	error (module)	
	initialization	
	setting	
	paste	
	position/velocity control monitor	10-16
	positioning data	
	assisting the setting of	.8- 9, 10
	batch setting of	
	comment	
	comment display	
	copying of (axis basis)	
	cutting/copying/pasting of	
	display color of8-	
	displayed number of	
	error (project) of	
	error (QD75/LD75/LD77) of	
	setting of	
	preview	
	print	
	printer setting	
	procedure	
	for opening project	6- 6
	installation	
	new module read confirmation	
	of navigation	
	of new project creation	
	work until positioning operation	

	product
	information11- 41
	makeupA-12
	product ID 4- 5
	Programmable controller
	corresponding1- 1
	storing buffer memory values into 11-5
	type of 7- 2
	project
	active 5- 2
	makeup 6- 1
	project path change 6- 4
	project tree view 5- 1
[C	מ
_	Q corresponding MELSECNET/H network
	remote I/O module 1- 1, 2- 2, 7- 1, 9- 1
	Q corresponding serial communication
	module1- 1, 2- 1, 7- 2, 5
	QD75/LD75/LD77 READY signal (X0) 11-24
[F	श
	radio button 5- 3
	read
	from HD/FD6- 6
	from positioning module 10- 1
	from SW0D5C-AD75P format file 6-11
	from SW1RX/IVD/NX-AD75P format file 6-11
	of trace data11-36, 41
	remote I/O7- 1
	right-click menu 5- 2, 8- 2, 10-28, 11-11,12
	row clear 11-17
	RS-232C cable2- 1, 7- 2
[S	51
•	sampling monitor10-25
	save
	data in flash ROM of positioning module 9-6
	of auto refresh setting11- 9
	of project 6- 8
	of trace data11-36, 41
	save as
	Select all
	servo amplifier data read 9- 6

servo monitor	10-19
servo On/Off	10-42
servo parameter setting	8- 3
setting	
of block start data	8-16
of condition data	8-18
of M code comment	8-12
of parameters	8- 1
of positioning data	8- 3
of print range	11-28
of printer	
of selection range in batch	11-12
option	
shortcut key	
signal monitor	
single-module test	
software registration card	
specifying access target	
speed	
automatic setting of	8-10
monitoring10- 5	, 15, 16
speed change test	
spin box	
spreadsheet software data	
copying from	11-12
reading	
writing to	
SSCNET	
(Servo System Controller NETwork)	8- 3
start	
of application	4-31
of monitor10- 4, 5	, 25, 27
of test	
status bar	5- 1
status signal monitor	10-12
stop	10- 1
switching	
of block to be edited5-	1, 8-17
of window	5- 4
system configuration	2- 1
system monitor	7- 8

[7]	
_	tab	5- 3
	teaching	11-30
	test	
	by JOG operation	10-40
	by MPG operation	10-40
	of block start data	10-32
	of ON/OFF of external I/O signals	7-10
	of positioning data	10-32
	of module alone	
	On/Off	10-28
	OPR	10-38
	present value change	
	speed change	
	test mode	
	positioning data edit in	11-32
	shift to	
	test without external device	
	text box	
	time-out	
	title bar	
	toolbar	
	trace	
	displaying the results of	11-35 40
	setting the conditions of	
	trace data file	11 00, 00
	read of	11-36 41
	write of	
	transmission speed	
	transmission speed	
ſι	n	
	uninstallation	4-27
	USB2- 1, 3,	
	utilizing AD75 data	
	dilizing AD75 data	0-11
[\	л	
L۷	velocity/position control monitor	10_15
	verify	10-13
	module data	0 1
	of project	
	version	1 1- 1
	of GX Configurator-QP	11 /12
	_	
	of positioning module	
	virtual positioning	ठ-13

[W]		
W	arning	
	checking code definition	11-43
	monitoring the history of	10- 7
W	aveform data	
	sampling using	10- 25, 27
	simulation using	8-13
	trace using	11-35, 40
W	indow	
	cascade	5- 1
	close all	5- 1
	tile	5- 1
W	'indows®	2- 7, 9,10
W	rite	
	in CSV format	6-16
	of trace data	11-36, 41
	to flash ROM	9- 7
	to HD/FD	6- 8
	to positioning module	9- 1
[X]		
X	device monitor	10- 9
[Y]		
	device monitor	10- 9
	device monitor	10

Microsoft, Windows, Windows NT, and Windows Vista are registered trademarks of Microsoft Corporation in the United States and other countries. Pentium is either a trademark or registered trademark of Intel Corporation in the United States and other countries. Other company and product names herein may be either trademarks or registered trademarks of their respective owners. VS-FlexGrid Pro Copyright(C) 2000 VideoSoft Corporation

GX Configurator-QP Version 2

Operating Manual

MODEL	SW2D5C-QD75P-O-E	
MODEL CODE	13JU19	
SH(NA)-080172-O(1205)MEE		



HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS : 1-14 , YADA-MINAMI 5-CHOME , HIGASHI-KU, NAGOYA , JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.